



Division of Water Resources
1-888-891-8332 (TDEC)
General NPDES Permit for Stormwater Discharges
from Industrial Activities (TMSP)

Sector AC - Summary

You now have Tennessee Multi-Sector Stormwater Permit (TMSP) coverage. Here's what to do next:

1. Keep the **Notice of Coverage (NOC)** on-site (*Section 4.2.2 of the TMSP*)
2. Make sure the **Storm Water Pollution Prevention Plan (SWPPP)** is signed (*Section 4.2.1 of the TMSP*), kept on-site, and contains at a minimum the following information (*Section 3 of Sector AC*):
 - List of the pollution prevention team members;
 - Drainage map showing outfalls and directions of stormwater runoff;
 - Description of potential pollutant sources at the facility; and
 - Description of ways to prevent pollution of stormwater
3. Make sure that stormwater management controls described in the SWPPP are in place. For example:
 - Maintain areas onsite that may contribute pollution to stormwater (*Section 3.2.3.1 of Sector AC*);
 - Conduct preventive maintenance of equipment (*Section 3.2.3.2 of Sector AC*); and
 - Have a procedure in place for cleaning up spills that may occur onsite (*Section 3.2.3.3 of Sector AC*)
4. Conduct inspections, make notes, and keep inspection notes on-site:
 - ✓ **Appropriate intervals (monthly recommended)** – during dry weather, check areas that may cause pollution of stormwater (*Section 3.2.3.4 of Sector AC*);
 - ✓ **Quarterly** – when it rains, check all outfalls for signs of pollution (*Section 5 of Sector AC*); and
 - ✓ **Annually** – during dry weather, check entire site and all outfalls (*Section 3.2.4 of Sector AC*):
 - Write a report describing any problems noted during the inspection

Disclaimer: This document is strictly an outline of TMSP permit requirements and is not intended to replace the TMSP and specific sector documents. The permittee is obligated to comply with all terms and conditions outlined in the permit, found here: <http://state.tn.us/environment/permits/tmsp.shtml>.