MILEAGE

LEGEND Check Mark or X = OK, R = Repair Needed, N/A = Not Applicable, Blank = Not Inspected

PM-A CHECKLIST (grease & check)

APPROACH & DRIVER compartment	OUTSIDE WALK AROUND lights o	Brake adjustment
Fluid leaks on ground	Exterior lights / Stepwell / Stop / Reverse	Exhaust system / Hangers, clamps, leaks
Bus leaning	Reflectors / Reflective tape	Transmission / Leaks, wiring & vent
Entrance door op, condition & seals	Emergency doors / lube buzz sw & latch	Splash guards
Grab handles secure	Wheel Chair Lift / lube / inspect / adjust	Wheels, lug nuts, hubs, hub oil level
Step well / Step treads	W/S washer fluid / wiper arms & blades	Lube all fittings and pivot points
Cleanliness	Door & compartment hinges	Tire pressure as per recommendation
Emergency Equipment	Body damage	Tire tread depth min 6/32's Rr 4/32 Ft
Drivers Seat & Seat belt	Storage Comp / Clean / Dry / Cond	ENGINE COMPARTMENT / FLUIDS
Gauges before start / KOEO / Warning lamps	Engine compartment / Doors / RE	Motor oil level
Wait to start lamp / Intake heater cycle	Batteries / water / clean / cables / tray	Hydraulic / Steering oil level
Starter operation	Stop arms visual	Coolant level / radiator & bottle
Gauges after start / KOER	Electrical panels / wires, fuses, breakers, etc	Radiators / clean / condition
Engine operation	Child Check Monitor	Coolant test / PH Freeze Pt
Air Build up / Cut out psi	RAISE BUS ON HOIST	Molybdate PPM Nitrite
Parking brake hold @ 1200 rpm	Step well & light wiring	Fluid leaks / Fuel / Coolant / Oil / Hyd-PS
Brake interlock / pump brakes dn / popping?	Belts, hoses & clamps	Air filter / minder, ducts, clamps (comp inlet)
Low air warning >60 psi /	Fluid leaks	Heater valves on - YES NO
Park brake valve set (pop out 20-40 psi)	Wiring & cables (power and ground)	Fan & Fan Clutch / wiring, air hoses, etc
PP1 knob and pin / build air / KOEO	Starter, junctions, clean & tight	Bolts and brackets
Steering wheel straight / Tilt / Tele	Steering gear, linkages, tie rod ends	Wiring & connectors
Turn signals and cancelation	Front axle, springs, pins, bags, valves,	Compartment light
4 way hazard lights	shocks & brackets, etc.	Belts, hoses, clamps
Head lights / Hi/Lo indicator	Front brake lining / drums / rotors	Alternator wiring / mounts
Dome lights / Panel lights / Dash lights	Front axle seals	Belt tensioner / Pulley alignment
Mirror condition / Controls / Defroster	Front brake hoses, cans, slacks	After cooler / hoses / clamps
Sun Visor / Mounts / Condtion	Brake adjustment	Shutters
Heater / Defroster / Dash Fans / Knobs	Drive shafts, carriers, u-joints	Compartment cover seal
Wipers / Washers / Windshield Condition	Visual air dryer, Oil?	Engine cleanliness
Horns / air & city / dual tone	Air tanks, moisture or oil?	FINISH UP DETAILS
Service door operation	Fuel tanks, lines and filters	Service sticker
INTERIOR INSPECTION	Differential oil level / vent	Inspection sticker, OK?
AM/FM Radio & PA sys	Rear axle, springs, pins, bags, valves,	Other PM's due?
Passenger Seat Condition / secure	shocks shock brackets, etc.	Check and clear diagnostic codes
All fasteners - Interior	Rear brake lining / drums / rotors	Clean up & wipe off
Side Windows / Latches / Lube	Rear axle seals	Electronic Work Order
Emerg X, latch, operation, buzzers, decals	Rear brk hoses, cans, slacks, etc.	

PM-B CHECKLIST (lube, oil & filters) (includes PM-A above)

Drain motor oil if required.	Change required oil filters	Change coolant filter	
Sample motor oil	Change required fuel filters	Fuel/Oil additive	

PM-C CHECKLIST (Annual, includes a PM-A)

Replace air filter	Chg hydraulic / P/S oil & filters	Battery cables / grounds, remove, clean, coat	
Change trans fluid and filters	Rebuild air dryer		
Change rear differential oil	Batteries, clean & test		

NOTES: