


# Vapor Intrusion Assessments

## Introduction to Collecting Quality Vapor Samples


- Regulatory overview
- Sampling methodologies
- Equipment
- The laboratory




**Tom Yoder**  
Product Manager

**John Reynolds**  
Customer Service Manager

# The migration of volatile chemicals from the subsurface into overlying buildings.



# Vapor Intrusion Timeline



# Final EPA VI Guidance

FINALLY

OSWER Publication 9200.2-154

## OSWER TECHNICAL GUIDE FOR ASSESSING AND MITIGATING THE VAPOR INTRUSION PATHWAY FROM SUBSURFACE VAPOR SOURCES TO INDOOR AIR

U.S. Environmental Protection Agency  
Office of Solid Waste and Emergency  
Response

June 2015

OUST Publication EPA 510-R-15-001

## Technical Guide For Addressing Petroleum Vapor Intrusion At Leaking Underground Storage Tank Sites

U.S. Environmental Protection Agency  
Office of Underground Storage Tanks

June 2015

# EPA Proposed Rule

## Federal Register - 40 CFR Part 300 - Addition of a Subsurface Intrusion Component to the Hazard Ranking System; Proposed Rule

EPA-HQ-SFUND-2010-1086; FRL-9925-69-OLEM

- On Feb. 29, 2016, the EPA proposed to add a subsurface intrusion (Ssl) component to the Hazard Ranking System
  - used to evaluate sites for placement on the National Priorities List (NPL).
- Enables EPA to use remedial authority under CERCLA.
  - introduces a complex scoring system to quantify the threat of intrusion.
  - includes radionuclides.
- Does not affect the status of current sites or current proposed sites.
- Comments are due by April 29, 2016.
- Projected publish date of Dec. 2016

<https://yosemite.epa.gov/opei/rulegate.nsf/byRIN/2050-AG67>

# Vapor Intrusion – Chemicals of Concern

- The two most common classes of chemicals of concern are: **chlorinated solvents (CHCs) and petroleum hydrocarbons (PHCs).**
- PHCs typically biodegrade in groundwater and in unsaturated soil zones. This aerobic biodegradation can limit the potential for petroleum vapor intrusion (PVI).
  - ~ In the presence of oxygen, PHCs biodegrade readily.
- In contrast, biodegradation of CHCs is anaerobic, which is generally slower. This limited biodegradability is to some degree responsible for the greater observed prevalence of chlorinated solvent vapor intrusion (CVI) as compared with PVI.



**TABLE 1-2  
DIRECTORY TO ADDITIONAL UPDATES IN THIS TECHNICAL GUIDE PUBLICLY  
IDENTIFIED BY OSWER (EPA 2010B)**

Topics to Be Updated, Including References to the Draft VI Guidance	Location Within This Technical Guide
Observational data since 2002 indicates that the "single line of evidence" approach with site-estimated attenuation factors is generally not appropriate for external soil gas samples.	Section 6.4.4 and Appendix A
Experiences since 2002 illustrate the value of collecting indoor air samples earlier in the investigations. The "indoor air last" approach has been updated, which will allow more flexibility in the sequencing of subsurface and interior/indoor sample collection.	Sections 6.3.4 and 6.3.8
The portions addressing background contamination have been updated. EPA also updated with more specific methodologies for evaluating and/or decision-making and managing background contamination.	Sections 6.3.5, 7.4 and 7.8
The portion of this Technical Guide focusing on testing indoor air has been updated to allow more flexibility in the duration of sampling to take advantage of other sampling durations and methods.	Section 6.4.1
The Draft VI Guidance allows site-specific decisions to be made based on indoor air concentrations in a relatively few representative buildings. This portion of this Technical Guide has been updated to increase the confidence that the approach fully addresses building-by-building variability.	Sections 6.2.2 and 7.8

Page 15, Table 1-2  
Note important  
updates to Indoor Air  
Testing

# Key Recommendation Highlights

Limit analyses to chemicals of concern

- Section 6.4

Assess the VI pathway using multiple lines of evidence

- Sections 6.3, 7.1 & 7.2

Generally support the decision to collect indoor air data

- Section 6.3.4 & 6.4.1

Consider collecting multiple rounds of indoor air samples

- Section 7.4

Document objectives and methods in a VI work plan

- Section 6.2



# The Conceptual Site Model (CSM)

“A CSM integrates all lines of site-specific evidence into a three dimensional conceptualization of site conditions...”

A picture and narrative of the site and it's contamination

- How it got there
- Is it migrating or degrading
- It's distribution across the site
- Who might be exposed and at what levels

Considerations:

- Site conditions and historical data
- Screening levels being applied
- Sampling protocols being used
- Compounds of concern
- Anticipated concentrations

Section 2.0 -  
The CSM will help  
guide the DQOs




Rick Ehrhart, RCRA Corrective Action, EPA Region 6, [ehrhart.richard@epa.gov](mailto:ehrhart.richard@epa.gov)

***Involve the lab early to ensure that data quality objectives can be met.***

# Sources of Variability




[http://www.itrcweb.org/gd\\_VI.asp](http://www.itrcweb.org/gd_VI.asp)




## *Sources of Potential Variability in Measured Data*

- Barometric pressure
- Surface cover
- Preferential pathways
- Soil moisture & permeability
- Seasonal effects: Advection
- Biodegradation
- Background air

# Multiple Lines of Evidence

		Chemistry	Geology	Hydrology	Weather	Building	Biology
 Vapor Intrusion More Likely	High Source Conc., Highly Volatile and Toxic Compounds	Vertically Fractured Media; Coarse-Grained, Uniform Stratigraphy	Low Moisture Content, Shallow Water Table, Large Water Table Fluctuations	Heating Season, Falling Barometric Pressure, Heavy Rains, Strong Winds	Cracked Slab, Sumps, Partial Slabs, Low Air Exchange Rate, Tall Buildings in Cold Climates	Non-Degradable compounds or Degradable PHCs and Anoxic Conditions	
	Low Source Conc., Less Volatile and Toxic Compounds	Horizontal and Laterally Extensive Fine-Grained Layers with High Moisture Content	Thick Capillary Fringe, Deep Water Table, High Moisture Content	Increasing Barometric Pressure, Minimal Wind, Moderate Temperature	HVAC System with Positive Pressure, High Air Exchange Rate, Intact Slab	Degradable PHCs and Oxygen-Rich Conditions	
 Vapor Intrusion Less Likely							

# Vapor Intrusion Concurrent Sampling



Contaminated Groundwater

# Indoor Air Sampling

## Pros

- Actual indoor air concentration, no modeling, no attenuation factors
- Relatively quick, no drilling or heavy equipment
- Less spatial variability than soil gas

Section 6.4.1  
“A potential  
shortcoming of  
indoor air is  
background”

## Cons


- Working with the “Homeowner” or “Building owner” requires time, effort and finesse
- Access agreements, factsheets, meetings
- Requires removal of potential interior or lifestyle sources
- **Contribution from unknown indoor sources and ambient air**

Per EPA: Collect indoor samples and compare with controls

- Sub slab, ambient, lines of sight and building specific evidence



# Background Contamination



Source: NJDEP

## Common Household Contaminants

Acetone	Formaldehyde
Benzene	n-Heptane
Bromomethane	n- Hexane
2-Butanone (MEK)	Methylene chloride
Chlorobenzene	Methyl isobutyl ketone
Chloroethane	Methyl tert butyl ether
Chloroform	Styrene
Cyclohexane	1,1,2,2-Tetrachloroethane
1,4-Dichlorobenzene	Tetrachloroethene (PCE)
Dichlorodifluoromethane	Toluene
1,1-Dichloroethane	1,1,1-Trichloroethane
1,3-Dichloropropene	Trichloroethene (TCE)
Ethylbenzene	Xylenes, total

- Consumer Activities
- Household Products
- Building Materials
- Outdoor Air

Section 6.3.5  
Identify & Evaluate  
Contributions from  
Indoor & Ambient  
Sources

# Sub Slab Sampling

## Pros

- Can be used to resolve indoor sources vs. a VI source
- Can be used to assess if the VI migration route is complete
- Can be used to assess the potential for VI risk

## Cons

- Method is intrusive
- Requires access agreement and entry into buildings.
- **Substantial spatial variability under the slab**

Per EPA: Collect multiple samples per building to address spatial variability and multiple rounds to address temporal variability.


Section 6.4.3  
“There may be substantial spatial variability in sub-slab soil gas”



# “In Field” Leak Detection

## Leak check procedure /Tracer Gases:

- Use a portable monitoring device to analyze prior to sampling
- If high concentrations ( $> 10\%$ ) are observed, the probe seal should be enhanced to reduce the infiltration of ambient air



Companies such as:



<http://www.ashtread-technology.com/us/>

Section 6.4.4 “a reliable seal of the annulus between the probe and the probe housing and leak testing for the seal are generally recommended”

[https://www.health.ny.gov/environmental/investigations/soil\\_gas/svi\\_guidance/docs/svi\\_main.pdf](https://www.health.ny.gov/environmental/investigations/soil_gas/svi_guidance/docs/svi_main.pdf)

# Soil Gas Sampling

## Pros

- Near source, it may provide an estimate of source vapor concentration
- Can be performed without entering the structure

## Cons

- Significant lateral and vertical spatial variability
- May not be representative of vapor concentrations under buildings

Per EPA: “Several rounds of sampling are generally recommended, particularly...”

Section 6.4.4 “individual exterior soil gas samples cannot generally be expected to accurately estimate sub-slab or indoor air concentrations”



# Field Quality Control Samples



## Field Duplicates

- Require the use of a “T-fitting” or “Co-locator”





# Media Selection

Determined by reporting limit requirements

## Summa Canisters:

**Soil Gas:** 1L generally acceptable

**Ambient & Indoor Air:** 6L only

## Flow Controllers

- Preset by the laboratory for 5 min- to 24hrs

## Tedlar Bags:

- For gases and high levels of detection



# Sampling Equipment



6 liter canister with 200 ml flow meter



6 liter canister with 24hr flow controller



200 ml flow meter with filter and gauge  
– Soil gas sampling



Flow controller with filter and gauge  
– Indoor or ambient sampling

# Media Certification and Management

Canisters are segregated for cleaning

- Low level (ambient & indoor)
- Source level (soil gas)

Canister Cleaning

- Evacuated, heated, pressurized w/ zero air or nitrogen

Certification

- Batch or individual
- Leak free – overnight leak check test required

Flow Controller Certification: Cleaned & Performance checked



# Tubing & Gauges, Impact to Data?

## Field Sampling Media

### Tubing options:

Stainless steel < **Teflon FEP** < Polyethylene < **Nylaflow**

### Tips:

Minimize length and store properly

**Initial Vacuum** – confirm sufficient vacuum is in the canister.

- ▣ Range will be 25-30”Hg

**Final Vacuum** – confirm sufficient sample was collected.

- ▣ Range should generally be 10-0”Hg





# Shipping, Preservation and Holding Times

## Canisters

- No preservation required
- Can be shipped by air with a few caveats
- **Hold time specified in TO-15 is 30 days**

Section 6.4.1  
“Fourteen days is the  
most commonly cited  
hold time for air  
samples in canisters”




## Tedlar bags

- No preservation required
- Can be shipped by air with a few caveats
  - ~ Do not overfill
- Hold time is 72hrs



# Involve Your Laboratory in the Planning Process

- Compounds of concern & anticipated concentrations
- Detection limits
- Type(s) of sampling equipment
  - ~ 1 liter vs 6 liter
  - ~ Batch vs Individual certification
  - ~ Tubing
  - ~ Flow controllers and settings
  - ~ T-fitting
  - ~ Extra fittings
- Number of samples
- Sample types
- Report type



***Involve the lab early. Request comments on the conceptual site model (CSM) and achievability of data quality objectives***

# Summary

Do not take samples unless you have some idea of what the data is going to tell you

- Conceptual Site Model

Define your data quality objectives up front, this will determine the appropriate containers, collection procedures and analyses

Over communicate with your testing laboratory. Teamwork up front will ensure less discussion when you receive your data

***Data quality is a function of the whole process: the project set up, the field sampling protocols, and the analytical protocols***

# Thank You for Attending

## Questions?

# Vapor Intrusion Contacts

## TestAmerica Burlington, VT

- Don Dawicki
- 802-660-1990
- 802-923-1026 (direct dial)
- [don.dawicki@testamericainc.com](mailto:don.dawicki@testamericainc.com)

## • Ambient Air Product Manager

- ~ Tom Yoder in Knoxville, TN
- ~ 865-291-3000
- ~ 865-291-3030 (direct dial)
- ~ [tom.yoder@testamericainc.com](mailto:tom.yoder@testamericainc.com)

## TestAmerica Knoxville, TN

- Jamie McKinney
- 865-291-3000
- 865-291-3051 (direct dial)
- [jamie.mckinney@testamericainc.com](mailto:jamie.mckinney@testamericainc.com)

## • TestAmerica Phoenix, AZ

- ~ TO-17 and passive sampling
- ~ Kylie Emily
- ~ 602-437-3340
- ~ [kylie.emily@testamericainc.com](mailto:kylie.emily@testamericainc.com)

## TestAmerica Sacramento, CA

- Taryn McKnight
- 916-373-5600
- 916-374-4340 (direct dial)
- [taryn.mcknight@testamericainc.com](mailto:taryn.mcknight@testamericainc.com)