

Collection Systems

Grades 1 – 2

Course #401



2024 Edition



Collection Systems

Section 1	Exam Need to Know & References	1
Section 2	Wastewater/Collections Systems Overview	13
Section 3	Flow Measurement	33
Section 4	Pipe Materials	49
Section 5	Pipe Installation	59
Section 6	Lift Stations	67
Section 7	Inspection & Testing	81
Section 8	Cross Connection Control	95
Section 9	Safety & Trenching	113
Section 10	Pumps	145
Section 11	Equipment Maintenance	169
Section 12	Pipeline Cleaning & Maintenance	183
Section 13	Underground Repair	205
Section 14	Sewer Rehab & Rehabilitation	217
Section 15	Rules and Regulations	227
Section 16	Sacramento Review Questions	285

Section 1

Exam Need to Know & References

Suggested Collection System Exam References

The following are approved as reference sources for the collection examinations. Operators should use the latest edition of these reference sources to prepare for the exam.

Textbooks

California State University, Sacramento (CSUS) Foundation, Office of Water Programs (www.owp.csus.edu)

- Operation of Wastewater Treatment Plants, Volume I and II
- Operation and Maintenance of Wastewater Collection Systems, Volume I and II
- Manage for Success

Water Environment Federation (www.wef.org)

- Operation of Municipal Wastewater Treatment Plants - Manual of Practice No. 11
- Existing Sewer Evaluation and Rehabilitation - Manual of Practice FD-6
- Wastewater Collection Systems Management - Manual of Practice No. 7

Regulations

- Code of Federal Regulations, Title 40 (www.gpo.gov).
- Design Criteria for Sewage Works, State of Tennessee, Department of Health and Environment, Division of Water Pollution Control, Nashville, 1995.
- Rules Governing Water and Wastewater Operator Certification, State of Tennessee, Department of Environment and Conservation, Board of Certification for Water and Wastewater Operators, Nashville, TN, December 2009, Section 1200-5-3.
- State of Tennessee Cross-Connection Control Manual, State of Tennessee Department of Environment and Conservation, Division of Water Supply, 2008

Study Guides

- WEF/ABC Collection Systems Operator's Guide to Preparing for the Certification Examination, Water Environment Federation, (www.wef.org).
- Applied Math for Wastewater Plant Operators, Price, Joanne. 2000. Boca Raton, FL: CRC Press (www.crcpress.com).

Suggested Primary Collection System Exam References

The following are approved as reference sources for the ABC water treatment examinations. Operators should use the latest edition of these reference sources to prepare for the exam. These reference are not the only reference an operator should use in studying for the exam, however, these are the primary references used in developing the exam.

Collection 1

- ****CSUS Operation and Maintenance of Wastewater Collection Systems Volume I**
- ****CSUS Operation of Wastewater Treatment Plants Volume II**
- *Design Criteria for Sewage Works State of Tennessee Department of Health and Environment Division of Water Pollution Control Nashville, Latest Revision*
- **CSUS Operation and Maintenance of Wastewater Collection Systems Volume II**
- **CSUS Operation of Wastewater Treatment Plants Volume I**
- **Price Joanne Kirkpatrick Applied Math for Wastewater Plant Operators Technomic Publishing Company Inc. Lancaster PA 1991**
- *Rules Governing Water and Wastewater Operator Certification, State of Tennessee, Department of Environment and Conservation, Board of Certification for Water and Wastewater Operators, Nashville, Latest Revision*

Collection 2

- ****CSUS Operation and Maintenance of Wastewater Collection Systems Volume I**
- ****CSUS Operation of Wastewater Treatment Plants Volume II**
- ****CSUS Operation and Maintenance of Wastewater Collection Systems Volume II**
- **CSUS Operation of Wastewater Treatment Plants Volume I**
- *Design Criteria for Sewage Works State of Tennessee Department of Health and Environment Division of Water Pollution Control Nashville, Latest Revision*
- **CSUS Operation and Maintenance of Wastewater Collection Systems**
- *Rules Governing Water and Wastewater Operator Certification, State of Tennessee, Department of Environment and Conservation, Board of Certification for Water and Wastewater Operators, Nashville, Latest Revision*

There are 2-3 primary references for each of exam. The ** denotes that 20+ of the exam items are linked to the noted reference.

Bold items have at least three items linked to them. Any references that are not in bold, have only 1-2 items linked to them.

The Tennessee State references are included, however, there is a sixth reference if the sixth had at least three items linked to it; in some cases this was a tie of 2-3 references with just a few items each. State of Tennessee references are italicized.

Grade 2 Collection Systems Operator Need-To-Know Criteria (Subject Areas)

The following list of categories suggests topics of information which are important to know in order to be a successful and proficient Grade 1 Collection Systems Operator. The list may not be all inclusive, and knowledge of additional topics may be of benefit to the operator.

Category of Information: Process

- | | |
|---|--|
| <p>Gravity Sewers</p> <ul style="list-style-type: none"> • Describe • Operation/maintenance • Design/Construction <p>Pressure Sewers</p> <ul style="list-style-type: none"> • Describe • Operation/maintenance • Design/Construction <p>Vacuum Systems</p> <ul style="list-style-type: none"> • Describe • Operation/maintenance • Design/Construction <p>Sewer Equipment</p> <ul style="list-style-type: none"> • Application • Maintenance • Use/Procedure <p>Aeration</p> <ul style="list-style-type: none"> • Purpose • Describe types <p>Chemical Additives</p> <ul style="list-style-type: none"> • Purpose • Methods • Equipment <p>Chlorination</p> <ul style="list-style-type: none"> • Purpose • Methods • Equipment | <p>Corrosion Control</p> <ul style="list-style-type: none"> • Describe • Methods <p>Infiltration/Inflow Devices</p> <ul style="list-style-type: none"> • Describe • Methods of inspection and testing • Concept of sewer rehabilitation <p>Lift Stations</p> <ul style="list-style-type: none"> • Operation/maintenance • Design/Construction <p>Flow/Velocity Measurement</p> <ul style="list-style-type: none"> • Describe • Purpose • Flow regulators <p>Manholes</p> <ul style="list-style-type: none"> • Describe • Purpose • Design/Construction <p>Cross-Connection</p> <ul style="list-style-type: none"> • Definition • Types of devices |
|---|--|

Category of Information: Support Systems/Equipment

- | | |
|---|---|
| <p>Motors</p> <ul style="list-style-type: none"> • Single phase • Poly phase • Variable speed <p>Drives</p> <ul style="list-style-type: none"> • Coupled • Direct (Shaft; Gear) • Speed Reducer (Fixed; Variable) • Right angle <p>Blowers and Compressors</p> <ul style="list-style-type: none"> • Centrifugal • Positive displacement (Rotary; Piston) <p>Generators – AC & DC</p> <p>Engines – Gasoline, Diesel & Gas</p> <p>Hydrants (Basic)</p> | <p>Pumps</p> <ul style="list-style-type: none"> • Air Lift • Centrifugal • Positive displacement <ul style="list-style-type: none"> ○ Piston plunger ○ Progressive cavity ○ Diaphragm • Screw • Turbine • Metering • Ejector <p>Joints</p> <ul style="list-style-type: none"> • Flanged • Compression • Dresser • Victualic • Fused • Threaded |
|---|---|

Category of Information: Support Systems/Equipment (continued)

Valves

- Ball
- Check
- Globe
- Gate
- Plug
- Petcock
- Pressure control
- Vacuum relief
- Mud
- Butterfly
- Multiport
- Telescoping
- Sluice Gate
- Air release
- Foot
- Altitude

Pipes

- Types
- Cleaning/maintenance
- Sewer rehabilitation

Fittings

- Coupling
- Union
- Plug/Caps
- Corporation (Ferrell; Cock)
- Curb Stop
- Special

Odor Control

- Biofilters
- Chemical Additives
- Scrubbers

Rolling Stock

- Service vehicles
- Fork lifts
- Trucks
- Tractors
- Trailers
- Lawn Mowers
- Loaders
- Portable pumps
- Generators

Chemical Feeders

- Solids
- Liquids
- Slurry

Measuring and Control

- Signal generators
 - Kennison nozzle
 - Magnetic flowmeter
 - Parshall flume
 - Proportional weir
 - Rectangular weir
 - Venturi
 - Propeller meter
 - Ultrasonic
 - Pitot tube
- Signal transmitters
 - Electric
 - Pneumatic
 - Hydraulic
 - Mechanical
 - Telemetry
- Signal receivers
 - Counters
 - Indicators
 - Log Scale Indicators
 - Totalizers
 - Recorders
 - Combination recorders
- Meters
 - Hydraulic – Rotameters
 - Electrical – Amp
 - Electrical – Watt
 - Electrical – Watt Hour
 - Electrical – Multi
 - Electrical – Multi – VOM
 - Electrical – Megger
 - Mechanical – RPM
- Alarms
- Controls
 - Pneumatic
 - Float
 - Hydraulic
 - Electrical
 - Telemetry
 - Timers

Transformers

- Step down
- Step up

Safety Equipment

- Personal protection gear
- Traffic control (Warning devices; Barricades)
- Hazard detection
- First Aid/Hygiene

Category of Information: Laboratory

Materials testing

- Concrete
- Piping

Category of Information: General Information/Knowledge

Units of expression

- Define units
- Convert units

Sources and characteristics

- Characterizing sources
- Quality/quantity
- Identify characteristics
- Describe effects

Electrical

- Basic concepts
- Math calculations

Hydraulics

- Basic concepts
- Math calculations

Maps/plans

- Interpretation and use
- Describe types



Page 2

- This will be the first page you fill out

APPLICATION FOR CERTIFICATE OF COMPETENCY
Water and Wastewater Operator Certification Board

1. Mark either "Examination" or "Reciprocity" to indicate how you want your application considered. Reciprocity applicants should indicate state, license classification, and license number.

Application for Certification by: Exam Reciprocity (If reciprocity) State: _____ Class: _____ No. _____

Do you presently hold a water or wastewater certificate in the state of Tennessee? Yes No

2. Circle only 1 classification. A separate application must be submitted for each classification for which you are applying.

<p>Wastewater Classifications</p> <p>Biological Natural <input type="checkbox"/></p> <p>Wastewater Treatment 1 <input type="checkbox"/></p> <p>Wastewater Treatment 2 <input type="checkbox"/></p> <p>Wastewater Treatment 3 <input type="checkbox"/></p> <p>Wastewater Treatment 4 <input type="checkbox"/></p> <p>Collection Systems 1 <input type="checkbox"/></p> <p>Collection Systems 2 <input type="checkbox"/></p>	<p>Water Classifications</p> <p>Small Water System <input type="checkbox"/></p> <p>Water Treatment 1 <input type="checkbox"/></p> <p>Water Treatment 2 <input type="checkbox"/></p> <p>Water Treatment 3 <input type="checkbox"/></p> <p>Water Treatment 4 <input type="checkbox"/></p> <p>Distribution Systems 1 <input type="checkbox"/></p> <p>Distribution Systems 2 <input type="checkbox"/></p>	<p>For Board Use Only</p> <p>Education _____</p> <p>Months of Experience _____</p> <p>Work O.E. _____</p> <p>College O.E. _____</p> <p>Related O.E. _____</p> <p>TOTAL _____</p> <p>Recommendation _____</p> <p>Reviewer _____</p> <p>Date _____</p> <p>Date of Exam _____</p> <p>Comments _____</p>
---	--	---

3. Complete all of the following personal information. All correspondence concerning your application will be sent to the address entered below.

Last Name: _____ First Name: _____ MI: _____

Mailing Address: _____

City: _____ State: _____ Zip: _____

Work Phone: (____) _____ Home Phone: (____) _____

Social Security Number: _____ Birthdate: ____/____/____

Employment County: _____ Resident County: _____

Email Address: _____

Currently Employed At: _____

Tennessee Facility I.D. Number: PWSID# _____ NPDES# _____

I Am A United States Citizen: Yes No

Check the examination type: Electronic

CN-0704 (Rev 05-22) Page 2 of 8 RDA 2404

**APPLICATION FOR CERTIFICATE OF COMPETENCY
Water and Wastewater Operator Certification Board**

1. Mark either "Examination" or "Reciprocity" to indicate how you want your application considered. Reciprocity applicants should indicate state, license classification, and license number.

Application for Certification by: Exam Reciprocity (If reciprocity) State Class No.

Do you presently hold a water or wastewater certificate in the state of Tennessee? Yes No

2. Circle only 1 classification. A separate application must be submitted for each classification for which you are applying.

Wastewater Classifications	Water Classifications	For Board Use Only
<input type="checkbox"/> Biological Natural <input type="checkbox"/> Wastewater Treatment 1 <input type="checkbox"/> Wastewater Treatment 2 <input type="checkbox"/> Wastewater Treatment 3 <input type="checkbox"/> Wastewater Treatment 4 <input type="checkbox"/> Collection Systems 1 <input type="checkbox"/> Collection Systems 2	<input type="checkbox"/> Small Water System <input type="checkbox"/> Water Treatment 1 <input type="checkbox"/> Water Treatment 2 <input type="checkbox"/> Water Treatment 3 <input type="checkbox"/> Water Treatment 4 <input type="checkbox"/> Distribution Systems 1 <input type="checkbox"/> Distribution Systems 2	Education _____ Months of Experience _____ Work O.E. _____ College O.E. _____ Related O.E. _____ TOTAL _____ Recommendation _____ Reviewer _____ Date _____

Last Name: First Name: M/I:

➔ Mailing Address:

City: State: Zip:

Work Phone: () Home Phone: ()

➔ Social Security Number: Birthdate: / /

Employment County: Resident County:

➔ Email Address:

➔ Currently Employed At:

➔ Tennessee Facility I.D. Number: PWSID# NPDES#

➔ I Am A United States Citizen: Yes No

Check the examination type: Electronic

Height	_____
Weight	_____
Eye Color	_____
Sex	_____

Page 3

4. A copy of your high school diploma or GED certificate must be submitted with your application unless you have one on file or are having college transcripts submitted.

Are you a high school graduate? Yes No Date of graduation _____

If not, do you have a GED certificate? Yes No Date received GED _____

5. If a college degree is required for the classification for which you are applying or if college work is being claimed as credit for experience, transcripts must be submitted directly to the Board by the college or university. If you are only using your college transcript for proof of high school education, the transcript does not have to be mailed from the school.

Have you graduated from a college or university? Yes No

School _____ Year _____ Degree _____ Major _____

6. List courses and seminars which relate to water/wastewater operations. Proof of successful completion must be included, and course descriptions or catalogs should be attached.

School, Seminars, and Other Training in Water or Wastewater Operations		
Course	Provider	Length of course

Instructions for Completing Job Pages:

7. The following three pages are available for describing related job activities. Complete a job page for each related job. If you need additional pages, make copies of these pages and attach to this application. The information provided will be used to determine your qualifications to take the exam.

Begin with your present or most recent job. List NPDES or PWSID numbers for Tennessee facilities. For each facility that does not have a Tennessee I.D. number, request and complete a Supplement A/B Form.

On each job page are four checklist sections describing operating activities. Place a check mark beside each activity you performed while in that job. At the bottom of each section, list the total percent of time required to perform the activities checked. If the checklist does not adequately describe all of your duties and experience, use the blanks at the bottom of the page for additional information. The total percentage for any job page must not exceed 100%.

To reach your local
REGIONAL ENVIRONMENTAL FIELD OFFICE
Call 1-888-891-8332 OR 1-888-891-TDEC

- Please provide copies of the completion for each course listed
- 3 months of operating experience will be given for all WW, WT, DS, SWS, CS, BNS
- Up to 36 months of operating experience can be given for Grade 4 WT, WW only

5. If a college degree is required for the classification for which you are applying or if college work is being claimed as credit for experience, transcripts must be submitted directly to the Board by the college or university. If you are only using your college transcript for proof of high school education, the transcript does not have to be mailed from the school.

Have you graduated from a college or university? Yes No

School _____ Year _____ Degree _____ Major _____

6. List courses and seminars which relate to water/wastewater operations. Proof of successful completion must be included, and course descriptions or catalogs should be attached.

School, Seminars, and Other Training in Water or Wastewater Operations		
Course	Provider	Length of course

Page 4

Job A: (List most recent position.) (For instructions, see Number 7, page 3.)
(Do not show more than 100% for your TOTAL activities in this job.)

Employed: From To Title of Your Position:

Facility At Which Employed: Immediate Supervisor:

TN NPDES # or TN PWSID # Average Number Hours Worked Per Week:

Water Treatment Operations Section

The following activities are acceptable for water treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Operation & maintenance (O & M) of pretreatment systems	<input type="checkbox"/> Performance of laboratory control tests
<input type="checkbox"/> O & M of coagulant feed systems	<input type="checkbox"/> Interpret laboratory results and make adjustments to improve effluent quality
<input type="checkbox"/> O & M of filtration systems	<input type="checkbox"/> O & M of pumps and motors
<input type="checkbox"/> O & M of flocculent feed systems	<input type="checkbox"/> Plant & ground maintenance
<input type="checkbox"/> O & M of disinfection feed systems	
<input type="checkbox"/> O & M of hypochlorination and gas chlorination systems	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Distribution System Operations Section

The following activities are acceptable for water distribution system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Operation & maintenance (O & M) of pumps	<input type="checkbox"/> Pipeline installation
<input type="checkbox"/> O & M of booster station	<input type="checkbox"/> Installation of taps
<input type="checkbox"/> O & M of fire hydrants	<input type="checkbox"/> Leak detection
<input type="checkbox"/> O & M of valves	<input type="checkbox"/> Leak repairs
<input type="checkbox"/> O & M of storage tanks	<input type="checkbox"/> Meter reading
<input type="checkbox"/> Distribution system flushing	<input type="checkbox"/> Close Connection Control

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Wastewater Treatment Operations Section

The following activities are acceptable for wastewater treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Interpret process control data for plant operations	<input type="checkbox"/> Adjustment of wastewater levels or flow patterns through a lagson system
<input type="checkbox"/> Cleaning and maintenance of preliminary treatment, such as bar screens, grit chambers, comminutors, etc.	<input type="checkbox"/> Control of recirculation rates to trickling filters or rotating biological contactor (RBC)
<input type="checkbox"/> Control of sludge pumping	<input type="checkbox"/> Operation of chlorine feed rates for disinfection
<input type="checkbox"/> Control of return and waste sludge rates	<input type="checkbox"/> Operation of digester and/or solids conditioning processes
<input type="checkbox"/> Control of aeration rates	<input type="checkbox"/> Perform laboratory control tests
<input type="checkbox"/> Perform calculations and use them to operate and control plant	<input type="checkbox"/> Interpret lab results to improve effluent quality

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Collection System Operations Section

The following activities are acceptable for collection system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Operation & maintenance (O & M) of pumps	<input type="checkbox"/> Manhole maintenance and repairs
<input type="checkbox"/> O & M of lift stations	<input type="checkbox"/> Leak detection
<input type="checkbox"/> O & M of valves	<input type="checkbox"/> Line repair
<input type="checkbox"/> Line installation	<input type="checkbox"/> Line clearing
<input type="checkbox"/> Installation of service connections	<input type="checkbox"/> Work on L.V. crew
<input type="checkbox"/> O & M of lines and equipment	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

% Time	List any duties not covered in the sections above.

CN-0704 (Rev 05-22) Page 4 of 8 RDA 2404

- Make sure the dates are correct for each job page filled out
- NPDES # or PWSID # required
- Total time can only add up to 100%
- Fill out a separate form for each job

Job A: (List most recent position.) (For instructions, see Number 7, page 3.)
(Do not show more than 100% for your TOTAL activities in this job.)

Employed: From To Title of Your Position:

Facility At Which Employed: Immediate Supervisor:

TN NPDES # or TN PWSID # Average Number Hours Worked Per Week:

Water Treatment Operations Section

The following activities are acceptable for water treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input checked="" type="checkbox"/> Operation & maintenance (O & M) of pretreatment systems	<input type="checkbox"/> Performance of laboratory control tests
<input checked="" type="checkbox"/> O & M of coagulant feed systems	<input type="checkbox"/> Interpret laboratory results and make adjustments to improve effluent quality
<input checked="" type="checkbox"/> O & M of filtration systems	<input checked="" type="checkbox"/> O & M of pumps and motors
<input checked="" type="checkbox"/> O & M of flocculent feed systems	<input type="checkbox"/> Plant & ground maintenance
<input checked="" type="checkbox"/> O & M of disinfection feed systems	
<input checked="" type="checkbox"/> O & M of hypochlorination and gas chlorination systems	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES: **50%**

Distribution System Operations Section

The following activities are acceptable for water distribution system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input checked="" type="checkbox"/> Operation & maintenance (O & M) of pumps	<input checked="" type="checkbox"/> Pipeline installation
<input checked="" type="checkbox"/> O & M of booster station	<input checked="" type="checkbox"/> Installation of taps
<input checked="" type="checkbox"/> O & M of fire hydrants	<input checked="" type="checkbox"/> Leak detection
<input checked="" type="checkbox"/> O & M of valves	<input checked="" type="checkbox"/> Leak repairs
<input checked="" type="checkbox"/> O & M of storage tanks	<input checked="" type="checkbox"/> Meter reading
<input checked="" type="checkbox"/> Distribution system flushing	<input checked="" type="checkbox"/> Close Connection Control

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES: **50%**

Wastewater Treatment Operations Section

The following activities are acceptable for wastewater treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Interpret process control data for plant operations	<input type="checkbox"/> Adjustment of wastewater levels or flow patterns through a lagson system
<input type="checkbox"/> Cleaning and maintenance of preliminary treatment, such as bar screens, grit chambers, comminutors, etc.	<input type="checkbox"/> Control of recirculation rates to trickling filters or rotating biological contactor (RBC)
<input type="checkbox"/> Control of sludge pumping	<input type="checkbox"/> Operation of chlorine feed rates for disinfection
<input type="checkbox"/> Control of return and waste sludge rates	<input type="checkbox"/> Operation of digester and/or solids conditioning processes
<input type="checkbox"/> Control of aeration rates	<input type="checkbox"/> Perform laboratory control tests
<input type="checkbox"/> Perform calculations and use them to operate and control plant	<input type="checkbox"/> Interpret lab results to improve effluent quality

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Collection System Operations Section

The following activities are acceptable for collection system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Operation & maintenance (O & M) of pumps	<input type="checkbox"/> Manhole maintenance and repairs
<input type="checkbox"/> O & M of lift stations	<input type="checkbox"/> Leak detection
<input type="checkbox"/> O & M of valves	<input type="checkbox"/> Line repair
<input type="checkbox"/> Line installation	<input type="checkbox"/> Line clearing
<input type="checkbox"/> Installation of service connections	<input type="checkbox"/> Work on L.V. crew
<input type="checkbox"/> O & M of lines and equipment	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

% Time	List any duties not covered in the sections above.

Job A: (List most recent position.) (For instructions, see Number 7, page 3.)
(Do not show more than 100% for your TOTAL activities in this job.)

Employed: From To Title of Your Position:

Facility At Which Employed: Immediate Supervisor:

TN NPDES # or TN PWSID # Average Number Hours Worked Per Week:

Water Treatment Operations Section

The following activities are acceptable for water treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input checked="" type="checkbox"/> Operation & maintenance (O & M) of pretreatment systems	<input checked="" type="checkbox"/> Performance of laboratory control tests
<input checked="" type="checkbox"/> O & M of coagulant feed systems	<input checked="" type="checkbox"/> Interpret laboratory results and make adjustments to improve effluent quality
<input checked="" type="checkbox"/> O & M of filtration systems	<input checked="" type="checkbox"/> O & M of pumps and motors
<input checked="" type="checkbox"/> O & M of flocculent feed systems	<input checked="" type="checkbox"/> Plant & ground maintenance
<input checked="" type="checkbox"/> O & M of disinfection feed systems	
<input checked="" type="checkbox"/> O & M of hypochlorination and gas chlorination systems	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES: **100%**

Distribution System Operations Section

The following activities are acceptable for water distribution system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input checked="" type="checkbox"/> Operation & maintenance (O & M) of pumps	<input checked="" type="checkbox"/> Pipeline installation
<input checked="" type="checkbox"/> O & M of booster station	<input checked="" type="checkbox"/> Installation of taps
<input checked="" type="checkbox"/> O & M of fire hydrants	<input checked="" type="checkbox"/> Leak detection
<input checked="" type="checkbox"/> O & M of valves	<input checked="" type="checkbox"/> Leak repairs
<input checked="" type="checkbox"/> O & M of storage tanks	<input checked="" type="checkbox"/> Meter reading
<input checked="" type="checkbox"/> Distribution system flushing	<input checked="" type="checkbox"/> Close Connection Control

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Wastewater Treatment Operations Section

The following activities are acceptable for wastewater treatment plant operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Interpret process control data for plant operations	<input type="checkbox"/> Adjustment of wastewater levels or flow patterns through a lagson system
<input type="checkbox"/> Cleaning and maintenance of preliminary treatment, such as bar screens, grit chambers, comminutors, etc.	<input type="checkbox"/> Control of recirculation rates to trickling filters or rotating biological contactor (RBC)
<input type="checkbox"/> Control of sludge pumping	<input type="checkbox"/> Operation of chlorine feed rates for disinfection
<input type="checkbox"/> Control of return and waste sludge rates	<input type="checkbox"/> Operation of digester and/or solids conditioning processes
<input type="checkbox"/> Control of aeration rates	<input type="checkbox"/> Perform laboratory control tests
<input type="checkbox"/> Perform calculations and use them to operate and control plant	<input type="checkbox"/> Interpret lab results to improve effluent quality

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

Collection System Operations Section

The following activities are acceptable for collection system operating experience. Please place a check mark beside each activity which you perform. List the total percentage of time which you spend performing all of the activities which you checked.

<input type="checkbox"/> Operation & maintenance (O & M) of pumps	<input type="checkbox"/> Manhole maintenance and repairs
<input type="checkbox"/> O & M of lift stations	<input type="checkbox"/> Leak detection
<input type="checkbox"/> O & M of valves	<input type="checkbox"/> Line repair
<input type="checkbox"/> Line installation	<input type="checkbox"/> Line clearing
<input type="checkbox"/> Installation of service connections	<input type="checkbox"/> Work on L.V. crew
<input type="checkbox"/> O & M of lines and equipment	

TOTAL % TIME SPENT IN THE ABOVE CHECKED ACTIVITIES:

% Time	List any duties not covered in the sections above.

10

Exam Need to Know & References

Page 8

- Certified Operator signing **MUST** be equal to or higher than exam sitting for by applicant. Must include certification #.
- If none available, then fill out gray box.
- Please sign application

9. Verification of work experience must be documented by a certified operator of a similar or higher classification, familiar with the applicant's work experience. However, if no such person is available, experience may be documented by a person in authority with the system.

I hereby certify the information contained in the work experience section of this application is true and correct to the best of my knowledge. As specified in Tennessee Code Annotated Section 39-16-702(a)(4), this declaration is made under penalty of perjury.

I have observed this applicant for ___ years.

Name of Certified Operator documenting work experience: (Please Print)	Certification Number (s):
Signature of Certified Operator:	

Complete This Section Only If A Certified Operator Of Similar Or Higher Classification Is Not Available.

Printed name and signature of person in authority of the applicant's system documenting work experience: (if different than above)	System's Person in Authority Name and Position Title: (if different than above)
Name of facility/utility/system:	Telephone number: (include area code)
Address: (number and street)	
City:	State: Zip code:



10. Application must be signed and dated. By signing, applicant verifies that all information supplied on this application is correct to the best of his/her knowledge.

I certify under penalty of law that this document and all attachments were prepared by me, or under my direction or supervision. The submitted information is to the best of my knowledge and belief true, accurate, and complete; and that I am lawfully present in the United States as a U.S. citizen or a qualified alien as defined in 8 U.S.C. §1641(b). I am aware that there are significant penalties for submitting false information, including the possibility of fine and imprisonment. As specified in Tennessee Code Annotated Section 39-16-702(a)(4), this declaration is made under penalty of perjury.

Date of Application	Signature of applicant
---------------------	------------------------


Section 2

Wastewater Collection Systems Overview

Introduction to Collection Systems

Wastewater Collection Systems



Wastewater Collection Systems

- ▶ A wastewater collection system gathers the used water from homes and businesses and conveys it to a wastewater treatment facility
- ▶ The used water comes from kitchens and bathrooms or different processes of homes, businesses and industries
- ▶ Additional water can also enter the collection system from groundwater, surface water, and stormwater

Wastewater Collection Systems

- ▶ The system must be kept in good operating conditions because if it fails...
 - ▶ Blockages occur in the lines resulting in wastewater backups into homes and businesses
 - ▶ Raw wastewater can bypass the treatment facility resulting in contamination of surface waters and public health issues
 - ▶ Streets collapse – leaking sewer mains saturate the ground surrounding the pipe and eventually wash away the bedding materials leaving a void that can cause a collapse in the street above

Wastewater Collection Systems

- ▶ Proper operation and maintenance of the collection system is a way to protect the capital investment the community has made in the system so that it performs its intended function and be used efficiently throughout the planned life of the system
- ▶ This is achieved by trained collection system operators who use manual and power operated equipment to install, inspect, and repair the system to keep it running


Wastewater Collection Systems

*“The better collection systems operators are trained to do their jobs, the more effectively a wastewater treatment plant can do its intended job.”**

* Operation and Maintenance of Wastewater Collection Systems – Vol. I, 7th Edition

Introduction to Wastewater Treatment



Why do we treat waste?


Purpose of Wastewater Treatment

- ▶ To protect the environment and public health by:
 - ▶ Removing solids
 - ▶ Stabilizing organic matter
 - ▶ Removing pathogenic organisms

Disease causing


What is Pure Water



- ▶ Water is made up of two hydrogen atoms and one oxygen atom
- ▶ “Pure” water is manufactured in labs, even rain and distilled water contain other substances called impurities
- ▶ The majority of wastewater is just water; a much smaller portion are wastes


Waste Solids

- ▶ Total solids
- ▶ Dissolved solids
- ▶ Suspended solids
 - ▶ Settleable
 - ▶ Nonsettleable
- ▶ Floatable solids
- ▶ Organic and inorganic solids




Types of Waste


- ▶ **Organic waste**
 - Contains carbon
 - Will use up oxygen in water
 - More food = More bugs = More oxygen used
- ▶ **Inorganic waste**
 - Salts ◦ Gravel
 - Metals ◦ Sand



Sucrose



Salt



- ▶ Both may come from domestic or industrial waste
- ▶ Collection systems job is to get all solids to WWTP

Organic Waste

- ▶ Domestic wastewater contains a large amount of organic waste
- ▶ Industries also contribute some amounts of organic wastes
- ▶ Some of these organic industrial wastes come from vegetable and fruit packing, dairy processing, meat packing, tanning and processing of poultry, oil, paper and fiber





Importance of Organic Waste

- ▶ Organic material consumes oxygen in water
 - ▶ Bacteria will "feed" on organic matter and most need oxygen to be able to do this
 - ▶ We want these bacteria to "feed" on the organic matter and use it up in the treatment plant and not in our receiving water
- ▶ High concentrations of organic material can cause taste and odor problems in recreational and drinking water
- ▶ Some material may be hazardous


Oxygen Depletion

- ▶ When organic wastes are discharged to a receiving stream bacteria begin to feed on it, these bacteria need oxygen for this process
 - ▶ As more organic waste is added to the receiving stream, the bacteria reproduce
 - ▶ As the bacteria reproduce, they use up more oxygen, faster than it can be replenished by natural diffusion from the atmosphere
 - ▶ This can potentially cause a fish kill and odors
- ▶ Eutrophication
 - ▶ the gradual increase in the concentration of phosphorus, nitrogen, and other plant nutrients in an aquatic ecosystem




Oxygen Depletion

- ▶ Most living creatures, including fish, need oxygen to survive
- ▶ In water this oxygen is present as dissolved oxygen
 - ▶ Most fish can survive with at least 5 mg/L DO




Dissolved Oxygen

- ▶ There are two important factors that can influence the amount of dissolved oxygen present:
 - ▶ Water Temperature
 - ▶ Greater temperature ↑ Less DO ↓
 - ▶ Lower temperature ↓ More DO ↑
 - ▶ Organic matter
 - ▶ Organic material requires oxygen to decompose
 - ▶ More organic material requires more DO, and will tend to deplete water of DO




Oxygen Depletion




- ▶ One of the principal objectives of wastewater treatment is to prevent as much of this "oxygen-demanding" organic material as possible from entering the receiving water

Water Pollution

- ▶ Any condition caused by human activity that adversely affects the quality of stream, lake, ocean, or groundwater




NPDES Permit



- ▶ **National Pollutant Discharge Elimination System**
 - ▶ Required by the Federal Water Pollution Act Amendments of 1972 to help keep the nation's water suitable for swimming and for fish and other wildlife
 - ▶ Regulates discharges


Treatment



- ▶ The treatment plant removes the organic matter the same way a stream would in nature, but it works more efficiently by removing the wastes in secondary treatment
- ▶ The treatment plant is designed and operated to use natural organisms such as bacteria to stabilize and remove organic matter


Human Health

- ▶ Initial efforts for wastewater treatment came from preventing disease outbreaks
 - ▶ Most bacteria in wastewater are not harmful to humans
 - ▶ Humans who have a disease caused by bacteria or viruses can discharge some of these pathogens
 - ▶ Many serious outbreaks of communicable diseases have been traced back to contamination of drinking water or food from domestic wastewater
- ▶ **Good personal hygiene is your best defense against infections and disease**




Diseases


- ▶ **Bacteria**
 - ▶ Cholera
 - ▶ Dysentery
 - ▶ Shigella
 - ▶ Salmonella
 - ▶ Typhoid
- ▶ **Viruses**
 - ▶ Polio
 - ▶ Hepatitis (jaundice)
- ▶ **Protozoa**
 - ▶ Giardia lamblia
 - ▶ Cryptosporidium parvum




Cryptosporidium




Cholera




Giardia



Dysentery




Polio




Hepatitis

Wastewater Characteristics

- ▶ Fresh wastewater is usually a grey/dishwater color
 - ▶ Septic wastewater will typically have a black color
- ▶ Fresh domestic wastewater has a musty/earthy odor
 - ▶ If the wastewater is allowed to go septic, this will change significantly to a rotten egg odor associated with the production of hydrogen sulfide gas







Preliminary Treatment

- ▶ The main goal of preliminary treatment is to remove as many solids as possible from the wastewater stream
- ▶ This is accomplished by passing the wastewater through screens to filter out large solids and then slowing the water down to settle out smaller solids
- ▶ Solids are removed and treated as solid waste and not treated with the dissolved solids in the wastewater

Solids



- ▶ Cause many problems in collection and treatment plant systems
- ▶ Fill storage areas, clog ditches and channels
- ▶ Interfere with mechanical systems
- ▶ Associated with taste/color/clarity problems in drinking water

Preliminary Treatment

Solids Screening



- ▶ Variations: bar racks, mechanical rotating, rotary drum screen
- ▶ Must be cleaned regularly to prevent restriction of flow
- ▶ Failure to keep a bar screen clean can also result in a shock load
- ▶ Removes roots, rags, cans...

Preliminary Treatment

Solids Shredding

- ▶ Comminuter – device used to reduce the size of the solid materials in the wastewater by shredding
- ▶ Smaller solids can be settled out and cause less problems with pumps downstream
- ▶ Can help with clogging problems from rags and wipes
- ▶ Solids are not removed by a comminuter




Preliminary Treatment


Aerated Grit Chamber

- ▶ 1 ft/sec flow through grit chamber
- ▶ Used to remove grit – heavy, mainly inorganic solids (sand, egg shells, gravel, seeds, etc.)
- ▶ Aeration also freshens wastewater and helps remove floatables

Cyclone Grit Chamber


- ▶ Vortex forces heavier particles to sink



Primary Clarifier

- ▶ Goal of primary treatment is settle out more solids
- ▶ Velocity drops to < 1 fps
- ▶ Separates settleable and floatable solids
- ▶ Detention time ~ 1.5-2.0 hrs
- ▶ Raw water is gray



Secondary Treatment

- ▶ The main goal of secondary treatment is to remove organic waste from the wastewater stream
- ▶ This is accomplished biologically by allowing the waste to come into contact and be consumed by a population of microorganisms
- ▶ The reduction of waste from the microorganisms occurs in some type of biological reactor

Biological Constituents

- ▶ Many are human pathogens
- ▶ Most occupy a role in the treatment process
- ▶ They are:
 - ▶ Bacteria
 - ▶ Archaea
 - ▶ Fungi/yeast
 - ▶ Protozoa
 - ▶ Rotifers
 - ▶ Algae
 - ▶ Viruses

Amoeba ingesting alga

Rotifer

Paramecia conjugating

Stalked Ciliates

Biological Reactors


- ▶ There are different ways the “bugs” can come into contact with the waste
 - ▶ Fixed film reactors

Trickling Filter

Biological Reactors


- ▶ There are different ways the “bugs” can come into contact with the waste
 - ▶ Fixed film reactors

Rotating Biological Reactor “RBC”



Biological Reactors


- ▶ There are different ways the “bugs” can come into contact with the waste
 - ▶ Mixed reactors



Oxidation Ditch
Sequencing Batch Reactor “SBR”

Biological Reactors


- ▶ Secondary treatment requires a balance of organic waste and oxygen to maintain a healthy bug population for treatment





Fine bubble diffusers
Mechanical aeration

Biological Reactors

- ▶ A secondary clarifier is used settle out solids from the biological reactor to yield a treated effluent
- ▶ Solids are either returned to mixed reactors (RAS) or wasted from fixed film reactors



Secondary Clarifier



Disinfection

- ▶ Purpose is to kill pathogenic organisms still in wastewater
- ▶ Wastewater must contain 200 cfu/100mL for Fecal coliforms or 126 cfu/100mL for *E. coli* to be considered "disinfected"



Disinfection




Sodium Hypochlorite (liquid) Calcium Hypochlorite (solid)

Chlorine Ton Cylinder (gas)

Chlorine Contact Chamber

Ultraviolet System

Solids Treatment



Primary Treatment Secondary Treatment

Solids Treatment

- Digestion
- Dewatering
- Disposal

Solids Treatment




Gravity Thickener Belt Press Gravity Filter Bed

Anaerobic Digester Hauling Solids Away

Effluent Discharge

- ▶ Most wastewater is discharged to a receiving stream, river, lake or ocean.
- ▶ Some is reclaimed or reused on golf courses, cemeteries, parks, etc.



Cascade Aerator

Wastewater Collection Systems



Fleming Training Center TN Department of Environment & Conservation


Learning Objectives

Understanding different types of Systems

- ▶ Gravity Systems
- ▶ Small Diameter Gravity Systems (SDGS)
- ▶ Pressure Systems
 - ▶ Septic Tank Effluent Pump (STEP)
 - ▶ Grinder Pump
- ▶ Vacuum Systems


Wastewater

- ▶ Defined: water supply of a community or industry after it has been used
- ▶ Treatment: “onsite” or “offsite” (centralized)
- ▶ Offsite treatment requires a “collection and conveyance” system



Wastewater Collection and Conveyance System

Collection System Components




Manholes should be placed every 400-500 feet apart to provide access for inspections and cleaning

Minimum size is 4"

Constant minimum slope is required to provide a velocity of **at least 2 fps** to avoid solids depositing


Wastewater Collection and Conveyance System

- ▶ Manholes are installed in lateral, main, trunk, and intercepting sewers for the purpose of placing persons, equipment, and materials into these sewers for inspection, maintenance, and the removal of solids from cleaning operations
- ▶ Manholes must be installed:
 - ▶ At the ends of any line 8" in diameter or larger line
 - ▶ Changes in grade, size of pipe or alignment
 - ▶ At intersections
 - ▶ And not greater than 400 ft on a 15" diameter and smaller sewers or 500 ft on 18-30" sewers





Wastewater Collection and Conveyance System

- ▶ Horizontal Separation – sewers should be laid with at least 10 feet of horizontal clearance from any existing or proposed water line
 - 10'
- ▶ Vertical Separation – when sewers must cross a water line, they should be laid 18" below the bottom of the water line
 - 18"



Wastewater Collection and Conveyance System

- ▶ Hydrogen sulfide is made in the collection system and can:
 - ▶ Make waste more difficult to treat
 - ▶ Damage concrete structures
 - ▶ Cause odor problems
- ▶ Biological activity in long, flat sewer lines will likely cause:
 - ▶ Hydrogen sulfide production
 - ▶ Oxygen deficiency in sewers, manholes or wet wells
 - ▶ Metal and concrete corrosion
- ▶ Chlorine can be used in the collection system or at the plant headworks to oxidize hydrogen sulfide

Oil and Grease

- ▶ Generally listed under one heading called FOG (fats, oils and greases) as it is often not important to know the exact make-up of this group of components.



Sewer Blockage Formation


- The start of a blocked pipe begins when grease and solids collect on the top and sides of the pipe interior.
- The build-up increases over time when grease and other debris are washed down the drain.
- Excessive accumulation will restrict the flow of wastewater and can result in a sanitary sewer overflow.

O & M of Collection Systems

- ▶ The facilities should be kept in good operating condition
- ▶ What happens when collection systems fail due to lack of or improper operation and maintenance?
 - ▶ SSO – Sanitary Sewer Overflow
 - ▶ Blockages occurring in the sewer line that result in backups into homes, businesses and other customer facilities
 - ▶ Bypassing raw wastewater
 - ▶ Street collapse



Building Service Lateral




- ▶ Connects internal plumbing to street sewer
- ▶ Usually homeowner is responsible
- ▶ Cleanout minimum 3 ft from foundation
- ▶ Typically 4 inch diameter
- ▶ Slope 1/4 inch per foot minimum, 2%

Typical dwelling served by a main sewer in the street


Conventional Gravity Sewer

- ▶ Uses natural slope of land to flow by gravity
- ▶ Manholes every 400-500 ft
 - ▶ State requirement: manhole at distance ≤ 400 ft for sewers 15 inches or less and 500 ft for sewers 18 to 30 inches
- ▶ Pump or lift station




Conventional Gravity Sewer

- ▶ Scouring velocity- 2 ft/sec
 - ▶ Flow < 2 ft/sec may lead to settling out of solids, stoppages, production of odors including toxic hydrogen sulfide, corrosive conditions
- ▶ Sewer not less than 2 1/2 ft deep



Gravity Collection Sewer



Gravity Collection Sewer


- ▶ **Building sewer** – a gravity-flow pipeline connecting a building wastewater collection system to a lateral or branch sewer
 - ▶ The building sewer may begin at the outside of the building's foundation wall or some distance (2-10 ft) from the wall, depending on local sewer ordinances
 - ▶ Also called house connection or service connection
- ▶ **Lateral sewer** – a sewer that discharges into a branch or other sewer and has no other common sewer tributary to it
 - ▶ Sometimes called a "street sewer" because it collects wastewater from individual homes

Gravity Collection Sewer

- ▶ **Branch sewer** – a sewer that receives wastewater from a relatively small area and discharges into a main sewer serving more than one branch sewer area
- ▶ **Main sewer** – a sewer line that receives wastewater from many tributary branches and sewer lines and serves as an outlet for a large tributary or is used to feed an intercepting sewer
- ▶ **Trunk sewer** – a sewer that receives wastewater from many tributary branches or sewers and serves a large territory and contributing population
- ▶ **Intercepting sewer** – a sewer that receives a flow from a number of other large sewers or outlets and conducts the waters to a point for treatment or disposal


Sewer Manhole

- ▶ Place people, equipment and materials into sewer for inspection, maintenance and cleaning
- ▶ May not have steps since hazardous if corroded
- ▶ **Minimum barrel diameter 48 inches**
- ▶ Inspected annually
- ▶ Reinforced concrete, brick, fiberglass




Inverted Siphon

- ▶ Sewer lines installed lower than the normal gradient of the sewer line to pass under obstructions such as watercourses and depressed roadways
- ▶ Wastewater is pushed through the siphon by the pressure resulting from the upstream sewer being higher than the downstream sewer




Air Jumper

- ▶ Air jumpers are sometimes constructed as part of an inverted siphon
- ▶ Since the siphon is completely filled with wastewater, a blockage in the flow of air in the sewer line occurs without an air jumper
- ▶ This blockage may cause a continuous release of toxic, odorous and corrosive hydrogen sulfide at the upstream siphon manhole
- ▶ Installation of jumpers prevents this from happening by providing the downstream flow of air that usually occurs above the wastewater in a partially filled sewer line



Small Diameter Gravity Sewer (SDGS)

- ▶ Alternative wastewater collection system installed in areas where deep excavation is a concern, and in areas that are hilly or flat
- ▶ SDGS uses a smaller diameter pipe than conventional gravity sewers due to less solids
- ▶ Follows the surface contour of the land, reducing the amount of excavation and construction costs
- ▶ Septic tanks onsite discharge to small diameter gravity main
- ▶ Discharges effluent by gravity, pump or siphon
- ▶ **Minimum velocity 0.5 ft/sec**



Interceptor Tank

- ▶ Septic tank
- ▶ Removes floating and settleable solids
- ▶ Levels out flows
- ▶ Sludge solids decompose anaerobically
- ▶ Regular inspection to measure liquid level, depth of sludge & thickness of scum
- ▶ NO tank additive works

Precast concrete, fiberglass, HDPE or coated steel common.

Septic Tank Effluent Pump (STEP) Lift Station

- ▶ Simple reinforced concrete or fiberglass wet well after septic tank
- ▶ Submersible pump operated by mercury float switches
- ▶ Also on gravity mains to allow gravity flow at shallow depth

STEP System

S – Septic
T – Tank
E – Effluent
P – Pump

STEP System


- ▶ Septic tank effluent pump with filter
- ▶ Float activated mercury switch controls pump
- ▶ Keep OUT: eggshells, plastic, bones, grease

Vent & Air Release Valve

- ▶ Vent maintains flow in SDGS main
- ▶ Air release valve vents air at high points in main that would restrict flow
- ▶ Gases vented from main are often quite odorous, use activated carbon filter, soil bed as a masking agent


Pressure Sewers

- Reasons:
 - Topography: Flat terrain or high slope
 - Rocky soil
 - High groundwater table




Pressure Sewer Components

- 4" gravity building sewer at 2% slope
- Holding tank
- Grinder pump & controls
- Valves to isolate system
- Pressure main




Grinder Pump System

- Submersible centrifugal pump with comminuting blade cuts and shreds solids in wastewater
- Pump unit acts to pressurize WW to move it through sewer
- WW flows from pump vault to pressurized main via a pressurized service line
- Grinder pump serving a home is usually 1-2 hp



Progressive Cavity Grinder Pump

- Creates pressure that moves WW through sewer
- Reduces size of solids
- Pump, motor, grinder, pipes, valves, controls
- Pressure sensor measures liquid level



Progressive Cavity Grinder Pump

- Check & gate valve on discharge prevent backflow
- Excavation not deep: 5-8 ft
- Uses small diameter pressure lines
- Odors associated with improper venting
- Maintenance: solids lodged in cutting blade
- Disadvantage: FOG is transported




Pressure Sewer vs. Gravity Sewer

- Higher energy costs for pumping
- Greater costs for pumping facilities
- Deep trenches not necessary
- Inverted siphons not needed to cross roads and rivers
- Smaller pipes often needed
- Fewer stoppages (system pressurized)
- No I&I – no extra capacity needed
 - No root intrusion, air tight system

Automatic Air Release Assembly

- ▶ Located in high point of pressure sewer
- ▶ Release air pockets that would reduce flow capacity




Pressure Sewer Cleaning

- ▶ Must have access for maintenance
- ▶ Manholes or access boxes must have valves and pipe spools that can be removed for cleaning the pipe
- ▶ Polyurethane pigs and swabs are slightly larger or the same size as the main to be cleaned
- ▶ Piggig typically done during low flow periods




Piggig Port

- ▶ Installed to insert pig to clean inside sewer
- ▶ The poly pig is forced through the pipe under pressure
- ▶ Replaces manhole needed in gravity sewer
- ▶ Radio beacon device allows operator to track pig location




Vacuum Sewer Layout

- ▶ Applications: flat or rolling terrain, unstable soil, high water table, rocky terrain, urban development in rural areas
- ▶ 3 Components:
 - ▶ On-site valve pit
 - ▶ Vacuum collection piping
 - ▶ Central vacuum station




Vacuum Sewer Components

- ▶ **Gravity building sewer** to vacuum interface unit
- ▶ **Vacuum interface unit** seals vacuum service
 - ▶ Once 3 gal WW accumulate, valve opens to allow atmospheric air to force WW into vacuum branch
- ▶ **Vacuum main** sends WW to treatment facility
- ▶ Minimum slope vacuum main is 0.2 ft/sec



Fiberglass Valve Pit with External Breather

- ▶ WW flows by gravity (1) into 30 gal holding tank
- ▶ As WW level rises, air is compressed in sensor tube connected to valve controller (2)
- ▶ Sensor signals valve to open until tank contents are evacuated (3)
- ▶ The spring-loaded interface valve (4) is controlled pneumatically and needs no electricity
- ▶ External breather is a 1 1/4 inch polyurethane pipe anchored in ground by concrete
- ▶ Breather pipe must be watertight and has domed cover to keep insects out




Vacuum Sewer – How Does It Work?




Isolation Valve

- ▶ Plug or gate valves isolate portions of vacuum sewer for repairs and maintenance
- ▶ Typical interval is 1500 to 2000 ft
- ▶ Also located at both sides of a bridge crossing and at both sides of an area of unstable soil




Typical Vacuum Station

- ▶ Steel or fiberglass collection tank (1) acts like wet well. Vacuum switches on reservoir tank (2) regulate vacuum pumps (3). Level control probes in collection tank regulate the VVW pumps (4).
- ▶ Daily operating tasks:
 - ▶ Visual check of gages and charts
 - ▶ Record pump run times
 - ▶ Check oil & block temperature



Typical Vacuum Station

- ▶ 1 station serves 200-300 customers
- ▶ Vacuum pumps operate 3-5 hrs/day
- ▶ Pumps are typically 20 hp



Vacuum Sewer Advantages

- ▶ Small pipe sizes, typically 3, 4, 6, 8 and 10 in
- ▶ Easy to avoid underground obstacles
- ▶ Shallow installation (2 to 4 ft) eliminates need for wide deep trenches reducing excavation costs and environmental impact
- ▶ High scouring velocity reduces blockages and keeps wastewater aerated and mixed
- ▶ No infiltration - leaks easily noted
 - ▶ Reduced infiltration leads to reduced size and cost of treatment plant
- ▶ No manholes
- ▶ Only power source at vacuum station

Vacuum Sewer O & M

- ▶ No odor problems
 - ▶ System is sealed; large air input with flow
- ▶ No corrosion problems
 - ▶ Corrosion resistant PVC, ABS, rubber, stainless steel
- ▶ Malfunctions:
 - ▶ Break in vacuum line
 - ▶ Valve malfunction
 - ▶ Closed isolation valve
- ▶ O&M of vacuum systems are more difficult than a low-pressure system because it is harder to maintain a vacuum due to the number of inlets and valves to the system

Collection Systems Vocabulary

_____ 1. Alignment	_____ 10. Infiltration
_____ 2. Barrel	_____ 11. Inflow
_____ 3. Bedding	_____ 12. Lift Station
_____ 4. Building Sewer	_____ 13. Manhole
_____ 5. Check Valve	_____ 14. Pneumatic Ejector
_____ 6. Combined Sewer	_____ 15. Sanitary Sewer
_____ 7. Exfiltration	_____ 16. Slope
_____ 8. Force Main	_____ 17. Storm Sewer
_____ 9. Grit	_____ 18. Weir

- A. A special valve with a hinged disc or flap that opens in the direction of normal flow and is forced shut when flows attempt to go in the reverse or opposite direction of normal flows.
- B. An opening in a sewer provided for the purpose of permitting operators or equipment to enter or leave a sewer. Sometimes called an "access hole" or "maintenance hole."
- C. The heavy mineral material present in wastewater such as sand, coffee grounds, eggshells, gravel and cinders. This tends to settle out at flow velocities below 2 ft/sec and accumulate in the invert or bottoms of the pipelines.
- D. (1) The cylindrical part of a pipe that may have a bell on one end. (2) The cylindrical part of a manhole between the cone at the top and the shelf at the bottom.
- E. A pipe or conduit (sewer) intended to carry wastewater or waterborne wastes from homes, businesses and industries to the POTW (Publicly Owned Treatment Works). Storm water runoff or unpolluted water should be collected and transported in a separate system of pipes or conduits (storm sewers) to natural watercourses.
- F. A sewer designed to carry both sanitary wastewaters and storm or surface water runoff.
- G. A separate pipe, conduit or open channel (sewer) that carries runoff from storms, surface drainage and street wash, but does not include domestic and industrial wastes. They are often the recipients of hazardous or toxic substances due to the illegal dumping of hazardous wastes or spills created by accidents involving vehicles and trains transporting these substances.
- H. A gravity-flow pipeline connecting a building wastewater collection system to a lateral or branch sewer. The pipeline may begin at the outside of the building's foundation wall or some distance (such as 2 to 10 feet) from the wall, depending on local sewer ordinances.
- I. A device for raising wastewater, sludge or other liquid by compressed air. The liquid is alternately admitted through an inward-swinging check valve into the bottom of an airtight pot. When the pot is filled, compressed air is applied to the top of the liquid. The compressed air forces the inlet valve closed and forces the liquid in the pot through an outward-swinging check valve, thus emptying the pot.

- J. The seepage of groundwater into a sewer system, including service connections. Seepage frequently occurs through defective or cracked pipes, pipe joints, connections or manhole walls.
- K. The prepared base or bottom of a trench or excavation where a pipe or other underground structure is supported.
- L. A wastewater pumping station that lifts the wastewater to a higher elevation when continuing the sewer at reasonable slopes would involve excessive depths of trench. Also, an installation of pumps that raise wastewater from areas too low to drain into available sewers. These situations may be equipped with air-operated ejectors or centrifugal pumps. Sometimes called a pump station, but this term is usually reserved for a similar type of facility that is discharging into a long force main, while this has a discharge line or force main only up to the downstream gravity sewer.
- M. A pipe that carries wastewater under pressure from the discharge side of a pump to a point of gravity flow downstream.
- N. The inclination of a sewer trench excavation is the ratio of the vertical distance to the horizontal distance or "rise over run."
- O. The proper positioning of parts in a system. This refers to the location and direction of a pipeline or other line.
- P. Water discharged into a sewer system and service connections from such sources as, but not limited to, roof leaders, cellars, yard and area drains, foundation drains, cooling water discharges, drains from springs and swampy area, around manhole covers or through holes in the covers, cross connections from storm and combined sewer systems, catch basins, storm waters, surface runoff, street wash waters or drainage. This differs from infiltration in that it is a direct discharge into the sewer rather than a leak in the sewer itself.
- Q. Liquid wastes and liquid-carried wastes that unintentionally leak out of a sewer pipe system and into the environment.
- R. A wall or plate placed in an open channel and used to measure the flow of water. The depth of the flow over this can be used to calculate the flow rate, or a chart or conversion table may be used to convert depth to flow.

Collection Systems Questions

1. What is the purpose of a wastewater collection system?

9. The amount of wastewater that a collection system conveys is determined by quantities of:
 - a. Commercial wastewaters
 - b. Domestic wastewaters
 - c. Groundwater infiltration
 - d. Sludge produced by wastewater treatment plant
 - e. Surface water inflow

10. Construction materials for sewers are selected for their:
 - a. Ability to minimize infiltration and exfiltration
 - b. Cost of materials
 - c. Cost of installation
 - d. Resistance to deterioration
 - e. Resistance to root intrusion

Answers to Vocabulary and Questions

Vocabulary:


- | | | |
|------|-------|-------|
| 1. O | 7. Q | 13. B |
| 2. D | 8. M | 14. I |
| 3. k | 9. C | 15. E |
| 4. H | 10. J | 16. N |
| 5. A | 11. P | 17. G |
| 6. F | 12. L | 18. R |

Questions:

1. The purpose of a wastewater collection system is to collect the wastewater from a community's homes and industries and convey it at an appropriate velocity to a wastewater treatment plant.
2. The principal components of a low-pressure collection system include gravity sewers, holding tanks, grinder pumps and pressure mains.
3. The principal components of a vacuum collection system include gravity sewers, holding tanks, vacuum valves, vacuum mains and vacuum pumps.
4. Backflow preventers are used to stop the accidental backflow or reverse flow of wastewater into buildings from the sewer.
5. The width of a sewer trench is controlled by the diameter of the sewer pipe, clearance for pipe laying, soil stability for safety during excavation and the excavation procedures.
6. Poor sewer pipe joints can lead to problems caused by roots, infiltration & exfiltration.
7. a
8. a
9. a, b, c and e
10. All are correct

Section 3


Flow Measurement



Wastewater Flows and Flow Monitoring


What are the Wastewater Flows?

- Sanitary Sewer:
 - Domestic and industrial waste
- Storm water:
 - Snow melt, street wash, etc.
- Combined sewer:
 - Sanitary plus storm
 - Example: Nashville
- Infiltration/Inflow





1/1

- Inflow – Water discharged into a sewer system and service connections from such sources as, but not limited to, roof leaders, cellars, yard and area drains, foundation drains, cooling water discharges, drains from springs and swampy areas, around manhole covers or through holes in the covers, cross connections from storm and combined sewer systems, catch basins, storm waters, surface runoff, street wash waters or drainage
 - Inflow differs from infiltration in that it is a direct discharge into a sewer rather than a leak in the sewer itself



1/1

- Infiltration – the seepage of groundwater into a sewer system, including service connections.
 - Seepage frequently occurs through defective or cracked pipes, pipe joints, connections or manhole walls
 - Due to age and condition of system and portion of system submerged in groundwater
- Exfiltration – liquid wastes and liquid-carried wastes that unintentionally leak out of a sewer pipe system and into the environment





Wastewater flows: Why do we care?

- Collection and conveyance system design
 - Are they getting shorter or longer as the years go on?
 - Getting longer and further away from the treatment plant means the water spends more time in the system, which also means water easily becomes septic
- Treatment system design
 - Hydraulic criteria: must be able to pass peak flows
 - Treatment criteria: meeting treatment standards often depends on "hydraulic residence time"
 - e.g. MG / MGD = days = residence time
 - Growth projections (population, development)

Wastewater flow rates

- The average flow rate generated per person (per capita) per day is called the population equivalent
 - Typical units are gallons per capita per day (GPCD)
 - Typically estimated as 70% of the drinking water consumption during the wet season
 - Used as a quick way to estimate the amount of wastewater that could be generated by a community
- Rule of thumb:
 - US domestic is about 70-100 gpd/person
 - Developing countries: 5 to 50 gpd/capita
 - Other: depends on facility (industry, commercial, etc.)
 - I/I can be significant




Factors Effecting Flow Rates

- Geographical location & socioeconomic conditions
- Type of development – residential, industrial
- Season (I/I)
- Climate (I/I)
- Time of Day



"Diurnal variations" in domestic wastewater flows



Flow Monitoring



Flow Monitoring

- Flow monitoring may be categorized as:
 - Long-term
 - Temporary
 - Instantaneous

Long-Term Flow Monitoring

- The purpose of long-term monitoring is to adequately define I/I quantities
- Should be in place for one groundwater season – 60-120 days
- Typically located off the larger diameter trunk lines for greater accuracy and for ease of calibration

Temporary Flow Monitoring


- The purpose of temporary monitoring is to gather additional data to further refine the identification of portions of the system needing additional study
- Should be in place for 30 days on a system ranging up to 5000 linear feet
- Established at the mini-system level within a metered subarea

Instantaneous Flow Monitoring

- The purpose of instantaneous monitoring is to isolate line segments with excessive infiltration, once identified the sections are scheduled for internal inspection
- Typically conducted at night on three to five consecutive line segments

Flow Measurement

- Basics of Flow Measurement
- Open Channel Flow Measurement
 - Primary Elements
 - Secondary Elements
- Closed Pipe Flow Measurement
 - Differential Pressure
 - Mechanical Devices
- Flow Equalization



Basics of Flow Measurement

- Flow - The movement of a fluid
 - The science of hydraulics is the basis for flow measurement today. Most methods of open channel flow measurement are no more than sophisticated adaptations of level measurement practiced over the last four millennia
- Most flow data can be classified according to:
 - Accuracy
 - Time
 - Quantity

Basics of Flow Measurement

- Accuracy - the degree to which an instrument can measure a true value
- Accurate flow measurement generally depends upon:
 - Standard Designs
 - Careful selection of devices
 - Good calibration data and analysis
 - Proper user operation
 - Sufficient inspection and maintenance
 - Good training and supervision

Basics of Flow Measurement


- **TIME** - flow information is generally useful only when there is a time relationship established
 - This relationship may include:
 - The time interval
 - The time duration
 - The actual clock time
 - Relationships with other parameters can be derived using the correlated time-flow data
 - The degree of accuracy necessary varies depending on the requirement

Basics of Flow Measurement

- **QUANTITY** - the amount or volume of liquid moving past a fixed point
 - A liquid at rest (not flowing) is measured only in units of volume
 - Volume units describe how much space a given amount of water occupies, such as gallons or liters
 - Water that is flowing must be measured in terms of both volume and time, such as gallons per minute
 - Flowrate is therefore the amount of liquid that passes a point in a known period of time

Flow is ...

- Amount of water going past a reference point over a certain time
- Units: volume per unit time
 - (ft³/sec, gal/min, MGD)
- Calculated by the equation: $Q = AV$




Q = quantity of flow

A = cross-sectional area of flow

V = velocity of flow

Sewer System Evaluations

- Flow monitoring is primary tool for identifying high inflow/infiltration (I/I)
- System problems:
 - Back flooding into private property due to surcharging of sewer mains
 - Bypassing of untreated wastewater to environment
 - Reduced system capacity



Flow Metering Equipment Commonly Used in Wastewater Treatment Plants

Type	Accuracy	Advantages	Disadvantages
Open-Channel Flume	5-7%	Low headloss, self-cleaning	Requires careful construction, susceptible to flooding
Open-Channel Weir	5-7%	Low cost, ease of installation	High headloss, requires a well-developed flow profile, cleaning required
Full-Pipe Electromagnetic	1-3%	No headloss, bi-directional	Minimum conductivity required, expensive, well-developed velocity profile required
Full-Pipe Doppler	2-5%	No headloss, low cost, not affected by air bubbles	Not suitable for some pipe material, well-developed velocity profile required
Full-Pipe Venturi	1-3%	Low headloss, high accuracy	Expensive, well-developed velocity profile required

MOP No. 11 – Operation of Municipal Wastewater Treatment Plants

Types of Flow Meters


- Different types of flow measuring devices include constant differential, head area, velocity meter, differential head and displacement
- All flow measurement devices should be calibrated and maintained to ensure the accuracy of the measurement is $\pm 10\%$ of the true flow
- Methods that can be used to check the performance of a flow meter are:
 - Measure the area and velocity of an open channel
 - Measure how many minutes it takes to fill a 55-gallon drum
 - Measure how long it takes to fill a tank of a known volume


Flow Measurement Systems

- Any flow measurement system can be considered to consist of two distinct parts:
 - a **primary device** and
 - a **secondary device**
- Each device has a separate function to perform:
 - The flow passes through the primary device in a continuous, uninterrupted stream
 - The secondary device uses that information to determine the quantity of flow per unit time

Open Channel Flow Primary Elements

- Creates conditions that produce known relationship between flow and depth
- Channel width is known, but velocity is not needed
- Primary devices:
 - Weirs
 - Flumes
- Secondary element senses depth at measurement point, converting this to flow
- A detailed discussion of different types of weir and flume configurations used in North America is presented in the *Isco Open Channel Flow Measurement Handbook*





Teledyne Isco Open Channel Flow Measurement Handbook
8th Edition


GET YOUR OWN HERE:
<https://info.teledyneisco.com/flowhandbook>

Open Channel Flow

- Measurement of wastewater flow in open channels is the most frequently encountered situation in field monitoring
- Three elements must be present for open channel flow to occur:
 1. free, unconstrained water surface
 2. an open vent to atmosphere
 3. unimpeded, gravity flow
- The free water surface in an open channel flow stream is known as the hydraulic grade line (HGL)


Weir


- Overflow structure; rectangular or V-notch
- Discharge rate determined by measuring vertical distance from crest of overflow to surface of upstream pool
- Disadvantage: Organic solids collect behind weir, causing odors & inaccurate measurements
- Measures liquid flow in partially full channels or basins
- Blocks the flow in the channel
- Depth of water proportional to amount of flow



Weir

- Used in open channels and is placed across the channel, weirs are made of thin materials and may have either a rectangle or V-notch opening.
- The flow over the weir is determined by the depth of flow going through the opening.
- A disadvantage in using a weir at the influent of the plant is that solids may settle upstream of the weir and cause odors and unsightliness.
- Can provide final aeration/oxygenation





Weir

<p>Advantages</p> <ul style="list-style-type: none"> ➤ Low cost ➤ Easy to install 	<p>Disadvantages</p> <ul style="list-style-type: none"> ➤ High head loss ➤ Periodic cleaning ➤ Not suitable to flows with solids ➤ Accuracy affected by excessive approach velocities
--	--

Flume

- Entrance, Throat, Discharge
- Depth is measured behind flume crest
- Best for:
 - Flow with solids or debris
 - Large Flows
 - Variable flows



FLUME

Flumes

- Specially shaped open channel section with entrance, throat & discharge sections
- Constriction causes change in head which can be converted to flow rates
- Used where head loss is a concern, for larger flows or flows with solids or debris

Influent / Effluent Parshall Flume (9" throat)

Palmer-Bowlus flumes
measures flow in existing sewers





Palmer-Bowlus Flume

- commonly used to measure the flow of wastewater in sewer pipes and conduits
- has a u-shaped cross-section and was designed to be inserted into, or in line with, pipes and u-channels found in sanitary sewer applications

Flumes

Advantages	Disadvantages
<ul style="list-style-type: none"> ➤ Self cleaning ➤ Lower head loss ➤ Accuracy less affected by approach velocity 	<ul style="list-style-type: none"> ➤ High cost ➤ Difficult to install

Open Channel Flow Secondary Elements

- Measures or indicates liquid level in primary device
- Used with instruments to convert head to flow
- Selection based on location, type of information required & cost
- **Staff gauge** in stilling well
- **Floats** in stilling well
- **Bubblers**
- **Ultrasonic devices**

Secondary Elements

- Measure the water level in the Primary Device (weir or flume)
- Example 1 – Float
 - Simple, Inexpensive
 - Grease, solids may interfere

Secondary Elements

- Types of float controls
 - Rod-attached floats
 - Steel tape, cable or rope attached floats
 - Mercury switch floats
 - Ultrasonic
 - Pressure transducers


Level/Depth Measurement

- Level measurement techniques must be used with secondary devices to determine flowrate.
- Staff gages and float-operated units are the simplest devices used for this purpose.
- The selection of a suitable level measuring technology depends on a variety of factors which include the size of the channel, flow properties of the channel and composition/physical properties of the effluent
- In some instances, a flowmeter may be used in a wide variety of applications and sites

Level/Depth Measurement

Three most common technologies utilized are:

1. Ultrasonic/Radar - the sensor transmits high frequency pulses which hit the surface of the liquid and return to the sensor. The electronics measure the time it takes the sound to return
2. Pressure Transducer - water pressure is sensed by mechanical elements in the sensor which converts the pressure to a voltage
3. Bubbler - A constant flow of bubbles are continuously pushed through a small tube in the flow stream and the backpressure changes in proportion to the liquid level in the flow stream



Secondary Elements

- Ultrasonic Meter
 - Sound pulse
 - No direct contact with wastewater
 - Limit – Cannot measure less than 3 inches





Fig. 8.1.9 - Ultrasonic sound is used to measure liquid level and convert the level reading to a flow measurement

Ultrasonic Meter




Secondary Elements

- Pressure transducer
 - Converts water pressure to voltage
 - Not affected by wind, steam, foam or turbulence



CS15 Non-Clogging Submersible Pressure Transducer


Pressure Transducer



Secondary Elements

➤ Bubbler Tube

- Constant flow of air
- Depth determined by air pressure
- Generally operate at 5 psi, the depth of the water in the wet well will determine the pressure required.



Bubbler Tube




Area-Velocity Method

- Area-Velocity metering systems continuously measure V and A to calculate Q (subsurface or non-contact)



Area-Velocity Meter



Closed Channel Flow

- Closed channel flow is the movement of a liquid under pressure through a conduit or pipe with or without the influence of gravity. When there is a pressure or head difference in a pipeline, flow will occur in the direction of least resistance
- The rate of flow depends upon several factors:
 - The pressure or head difference between upstream and downstream
 - Flow resistance, or friction, due to pipe length, pipe roughness, bends, restrictions
 - Changes in conduit shape and size, and the nature of the flowing fluid
 - Cross-sectional area of the pipe


Closed Pipe Flow Measurement

- Differential Producers
 - Venturi meter
 - Orifice plate
- Velocity Meters
 - Propeller-type
 - Pitot tube
 - Magnetic meter
- Constant Differential
 - Rotameter

Closed Pipe Flow Measurement: Differential Producers


➤ **Venturi system**

- Pipe diameter gradually reduces at the throat and returns to original diameter
- Low pressure is created in throat
- Difference in pressure indicates amount of flow
- Simple and inexpensive
- Need straight runs of pipe before and after
- Excellent for gases and liquids (not sludge)




Closed Pipe Flow Measurement: Differential Producers

- Measure velocity directly or convert velocity head to pressure head by restricting flow in pipe
- Gases & liquids in closed pipes



Venturi meter: liquid passes through reduced throat section & velocity increases. Pressure differential then measured using **manometer**.


Differential Pressure Flow Measurement




Closed Pipe Flow Measurement: Velocity Meters

➤ **Magnetic Flow Meter**

- Creates magnetic field in water stream
- Conductor (water) moving through magnetic field produces electric current
- Measure of electricity indicates amount of flow
- Very accurate, Low maintenance
- Can be expensive (esp. for larger diameters)




Electromagnetic Flow Measurement



Closed Pipe Flow Measurement: Velocity Meters


➤ **Velocity Meter**

- Measures the ultrasonic transit time



Closed Pipe Flow Measurement: Constant Differential

- Chemical Feed Systems
- Rotameter
 - Float or ball in vertical tube
 - Increased flow causes float to ride higher
 - Simple, accurate, easy
 - Must keep tube and float clean



Rotameter

Rotameter Working Explanation with 3D Animation



Maintenance of Flow Measuring Devices

- Clean devices regularly
 - Grease build up on floats & magnetic meter coils
 - Weir plate clogged with debris
- Periodically inspect devices for damage & deterioration
 - Pneumatic lines may have air leaks
 - Electrical parts may short out
- Recalibrate secondary devices regularly

Flow Equalization

- Equalization may be required where peak flows are greater than 2 times the average design flow
- Care should be taken in design to minimize solids deposition
- Minimum requirements are to maintain 1.0 mg/l of dissolved oxygen
- Odor consideration must be addressed when a plant is located in a sensitive area or large equalization basins are used

Flow Measurement Vocabulary

1. Analog	9. Orifice
2. Composite	10. Primary Element
3. Conductivity	11. Secondary Element
4. Density	12. Sensor
5. Digital Readout	13. Surcharge
6. Head	14. Totalizer
7. Head Loss	15. Venturi Meter
8. Manometer	

- A. An opening (hole) in a plate, wall or partition. An orifice flange or plate placed in a pipe consists of a slot or a calibrated circular hole smaller than the pipe diameter. The difference in pressure in the pipe above and at the orifice may be used to determine the flow in the pipe.
- B. A measure of the ability of a solution (water) to carry an electric current.
- C. The secondary measuring device or Flowmeter used with a primary measuring device (element) to measure the rate of liquid flow. In open channels bubblers and floats are secondary elements. Different pressure measuring devices are the secondary elements in pipes or pressure conduits.
- D. The readout of an instrument by a pointer (or other indicating means) against a dial or scale. Also the continuously variable signal type sent to an analog instrument.
- E. An indirect measure of loss of energy or pressure. Flowing water will lose some of its energy when it passes through a pipe, bar screen, Comminutor, filter or other obstruction. This is measured as the difference in elevation between the upstream water surface and the downstream water surface and may be expressed in feet or meters. Flow measuring devices like venturi tubes and orifice plates use it.
- F. The supply of water to be carried is greater than the capacity of the pipes to carry the flow. The surface of the wastewater in manholes rises above the top of the sewer pipe, and the sewer is under pressure or a head, rather than at atmospheric pressure.
- G. The vertical distance (in feet) equal to the pressure (in psi) at a specific point. The pressure head is equal to the pressure in psi times 2.31 ft/psi.
- H. A measure of how heavy a substance (solid, liquid or gas) is for its size. It is expressed in terms of weight per unit volume, which is grams per cubic centimeter or pounds per cubic foot. The density of water (at 4° C or 39° F) is 1.0 gram per cubic centimeter or about 62.4 pounds per cubic foot.
- I. A device or meter that continuously measures and calculates a process rate variable in cumulative fashion.
- J. An instrument for measuring pressure. Usually it is a glass tube filled with a liquid that is used to measure the difference in pressure across a flow-measuring device such as an orifice or a Venturi meter.
- K. A collection of individual samples obtained at regular intervals, usually every one or two hours during a 24-hour time span. Each individual sample is combined with the

Section 4

Pipe Materials



Sewer Pipe Materials

Selection Considerations

- Pipe material selection is important since sewer systems are expected to have an economical life of at least 30 years and most are in service for a much longer period
- Pipe materials are selected for their strength to withstand earth and surface loads and resistance to deterioration by the wastewaters they carry and the surrounding soil

Selection Considerations

- Other considerations include:
 - Pressure – gravity or force main
 - Physical properties – crush strength, shear loading strength, flexural strength
 - Flow and capacity
 - Resistance to root intrusion
 - Trench conditions
 - Corrosion resistance – both from wastewater and surrounding soil
 - Abrasive wastewater
 - Safety requirements for handling and installation
 - Cost

Specification Standards



- Set by American Society of Testing Materials (ASTM) & American National Standards Institute (ANSI)
- Specify:
 - Internal diameter
 - Loadings (classes)
 - Wall thickness (schedule)

Key Pipe Characteristics

- Pipe must be resistant to corrosion from wastewater and surrounding soil
- Leak tightness: resistance to root intrusion and minimize infiltration and exfiltration
- Scouring factor
- Hydraulic characteristics


Key Pipe Characteristics

- Tensile strength – resistance to longitudinal (lengthwise) pull before material fails
- Flexural strength – ability of pipe material to bend or flex without breaking
- When either of these strengths are exceeded then pipe breakage occurs





Key Pipe Characteristics

- Shear breakage occurs when the earth shifts



- Beam breakage occurs when a pipe is unevenly supported along its length




Key Pipe Characteristics

- Pipe material used will produce either a flexible or rigid pipe with specific characteristics
- A flexible pipe will bend or bulge from its usual shape when subjected to a load without being adequately supported, but will not crack under most loads and will return nearly to its original shape when the load is removed

Pipe Materials

- Flexible Pipe
 - Ductile Iron Pipe (DIP)
 - Steel Pipe
 - Thermoplastic Pipe
 - Acrylonitrile Butadiene Styrene (ABS)
 - Acrylonitrile Butadiene Styrene Composite Pipe
 - Polyethylene Pipe (PE)
 - Polyvinyl Chloride Pipe (PVC)
 - Thermoset Plastic Pipe
 - Reinforced Thermosetting Resin (RTR)
 - Reinforced Plastic Mortar (RPM)


Ductile Iron Pipe (DIP)



- Flexible pipe
- Used for both gravity and pressure sewers
- DIP is manufactured by adding cerium or magnesium to cast (gray) iron just prior to the pipe casting process
- 3-54 inch diameters and length of 20 ft available
- Often used for stream crossings, inverted siphons and in high traffic area.
- Polyethylene, epoxy or cement mortar linings may be specified


Ductile Iron Pipe

<ul style="list-style-type: none"> ➤ Advantages <ul style="list-style-type: none"> ➤ Long laying lengths (in some situations) ➤ High pressure and load bearing capacity ➤ High impact strength ➤ High beam strength 	<ul style="list-style-type: none"> ➤ Disadvantages <ul style="list-style-type: none"> ➤ Subject to corrosion where acids are present ➤ Subject to chemical attack in corrosive soils ➤ High weight ➤ Expensive
---	--



Steel Pipe

- Flexible pipe
- Rarely used for gravity sewers but common for force mains
- Usually has interior protective coatings or linings (polymeric, bituminous, asbestos)
- 8-120 inch diameters with lengths up to 40 feet



Steel Pipe

Advantages

- Light weight
- Long laying lengths (in some situations)



Disadvantages

- Subject to corrosion where acids are present
- Subject to chemical attack in corrosive soils
- Subject to excessive deflection when improperly bedded
- Subject to turbulence abrasion

Thermoplastic Pipe

- Includes a wide variety of plastics that can be repeatedly softened by heating and hardened by cooling through a temperature range characteristic for each specific plastic

- ABS
- ABS Composite
- HDPE
- PVC



Acrylonitrile Butadiene Styrene

- Lightweight black plastic flexible pipe
- Used for both gravity and pressure sewers
- Long laying lengths
- Ease in field cutting
- Rather brittle: subject to environmental stress cracking
- Subject to attack by some organic chemicals
- Susceptible to damage by sunlight
- Elastomeric seal gasket joints or solvent cemented joints

Acrylonitrile Butadiene Styrene Composite

- Flexible pipe
- Produced by extrusion of ABS plastic material to create two concentric thermoplastic tubes integrally braced with truss beams and the annular space filled with Portland cement concrete
- Used for both gravity & pressure sewers
- Light weight and long laying lengths
- Ease in field cutting
- Subject to environmental stress cracking or attach by certain organic chemicals
- Susceptible to damage by sunlight

HDPE Pipe

- High Density Polyethylene
- Flexible pipe
- Inert - not subject to chemical attack
- Resists corrosion from hydrogen sulfide
- Easily handled
- Longer laying length vs. heavier pipe
 - Gives long-term maintenance advantage of fewer joints and fewer root intrusions
- Nonporous
 - Although groundwater may infiltrate through poorly made joints or taps, but it won't seep through the walls
- Commonly used with pipe bursting & sliplining




Polyvinyl Chloride (PVC)

- Most widely used plastic pipe
- Flexible pipe
- Non-porous
- Inert - not subject to chemical attack
- Easily handled, lighter weight vs rigid pipe
- Longer laying length vs. heavier pipe (10-20 ft)
- Subject to excessive deflection when improperly bedded



Polyvinyl Chloride (PVC)

- Needs to be protected from freezing temperatures and sunlight until installed
- Least susceptible to corrosion by acids formed from gases generated in sewers



Thermoset Plastic Pipe

- Include a broad variety of plastics that, after having been cured by heat or other means, are substantially infusible and insoluble

- Flexible pipe
- Two categories:
 - Reinforced Thermosetting Resin
 - Reinforced Plastic Mortar



Thermoset Plastic Pipe

- Reinforced Thermosetting Resin pipe contains fibrous reinforcement materials, such as fiberglass, imbedded in or surrounded by cured thermosetting resin
- Reinforced Plastic Mortar pipe contains fibrous reinforcements such as fiberglass and aggregates such as sand embedded in or surrounded by cured thermosetting resin

Thermoset Plastic Pipe

- | | |
|---|--|
| <ul style="list-style-type: none"> ➤ Advantages <ul style="list-style-type: none"> ➤ Light weight ➤ Long laying lengths | <ul style="list-style-type: none"> ➤ Disadvantages <ul style="list-style-type: none"> ➤ Subject to strain corrosion in some environments ➤ Subject to attack by certain organic chemicals ➤ Subject to excessive deflection when improperly bedded ➤ Subject to surface change from long-term ultraviolet exposure |
|---|--|



Key Pipe Characteristics

- A rigid pipe will require less support, however it will crack when the combination of a load on the pipe and its support causes a stress that exceeds the strength of the pipe
- Rigid pipe will not return to its original shape when the load is removed



Pipe Materials

- Rigid Pipe
 - Asbestos-Cement Pipe (ACP)
 - Cast-Iron Pipe (CIP)
 - Concrete Pipe
 - Reinforced Concrete Pipe (RCP)
 - Prestressed Concrete Pressure Pipe (PCPP)
 - Vitrified Clay Pipe (VCP)

Asbestos-Cement Pipe (ACP)

- Rigid pipe
- No longer manufactured
- It was used frequently for gravity and pressure sewers from 4 - 42 in
- Still found in many sanitary sewer systems throughout the US



Asbestos-Cement Pipe

- | | |
|--|---|
| <ul style="list-style-type: none"> ➤ Advantages <ul style="list-style-type: none"> ➤ Long laying lengths ➤ Availability of a wide range of strength classifications ➤ Availability of a wide range of fittings ➤ Resistant to abrasion | <ul style="list-style-type: none"> ➤ Disadvantages <ul style="list-style-type: none"> ➤ Subject to corrosion where acids are present ➤ Subject to shear and beam breakage when improperly bedded ➤ Low beam strength ➤ Restrictions by OSHA due to asbestos content (precautions need to be taken when repairing AC pipe) |
|--|---|

Cast-Iron Pipe (CIP)

- Rigid pipe
- CIP (gray iron) is used for both gravity and pressure sewers in diameters from 2 – 48 inches
- A cement mortar lining with an asphaltic seal coating may be specified on the interior of the pipe for protection from corrosion
- Very resistant to crushing and is often used for creek and river crossings, shallow trench locations, and under heavy traffic load areas



Cast-Iron Pipe

- | | |
|---|---|
| <ul style="list-style-type: none"> ➤ Advantages <ul style="list-style-type: none"> ➤ Long laying lengths (in some situations) ➤ High pressure and load bearing capacity | <ul style="list-style-type: none"> ➤ Disadvantages <ul style="list-style-type: none"> ➤ Subject to corrosion where acids are present ➤ Subject to chemical attack in corrosive soils ➤ Subject to shear and beam breakage when improperly bedded ➤ High weight ➤ High cost |
|---|---|

Concrete Pipe


- Rigid pipe
- Reinforced (RCP) and non-reinforced concrete pipe are used for gravity sanitary sewers
- Reinforced concrete pressure pipe and prestressed concrete pressure pipe (PCPP) are used for pressure as well as gravity flow sanitary sewers
- Rigid; heavy
- Rubber gasket joints



Concrete Pipe

- Prestressed pipe is reinforced with wire strands under tension to give the pipe an active resistance to loads or pressures on it






Concrete Pipe

<p>➤ Advantages</p> <ul style="list-style-type: none"> ➤ Wide range of structural and pressure strengths ➤ Wide range of nominal diameters <ul style="list-style-type: none"> ➤ Non-reinforced – 4-36 inches ➤ Reinforced - 12-200 inches ➤ Wide range of laying lengths – 4-24 feet 	<p>➤ Disadvantages</p> <ul style="list-style-type: none"> ➤ High weight ➤ Subject to corrosion where acids are present (if not coated) ➤ Subject to shear and beam breakage when improperly bedded ➤ Special field repair methods and special fittings may be required for PCPP
--	---

Vitrified Clay Pipe

- Rigid pipe
- Used for gravity sewers with laying lengths of 4-10 ft
- Manufactured from clay and shales
- Made non-porous (vitrified) by heating it at a high enough temperature to fuse the clay mineral particles
- 3-36 inch diameters are available, up to 42 in some areas
- Compression jointed
- Brittle: requires careful installation (shear & beam breakage possible)
- Heat resistant




Vitrified Clay Pipe

<p>➤ Advantages</p> <ul style="list-style-type: none"> ➤ High resistance to chemical corrosion ➤ High resistance to abrasion ➤ Wide range of fittings available 	<p>➤ Disadvantages</p> <ul style="list-style-type: none"> ➤ Joints susceptible to chemical attack ➤ Limited range of sizes available ➤ High weight ➤ Subject to shear and beam breakage when improperly bedded
--	--

Pipe Joints


- One of the most critical components of the sewer piping system are the pipe joints
- Joints must be effective to control groundwater infiltration, wastewater exfiltration, and root intrusion which leads to increased damage to the system
- An effective pipe joint must be:
 - Watertight
 - Root resistant
 - Flexible
 - Durable



Pipe Joints

- There are many types of gasket (elastomeric seal) pipe joints that provide a reliable, tight seal against leakage
- Gasketed pipe joints create a seal through the compression of an elastomeric seal or ring
- Two main types of gasket-type pipe joints
 - Push-on
 - Mechanical compression


Pipe Joints



- Push-on pipe joints use a continuous elastomeric ring gasket, which is compressed into the annular space formed by the pipe, fitting, or coupler socket and the spigot end of the pipe (Bell and spigot)
 - Gasket provides a positive seal when the pipe spigot is pushed into the socket
 - When this type of joint is used in pressure sewers, thrust restraint may be required to prevent joint separation


Pipe Joints

- The annular space is the ring-shaped space located between two circular objects
 - Examples: bell and spigot joints, pipe liner and the inside of the pipe



Pipe Joints

- Mechanical compression pipe joints use a continuous elastomeric ring gasket, which provides a positive seal when the gasket is compressed by means of a mechanical device
 - Flanged pipe joints
 - Push-on bell and spigot mechanical joint with gland-type follower




Mechanical Pipe Joints



Pipe Joints

- Solvent cement pipe joints involves bonding a sewer pipe spigot into a bell or coupler using a solvent cement
 - Can be used on thermoplastic pipe – ABS, ABS composite, and PVC
 - Safety precautions should be taken to ensure adequate trench ventilation for operators



Pipe Joints


- PVC pipe that is schedule 80 and heavier wall thicknesses may be threaded
 - Threading not recommended for polyethylene (PE) and polybutylene (PB)
- For PE and PB heat fusion pipe joints are commonly used
 - Involves butt fusion of the pipe lengths
 - Ends of two lengths of pipe are trimmed and softened to a melted state with heated metal plates then forced together to the point of butt fusion
 - Provides a positive seal that does not require thrust restraint in pressure applications

Pipe Joints – Butt Fusion



Pipe Joints

- Welded joints are typically found on steel pipe used for force mains and are very strong and leak tight
- Elastomeric sealing compound pipe joints can be used on concrete pipe that has been sandblasted and primed to provide a positive seal
- Mastic pipe joints are used for non-round shapes of concrete gravity sewer pipe which are not adaptable to gasket joints





Concrete Pipe Joints





Pipe Joints - Couplings

- Couplings can be used to join plain pipe ends and can consist of gaskets, solvent cement or welded ends
- Rubber couplings with compression bands can also be applied to join plain pipe ends

Pipe Joints - Couplings



➤ Dresser couplings consist of a cylindrical middle ring, two follower rings, two resilient gaskets made up of a special Dresser compound and a set of steel track head bolts

Pipe Joints - Couplings

➤ The middle ring of the Dresser coupling is placed over the ends of pipe to be connected and the follower rings compress the beveled gasket to achieve a durable seal and a flexible joint

➤ Gaskets absorb vibrations and pipe movement and allow for moderate deflection





Unrestrained Mechanical Couplings



Pipe Joints - Couplings


- Victaulic (groove and shoulder) couplings join ends of a pipe that each have a machined groove that receives the sides of a trough-shaped metal housing in which there is a similarly shaped rubber gasket



Pipe Joints - Couplings

- The housing encases the gasket and engages the groove providing a leak-tight seal in a self-restrained joint

- Not designed for use with plastic pipe
- Disadvantage: grooves weaken the pipe wall



Victaulic Coupling



Section 5
Pipe Installation



Pipe Installation and Maintenance

Pipe Shipping and Unloading

- Can be shipped via truck, railroad or barge
- Pipes must be handled carefully to prevent damage when it is loaded, transported, and unloaded
- Pipe should be inspected upon arrival and again before installation
- Handle carefully
- Inspect lining and coating

Pipe Shipping and Unloading

- Plastic pipe must be inspected closely if arriving in cold weather
- Always use the proper equipment to unload



Stacking Pipe

- If pipe is to be stacked and stored - ensure it is stored off the ground
- Secure pipe to prevent rolling
- Secure the storage area
- Protect plastic pipe from sunlight - but allow air circulation



Stringing Pipe

- Lay pipe as near to the trench as possible to minimize handling
- String pipe on side opposite of spoil pile
- Place bells in direction of installation
- Secure each section to prevent rolling into trench
- String only enough for one days work to prevent vandalism
- May need to cover ends to keep dirt out and prevent contamination

Construction Equipment

- Backhoes
 - Most common equipment used for trench excavations with vertical or sloped sides
 - Cable sling can be added for lowering pipe into trenches
 - Can be used to excavate through rocky and unstable soils




Construction Equipment

- Backhoes
 - Wheeled backhoes – easy to maneuver, can be used as a loader
 - Tracked excavators – used to install heavy pipe, place pipe bedding, and move shoring and other heavy items





Construction Equipment

- Mini-excavators – smaller, rubber-tired or tracked, used for shallow and restricted excavations
- Front-end loaders – used to place bedding and backfill material and to load excess material into dump trucks for hauling away from the site




IMPORTANT:
 ONLY TRAINED PROFESSIONAL
 OPERATORS SHOULD OPERATE
 HEAVY EQUIPMENT




Construction Equipment

- Skid steer loader – small, equipped with lift arms that can be outfitted with buckets or other tools
- Bulldozers – continuous-tracked, with metal blades that move soil, excavated material
- Hydro-excavators – chassis-mounted, combined high pressure water and air vacuum systems used to cut through and break up soil, and to lift slurry from the excavation area


Excavation

- Plans are prepared by project engineer and submitted for State approval
- Plans should show location and depth of line, manholes, etc.
- Plans should show location and depth of water and gas pipes, buried telephone lines, electric and cable lines
- Ensure selection of proper sized excavation equipment



Excavation

- Water and Sewer lines separation at least 18 inches between the bottom of the water main and top of the sewer line
- Sewers should be at least 10 feet horizontally from any water line
- Notify the public about the work




Trenching

- Most expensive part of pipe installation
- Minimize width and depth as much as possible without compromising safety
- Width should be no more than 1-2 feet more than pipe diameter, wider around curves
- Trench depth depends on maximum depth of frost penetration, minimum of 2.5 feet
- Minimum distance from trench to spoil pile is 2 feet

Trenching

- Must have an egress if 4 feet or deeper - stairway, ladders, etc
- Trench must be shored or sloped at 5 feet or deeper
- If 20 feet or deeper must be designed by an engineer
- Left open as short a time as possible
- Mark with barricades, warning tape, lights, etc to prevent accidents



Pipe Laying Procedures

- Inspect before laying and placing in trench
- Check for damage to the spigot end and lining
- Keep gaskets clean and dry




FIG. 19

Pipe Laying Procedures

- Use a sling or pipe tong to place into trench- never roll
- Cover pipe with plug at the end of each workday
- Ensure pipe bedding is level and compacted
- Compact the backfill beneath the pipe curvature (Haunching)




FIG. 21

Pipe Joints


- Ensure gasket and spigot clean before being attached
- Bell holes or recesses in bedding dug to allow for joint installation
- Spigot end must be inserted to the painted line
- Full-length pipes are beveled at end to facilitate connection
- Level pipe for cutting
- Insert pipe straight

Thrust Restraints In Pipe Installation

- Water under pressure and water in motion exerts tremendous pressure inside a pipeline and is highest when water flow changes direction
- All tees and bends should be restrained or blocked
- A thrust block prevents the separation of joints and pipe movement by transferring the resultant thrust force at a bend to the undisturbed soil behind the block

Thrust Restraints In Pipe Installation


- Thrust blocks are made of concrete or other permanent material
- Cast in place between fittings and undisturbed soil in the trench



LOCATION OF THRUST


Thrust Restraints In Pipe Installation

- Thrust anchors can be used when there is no undisturbed solid to block against
- Tie rods are used to restrain mechanical joint fittings
- Steel rods hold the pipe and are attached to a block of concrete
- Restraining fittings use clamps and anchor screws



Purpose Of Backfilling

- Provide for pipe and fitting support
- Provides lateral stability between pipe and trench walls
- Carries and transfers surface loads




Placing Backfill

- Only clean sand or selected soil should be used for first layer
- Moist enough for compaction
- Should not contain peat, rocks, debris or frozen material



Placing Backfill

- First layer placed equally on both sides of pipe, up to center, and compacted
- Do by hand or pneumatic tamper
- Second layer should be good quality backfill material
- Remaining backfill can be excavated spoils



NOTES:

1. EMBEDMENT MATERIAL MUST BE CLASS I (NO. 67 OR NO. 78M WASHED STONE IS TYPICALLY USED).
2. EMBEDMENT MATERIAL SHALL BE COMPACTED TO A MINIMUM 95% STANDARD PROCTOR DENSITY FOR CLASS I MATERIAL.
3. STANDARD BEDDING SHALL BE UTILIZED FOR ALL CASES WHERE TRENCH BOTTOMS ARE UNSTABLE DUE TO SOIL TYPE, OR MOISTURE CONDITIONS.
4. ALL SANITARY SEWER LINES LESS THAN 3 FEET AND OVER 20 FEET IN DEPTH MUST BE D.I.P.



BEDDING FOR FLEXIBLE & SEMI-RIGID SANITARY SEWER PIPE

DETAIL NO.
07000.13
SHEET 1 OF 1

Compacting

- Trench backfill should be well compacted to avoid later settling
- Water compaction: jetting trench backfill with water
 - Not suitable for all soil types
 - Wide variation in results
 - Backfill must dry out before restoration or paving

Compacting

- Mechanical compaction: hand-held air tampers, plate vibrators, vibrating rollers
- Excessive impact can damage pipe
- Maintenance of shoring during compaction in lifts




Testing

- Air testing (air compressor):
 - Test sewer pipes at air pressure of 3-5 psi above any outside water pressure on pipe
 - Air test pressure too high can blow out pipe joints or plugs, can injure personnel, or damage system
 - Better in steep terrain because of excessive water pressure at lower end of sewer pipe

Low Pressure Air Testing

- Leak test accomplished by stringing the sewer line.
- Then, a winch cable pulls in 2 plugs which are attached with an interconnecting hose, through in 20 ft intervals.
- Air is fed between plugs until test fails.
- Leak is isolated by moving the plugs back and forth.



Low Pressure Air Testing




Water Testing


- Water exfiltration test indicates new sewer's ability to convey wastewater without excessive leakage & to resist groundwater infiltration
- Infiltration test: groundwater entering pipe is monitored through use of weir.
- Can't determine location of leak.

Mandrel Testing

- After placing and compacting trench backfill, but before site restoration, all new installation of flexible pipe should be tested with a mandrel to measure for deflection and offset joints



Mandrel Testing




- The mandrel is a rigid, cylindrical plug with nine arms that is tapered at both ends and fitted with pulling rings to which pulling and tag lines are attached
 - Mandrel diameter is 95% of the average diameter of the pipe
 - Pulling and tag lines are marked so that the distance the mandrel has been pulled into the sewer can be determined

Mandrel Testing

- As the mandrel is pulled through the new section of pipe it will not pass through if:
 1. A flexible pipe has deflected beyond 5% of its diameter
 2. A rigid pipe has been crushed
 3. A joint is offset more than 5% of the pipe diameter
 4. A building sewer connection is protruding into the main line



Mandrel Testing



Site Restoration



- Restored to original condition as soon as possible
- Grass restored, curbs replaced, pavement repaired
- Check drainage ditches for debris which would facilitate flooding
- Private property must be returned to original condition


Section 6
Lift Stations



Wastewater Lift Stations

Objectives


- Purpose
- Types
- Components
- Operation
- Safety
- Maintenance



White House UD Pumping Station


Purpose of Lift Stations

- Lift or raise wastewater or storm water from a lower to a higher elevation




Location

- Excavation costs to keep gravity flow become excessive
- Poor soil stability
 - If soil is too unstable for trenching, pump station may be necessary.
- Groundwater table too high to install deep sewers
- Present flow insufficient to justify extension of large trunk sewers




Screw Pumps

- Screw carries wastewater up to discharge point
- Handle large solids & rags without clogging
- Screw supported by 2 bearings-must lubricate
- Daily inspection: bent flights, unusual noises, general operation




Screw Pumps

- Archimedes screw pumps at Memphis STP
- Each is 8 feet in diameter and can lift 19,900 gpm (28.6 MGD)
- May be covered to control flies, odors and spread of wastewater in air




Pneumatic Ejector

- Uses compressed air to eject wastewater
- Handles low flows with low to medium heads with large solids
- Maintenance: clean grease from tank; inspect valves, air lines, & electrical controls
- During routine maintenance, observe several cycles of the ejector




Installations

- Wet well/dry well vs. submersible pump station




Submersible Pump Station

- Pump is in wet well
- Low flows & higher heads (pumping against a large change in elevation)




Submersible Pumping Station

- Pump-motor unit, electrical & mechanical controls, piping, wet well, access frame & cover
- Guide bars of 2" pipe allow removal of pump from top of the manhole
- Check & isolation valves & flow meter installed in separate valve pit
- Operator does not have to enter the wet well to remove or install the pump




Duplex Submersible Pumping Station

- Two pumps (duplex)
- Completely submerged in WW
- Waterproof motor
- Second pump provides continuous operation if 1 pump fails or needs repairs.
- When mechanical seal starts leaking, WW can enter the motor and cause motor to burn out
- Mechanical seals keep wastewater out
 - Check motor with megger monthly
 - Replace mechanical seals regularly
 - Clean grit out of wet well regularly




Submersible Lift Stations

- Submersible lift stations are designed to blend readily with natural surroundings, since there is no pump house and there is a minimum of above-ground equipment
- Other advantages to below-ground installations are noise reductions and less safety-hazard concerns
- This submersible wastewater pump is being lowered into a lift station on a guide rail system
- All that is needed is a hoist; there is no need for a person to go into the pit
- By using a guide rail system, pump maintenance and installation is easier because the piping system does not need to be disconnected



Wet Well/Dry Well

- Dry well houses pumps, motors, electrical controls, & auxiliary equipment
- Typically for higher flows because has higher initial cost
- Equipment in wet well is minimized




Direct Inline Pumping (DIP) System

- Special impeller design that reverses direction when clogging is sensed
- One check valve and small footprint
- No wet well




Centrifugal Pumps

- Most common wastewater lift station pump
- Impeller: rotating vanes pump wastewater; large opening prevent clogging
- Volute: spiral-shaped casing collects water discharged by impeller



Horizontally Mounted Centrifugal Pump




Pump Operation

- Frequent starts & stops:
 - Cause excessive motor wear
 - Cause surges in wastewater flow
 - Increase power costs
- Draw more power starting than during normal operation because motor & pump have to start turning

Gate Valves

- Needed in lift station to permit proper flow of wastewater and permit maintenance to occur
- Immediately before & after pump to isolate it from wet well & force main
- Operate inactive valves to prevent sticking
- Always "back off" half turn when fully opening or closing to avoid "freezing"




Gate Valves

- More susceptible to plugging than plug valves
- Better than plug valves:
 - Some can be slammed shut by backflow, breaking the valve body & injuring operator from water hammer due to sudden stoppage of flowing water
 - Plug valves have a restriction which can become clogged with rags & sticks




Check Valve




- Installed in discharge of each pump to prevent the force main from drawing back into the wet well.
- Swinging check valve has valve body with clapper arm that open when pump comes on & closes when pump shuts off.
- Must close before flow reverses to prevent water hammer

Auxiliary Equipment

- Screens & comminutors installed prior to pumps to prevent large debris from entering & plugging pipes
 - Protects pumps downstream
- Ventilation system with sensors & alarms
- Lights sufficient in number & right location to avoid glare & shadows




Manually Cleaned Bar Screen/Rack





- Bar screens or racks collect leaves, sticks, cans, and trash.
- Must be cleaned frequently so flow to the pumps is not restricted.
- Screenings can cause odors and attract rats and flies.
- Screening disposal in landfill.
- Safety
 - Be careful not to trip or fall into the wastewater.
 - Back injuries and muscle strains can occur when pulling heavy water-logged debris.

Mechanically Cleaned Bar Screen

- In larger installations, mechanically cleaned bar screens are installed.
- To reduce wear, controls clean the screen only when debris has accumulated, and head loss reaches a preset level.
- Maintenance:
 - Keep well lubricated and adjusted
 - Hose down with water to prevent slime growth and odors/flies it generates



Comminutor



- Shreds solids, but leaves them in the wastewater
- Safety: never attempt to unjam cutter blades without first bypassing unit, turning off power, locking out breaker & placing tag on breaker
- Advantages vs. bar screens: eliminates screening disposal; eliminates problems from flies and odors
- Disadvantages: plastic and wood may be rejected and must be removed manually

Comminutor – Muffin Monster




Channel Monsters protect your system

Level Controllers


- Float controllers:
 - Grease & debris can hinder movement
 - Float attachment line breakage
 - May develop leaks
 - Sensitive to level changes




Float Operation




Float Operation



Float Operation




Float Operation




Level Controllers

- Air bubblers:
 - Constant low volume, low pressure air fed through vertically mounted pipe in wet well
 - Water level determined by force required to displace water in the pipe





Level Controllers

- Pressure transducer:
 - Submerged
 - Pressure created by static head of water level sensed by flexible membrane.
 - Converted to electrical signal in control system.
 - Rags & debris foul unit
 - Grease may cover unit




Level Controllers

- Ultrasonic transducer:
 - Ultrasonic pulses hit the water surface & bounce back
 - Pulse travel time is converted to electrical signal in control system

Grit

- Pump down the wet well to the lowest possible level and then flush the grit to the pump's suction with high pressure hoses
- Grit accumulation leads to reduced flow to pumps and loss of wet well capacity
- A mixer may re-suspended material in the bottom of the wet well




Grit Removal




- Removed by flushing, bucket machine or vacuum truck

Grease & Scum in Wet Well

- Causes odors & impairs functioning of equipment
- Removal:
 - Manual
 - Chemical/biological treatment of FOG



Odor Control

- Minimize wet-well turbulence
- Treatment with scrubbers or biofilters
- Chemical addition
 - Chlorine
 - Hydrogen peroxide
 - Oxygen
- Chemicals should be closely monitored



- Odor control unit installed at a lift station
- Carbon bed based scrubber to control Hydrogen sulfide odors

Lift Station Problems

- Power
- Control system (flooded wet well)
- Pumping system (stuck check valve; air-bound pump)
- Structure (ventilation fan burned out)

Lift Station Safety

- Confined space
- Hazardous atmospheres
- Slippery ladders or stairs
- Mechanical & electrical hazards
- Insects, snakes & rodents
- Infections & diseases
- Inadequate drainage
- Drowning



Lift Station Maintenance

- Daily
 - Visual inspection:
 - Is everything running?
 - Is anything missing or out of place?
 - Check chemical levels
 - Clean screens and check for buildup
 - Audible:
 - Any unusual sounds from motors, pumps, meters, etc.

Lift Station Maintenance

- Weekly
 - Record run hours:
 - How long each pump has run
 - Check if any maintenance is due
 - Check blowers
 - Run generator
 - Record meter numbers:
 - Totalizer numbers
 - Chemical feed volume and levels

Lift Station Maintenance

- Monthly
 - Check floats, sensors, connections
 - Operate every float to ensure proper operation
 - Check if alarms are working (audible, visible)
 - Verify SCADA or dialer connection
 - Verify numbers match with SCADA
 - Check pressure gauge
 - Verify pressure is correct for force main

Lift Station Maintenance

- **Annually**
 - Cleaning and Inspection
 - Vac truck for any solids accumulation
 - Check for corrosion
 - Pull pumps and motors
 - Complete any components that need replacement
 - Check valves and gates
 - Ensure no stuck valves or blocked gates
 - Drawdown test
 - Check pump functions and efficiency

Lift Station Maintenance

- **Drawdown test**
 - A way to periodically check the flow rate of each pump
 - Each pump is operated in hand to empty a known volume of wastewater from the wet well while timed

$$\frac{\text{Gallons pumped}}{\text{Time in minutes}} = \text{Actual gpm}$$

$$\text{Pump Efficiency \%} = \frac{\text{Actual gpm}}{\text{Rated gpm}} \times 100\%$$

Lift Station Maintenance – Basic Tasks

- **Annually:**
 - Cleaning and Inspection. Drawdown and efficiency test. Check all valves. Inspect for corrosion. Pull motors and inspect
- **Monthly:**
 - Amperage draws for each motor. Check floats and ensure high and low sensors are working. Check downstream pressure
- **Weekly:**
 - Record hour meters and calculate run times for each motor. Record number of cycles and gallons pumped
- **Daily:**
 - Ensure operation and check for unusual conditions

Diagnosing a Failed Check Valve



Lift Stations Vocabulary

- | | |
|-------------------------|-----------------------------|
| _____ 1. Cavitation | _____ 9. Lift Station |
| _____ 2. Comminutor | _____ 10. Pneumatic Ejector |
| _____ 3. Discharge Head | _____ 11. Suction Head |
| _____ 4. Dry Well | _____ 12. Volute |
| _____ 5. Entrain | _____ 13. Water Hammer |
| _____ 6. Force Main | _____ 14. Wet Well |
| _____ 7. Head | |
| _____ 8. Impeller | |

- A. A pipe that carries wastewater under pressure from the discharge side of a pump to a point of gravity flow downstream.
- B. A wastewater pumping station that lifts the wastewater to a higher elevation when continuing the sewer at reasonable slopes would involve excessive depths of trench. These stations may be equipped with air-operated ejectors or centrifugal pumps. Sometimes called a pump station.
- C. A device used to reduce the size of the solids chunks in wastewater by shredding. The shredding action is like many scissors cutting to shreds all the large solids in the wastewater.
- D. The spiral-shaped casing that surrounds a pump, blower or turbine impeller and collects the liquid or gas discharged by the impeller.
- E. The vertical distance, height or energy of water above a point. This may be measured in either height (feet) or pressure (pounds per square in or psi).
- F. A device for raising wastewater sludge or other liquid by compressed air.
- G. The formation and collapse of a gas pocket or bubble on the blade of an impeller or the gate of a valve. It is accompanied by a loud noise that sounds like someone is pounding on the impeller or gate with a hammer.
- H. The sound like someone hammering on a pipe that occurs when a valve is opened or closed very rapidly. When a valve position is changed quickly, the water pressure in a pipe will increase and decrease back and forth very quickly. This rise and fall in pressures can cause serious damage to the system.
- I. A rotating set of vanes in a pump designed to pump or lift water.
- J. The pressure (in pounds per square inch or psi) measured at the centerline of a pump discharge and very close to the discharge flange, converted to feet. The pressure is measured from the centerline of the pump to the hydraulic grade line of the water in the discharge pipe.
- K. The positive pressure (in feet or pounds per square inch or psi) on the suction side of a pump. The pressure can be measured from the centerline of the pump up to the elevation of the hydraulic grade line on the suction side of the pump.
- L. To trap bubbles in water either mechanically through turbulence or chemically through a reaction.

7. Why should air release valves be installed at high points in force mains?

8. Which type of pump is most commonly used in raw wastewater lift stations?

9. Why should lift stations be equipped with at least two pumps?

True-False

10. Equipment located in the wet well should be minimized.
True
False

11. Power to electrode controllers must be turned off and properly tagged before performing any maintenance on the equipment.
True
False

12. Gate valves are less susceptible to plugging than plug valves.
True
False

Multiple Choice

13. Lifting of wastewater in a lift station is accomplished by:
 - a. Air lift pumps
 - b. Centrifugal pumps
 - c. Piston pumps
 - d. Turbine pumps

14. Accumulated air in force mains is blown off by:
 - a. Air release valves
 - b. Altitude control valves
 - c. Blowers
 - d. Check valves

15. A sump pump is used to pump drainage out of a:
 - a. Dry well sump
 - b. Full wet well
 - c. Manhole
 - d. Wet well sump

16. The purpose of a check valve is to:
 - a. Adjust the discharge flows from the pump
 - b. Isolate the pump from the system
 - c. Prevent the force main from draining back into the wet well
 - d. Prevent plugging of pumps

17. Pumps draw more power starting than during normal operating conditions because:
 - a. Gate valves have to be pushed open
 - b. Pipe friction losses are greater
 - c. The motor and pump have to start turning
 - d. The total dynamic head is greater

18. Advantages of float control systems include:
 - a. Capacity to completely drain the wet well
 - b. May be reset manually or by remote control
 - c. Sensitivity to water level changes
 - d. Simple design eliminates fouling by grease or debris

19. Limitations of electrode controllers include:
 - a. Grease or slime can cover electrodes
 - b. If not properly maintained, pumps may not start and stop when desired
 - c. Rags and debris can foul electrodes
 - d. There are none
 - e. A, B and C

Answers to Vocabulary and Questions

Vocabulary:

- | | | |
|------|-------|-------|
| 1. G | 7. E | 13. H |
| 2. C | 8. I | 14. N |
| 3. J | 9. B | |
| 4. M | 10. F | |
| 5. L | 11. K | |
| 6. A | 12. D | |

Questions:

1. To lift or raise wastewater or storm water from a lower elevation to a higher elevation
2. The energy required to start a pump is greater than the total dynamic head (TDH) during normal operating conditions because additional energy is required to start the motor and the pump to start the water flowing through the pipes, the check valves and the pump.
3. Advantages: Prevent any large debris from entering and plugging or damaging the pump. Limitations: Must be cleaned frequently so there is no substantial restriction of wastewater flow to the pumps.
4. Isolation valves in lift stations should be gate valves instead of plug valves because some types of plug valves can be slammed shut by wastewater backflow and possibly injure you and break the valves body or a portion of the pipe system from the water hammer due to the sudden stoppage of the flowing water. Also plug valves have a restriction that can be clogged with rags or sticks.
5. To provide a safe atmosphere for operation and maintenance operators
6. Power, control systems, pumping systems, structures
7. to prevent accumulation of air and other gases; trapped pockets of air reduce the carrying capacity of the pipe, increase pumping costs, contribute to damage by water hammer and may create negative pressures strong enough to collapse pipes
8. centrifugal pumps
9. to provide continuous operation if one pump fails or needs repairs
10. True
11. True
12. False
13. B
14. A
15. A
16. C
17. C
18. C
19. E

Section 7
Inspection & Testing



Inspection & Testing Collection Systems

Reasons for Inspecting & Testing


- Wastewater collection systems are designed to be a reliable method to convey all wastewater to a treatment facility
- In order to accomplish this new and existing systems must be inspected and tested to gather information for the development of operation and maintenance programs
- The two main purposes of inspection and testing are to prevent leaks from developing in the system and to identify existing leaks so they can be corrected
 - The location and elimination of leaks is one of the major concerns of system operators

Reasons for Inspecting & Testing

- Inspection and testing accomplishes:
 - Identifying existing and potential problem areas
 - Evaluating the seriousness of detected problems
 - Determining the exact location of facilities and problems
 - Providing detailed information to supervisors regarding problems


Why are leaks a problem?

- When sewer lines are below the water table infiltration occupies valuable capacity in the sewer and downstream treatment plant
- Sewers above the water table can exfiltrate raw wastewater polluting soil, groundwater and surface water
- Leaks also attract root intrusion into sewers causing damage and stoppages



Types of Collection System Problems

- Design related deficiencies – ability of soil to support pipe and manhole weights, shifting soils, and vibrating or crushing forces from traffic
- Improper installation – improper line, grade, and joint installation or shortcuts in bedding, connections and backfilling
- Inadequate sewer use ordinances
- Improper inspection and enforcement of tap-ins or service connections



Types of Collection System Problems

- Population shifts or changing patterns of activities can result in surcharging sections of the system
 - Surcharge – the supply of wastewater to be carried exceeds the pipe capacity
- Problems of a recurrent nature – grease, debris, and trash from specific dischargers resulting stoppages or restrictions
- Problems characteristic of that region resulting in rapid deterioration – climate, high sulfate content, high soil or wastewater temperatures

Types of Collection System Problems

- Poor coordination and cooperation between local agencies – street construction and repair, existing utilities, handling illegal dumping into sewers
- Disaster or contingency situations – explosions, earthquakes, or subsidence
 - Subsidence – the settling of underground utilities after the removal of excess water from an aquifer
- Problems related to old or neglected collection systems




Why control Infiltration & Inflow?

- Infiltration and Inflow (I/I) is recognized as a major cause of operational problem which can lead to poor performance or system failure
- Hydraulic overloads in a collection system lead to surcharged manholes, overflowing manholes, exposure of the public to the pathogens found in raw wastewater, and negative environmental effects
 - Sanitary Sewer Overflow (SSO)
 - Capacity Assurance, Management, Operation, and Maintenance (CMOM) – program proposed by the EPA specifically to control SSOs, reduce system degradation, avoid hydraulic overloading, SSO response, and protect the public's investment

Why control Infiltration & Inflow?

- Hydraulic pressure resulting from overloading can lead to pipe failure because it is not designed as a pressure pipe
- Overloading can lead to exfiltration which can wash away the bedding material and soil creating voids that can lead to subsidence
- Wastewater treatment plants can exceed their hydraulic capacity which can overload the treatment processes and result in inadequate treatment

Examples of Infiltration & Inflow



Inflow

- ***Inflow is water that is not polluted and should be in a stormwater drainage system, not a wastewater collection system***
- Enters from deliberate illegal connections or by deliberate drainage of flooded areas
- Detection requires flow studies and inspections by smoke or dye testing of surrounding residential and commercial buildings or private property
- Corrections require sewer use ordinance
- Storm water inflow from pick holes in cover, poor seal between cover & casting

Infiltration

- Created by high levels groundwater
- Through deteriorated or broken pipes, joints, manholes
- Detected by metering flows during low flow periods
- Once located, conduct field verification using visual inspection, CCTV inspection and/or smoke or dye testing


Exfiltration

- Leakage of wastewater out of CS through broken or damaged pipes or manholes
- May contaminate shallow wells or ditches where children and pets play
- Detected by CCTV inspection or smoke testing

Manhole Inspections

- Manholes are an important part of the collection systems and require the same inspection and attention as the rest of the sewer network
- Inspection Objectives:
 - Determine the proper elevations or grades around the lid
 - Ensure lid isn't buried
 - Examine structural integrity – look for cracks
 - Performing its intended job

Manhole Inspection: Examples



Manhole Inspection: Equipment

- Inspection forms are needed to act as a record and a checklist to make certain all types of defects or maintenance requirements are adequately documented – can be done electronically
- Powerful flashlight – mirror can also be used (lamping)
- Map of the collections systems – geographic information system (GIS)
- Manhole hook or lid removal device
- Scrapers and wire brushes for cleaning the manhole ring

Manhole Inspection: Equipment

- Rigid straightedge (5-6 ft long) for measuring the grade around the lid
- Hand protection – leather gloves
- All traffic control safety equipment
 - Manual of Uniform Traffic Control Devices (MUTCD)
- Atmospheric monitoring device
- Telescoping measuring device to measure depth of flows, verify pipe diameters and measure depth of manhole inverts
- Blower and hose for ventilating the manhole

Manhole Inspection: Objectives

- Some agencies prohibit manhole steps and use ladders instead to eliminate hazards of corroded steps
- Manhole pressure tests are typically negative-pressure (vacuum) tests
- New manholes should be carefully inspected before acceptance
- Existing manholes should be inspected once every 1 to 5 years and more often for those located in areas of heavy vehicle traffic



Manhole Inspection: Procedure

➤ These six steps can be used to inspect manholes of brick and mortar, concrete, lining or prefabricated material



1. Locate the manhole and check the area around it for proper drainage away from the lid
 - Use the straightedge to measure the grade
 - A lid that is too high or too low will be subject to pounding from crossing vehicles
 - In easement areas the lid should be 2 or more inches above the surrounding soil

Manhole Inspection: Procedure

2. Test the atmospheric conditions
 - Insert the monitor probe through an opening in the manhole cover
 - Test for 15 minutes starting at the top and taking measurements every 5 feet until the bottom is reached



Manhole Inspection: Procedure

3. Use the ventilation blower
 - Use the outlet hose to blow away debris from around the manhole ring – prevents it from falling in on someone working in the manhole
 - Exercise caution when removing lid
 - Lower the outlet hose until it reaches the operator head level (5-6 feet up from bottom)
 - Lower the probe of the atmospheric monitoring device to the same level, should be monitored by the topside attendant and readings should be recorded every 10 – 15 minutes

Manhole Inspection: Procedure

4. Inspect the manhole
 - Mark the inspection form in accordance with the configuration of the pipes entering the manhole
 - Use flashlight to inspect all surfaces and joints
 - Look into the sewer piping upstream and downstream for cracks or breaks that could have been caused by settling
 - Using a light or a mirror and reflected sunlight to inspect a sewer between two adjacent manholes is known as lamping

Manhole Inspection: Procedure

4. Inspect the manhole
 - Document the locations and types of any observed defects including:
 - Crack or breaks in the walls or bottom
 - Infiltration – estimate flow in gallons per minute
 - Joint security
 - Offsets or misalignments
 - Root intrusions
 - FOG accumulations
 - Gravel, debris, concrete, grout accumulations
 - Sluggish wastewater flow or backup
 - Corrosion

Manhole Inspection: Procedure

5. Use a wire brush and scraper to clean the ledge of the manhole ring, then inspect it carefully for any cracks in the metal

If a crack is observed, the manhole should be barricaded and the ring should be replaced immediately because a single crack in a manhole ring weakens the rest of the metal parts, and could result in a sudden failure under vehicle load

Manhole Inspection: Procedure

6. Replace the manhole lid
 - The lid should not rock or rattle when touched
 - Inspect to be sure there not debris on the ring before reporting the rattle as a defect – it will only get worse with time
 - Vehicles driving over a rocking or improperly seated manhole lid can cause it to flip completely out of the ring creating a hazard
 - Defective manhole lids and rings should be replaced as soon as possible

CCTV Inspections

- Closed-circuit television inspection (CCTV) of a sewer provides valuable information for operators identifying issues and their locations within a collection system



CCTV Inspections

- Positive identification by CCTV eliminates the guesswork and can be used to identify:
 - Pipe structural conditions
 - Integrity of pipe joints
 - Leaks (I/I)
 - Pipe sags that accumulate debris
 - Service lateral condition and location
 - Root intrusion sources
 - Fats, oils, and grease accumulation
 - Illegal or protruding taps
 - Evaluate the effectiveness of maintenance work

CCTV Inspections

- There are two types of camera systems commonly used – analog and digital
- Analog – provides a video feed by cable to a remote viewing and recording system
- Digital technology processes several images per second to create a single image for viewing
 - High resolution images can be evaluated much more quickly and accurately than analog systems

CCTV Inspections

- Data collection and pipe assessments require standardization in observations and recording methods
 - This allows various personnel to record observations consistently
 - National standards system can be used such as the Pipeline Assessment and Certification Program (PACP) through the National Association of Sanitary Sewer Contractors (NASSCO)

CCTV Inspections

- Conventional CCTV inspection systems are used to inspect 6-15 inch diameter sewer pipes using a camera mounted to a self-propelled transporter or pulled by remote winch
 - Small diameter pipe can be inspected from a lateral-launch small camera system
 - Lateral-launch camera typically allows inspections of 50-70 feet from the main sewer pipe



CCTV Inspections

- Video signal is sent by cable to a TV monitor and recording equipment or computer
- Camera lens may be fixed allowing only forward viewing or pan/tilt type that allows rotational inspection of pipe joints, views up service connections, or inspect flaws closely




Self-propelled Transporters

- Used to move the camera through the pipe
- Called tractors or crawlers
- Can be continuous track or have wheels with different coatings and traction configurations for various pipe conditions



Self-propelled Transporters

- The camera is hard mounted to the transporter and a steel cable or bridle (strain relief cable) is used on the camera cable to provide some slack and strain relief, so the camera does not pull free from the cable during operation or pull-back



Winch CCTV Systems

- Although self-propelled transporters are the most common means of moving the camera in the pipe, remote winch systems are still used where self-propelled systems are not suitable
- The CCTV camera is mounted to a skid that is pulled through the system by a steel cable attached to the winch
 - Typically 500 – 1000 feet of small diameter cable
 - Winch is typically located at the far manhole

Additional Inspection Options

- Portable and small-diameter pipe inspection systems are simple, lightweight, and designed to give real-time data in areas of the system that are difficult to reach with conventional systems




Additional Inspection Options

- Digital scanning provides advanced inspection capabilities by capturing high-resolution digital images to give a full pipe or unfolded image
 - Wide-angled lenses used
 - Review and assessment of the inspection can be done separately
- Zoom cameras (pole cameras) are a rapid deployment pipe inspection tool
 - Allows for inspection of conditions in deep manholes and the pipes entering the manhole



Additional Inspection Options Pole Camera




Additional Inspection Options

- Nozzle-based camera platforms are used for real-time problem inspection when CCTV is not available, QA/QC of repairs and cleaning activities and standard assessments



CCTV Inspections

- “Pull type” CCTV inspection assembly requires at least two manholes be open.
- Pipe should be cleaned prior to inspection (high-velocity cleaning, power rodders, balling, bucket machines, water-jet vacuum trucks) to remove grit, grease, roots, sludge, etc.




Logging & Recording CCTV Inspections

- Written log/inspection report
- Still photographs
- Videotape recordings



Logging & Recording CCTV Inspections

- Example of what camera may see:
 - CCTV inspection shows one section flowing $\frac{1}{2}$ full, but upstream and downstream are only $\frac{1}{4}$ full, why?
 - There may be a sag in the pipe



Logging & Recording CCTV Inspections



Purpose of Smoke Testing

- Sources of entry of surface water to CS
- Proof buildings are connected to CS
- Location of illegal or faulty connections
- Location broken sewers
- Location lost manholes



Smoke Testing Equipment

- Smoke blower unit
- Pipe plugs
- Smoke bombs



Smoke Testing Preparations

- Warn public in advance when and where smoke testing is planned
- Involve local fire and police departments
- Train all operators how to handle persons who discover smoke in their homes
- Prepare operators to respect property and privacy of customers
- Inspect area to be tested



Smoke Testing



Dye Testing

- Used to:
 - Determine if facilities or fixtures are connected to sewer
 - Estimate velocity of WW in sewer
 - Test for infiltration and exfiltration
- Equipment: manhole hook & dye (tablet vs. powder)



Dye Testing

- Tracer dyes are also effective for estimating sewer velocities
- Start with downstream section and work upstream
- Insert the dye in the upstream manhole and record the time until it is first seen in the downstream manhole (t1) and when the dye can no longer be seen (t2)





Inspecting & Testing Vocabulary

- | | |
|----------------------------|----------------------|
| _____ 1. Corrosion | _____ 6. Subsidence |
| _____ 2. Offset | _____ 7. Surcharge |
| _____ 3. Pre-Cleaning | _____ 8. Tag Line |
| _____ 4. Saddle Connection | _____ 9. Water Table |
| _____ 5. Sewer Gas | |

- A. A building service connection made to a sewer main with a device called a saddle.
- B. A pipe joint that has lost its bedding support and one of the pipe sections has dropped or slipped, thus creating a condition where the pipes no longer line up properly.
- C. A line, rope or cable that follows equipment through a sewer so that equipment can be pulled back out if it encounters an obstruction or becomes stuck. Equipment is pulled forward with a pull line.
- D. The dropping or lowering of the ground surface as a result of removing excess water (overdraft or over pumping) from an aquifer. After excess water has been removed, the soil will settle, become compacted and the ground surface will drop and can cause the settling of underground utilities.
- E. The gradual decomposition or destruction of a material due to chemical action, often due to an electrochemical reaction.
- F. The upper surface of the zone of saturation of groundwater in an unconfined aquifer.
- G. Gas in collection lines (sewers) that result from the decomposition of organic matter in the wastewater. When testing for gases found in sewers, test for lack of oxygen and also for explosive and toxic gases.
- H. Sewers are surcharged when the supply of water to be carried is greater than the capacity of the pipes to carry the flow. The surface of the wastewater in the manholes rises above the top of the sewer pipe, and the sewer is under pressure or a head, rather than at atmospheric pressure.
- I. Sewer line cleaning, commonly done by high-velocity cleaners, that is done prior to the TV inspection of a pipeline to remove grease, slime and grit to allow for a clearer and more accurate identification of defects and problems.

Inspecting & Testing Questions

- 1. Why must inflow and infiltration be controlled?
- 2. What are the sources of inflow?

3. How can sources of infiltration be located?
4. How can infiltration problems be corrected or eliminated?
5. Why should exfiltration be controlled?
6. Why should manholes be inspected?
7. How often should a manhole be inspected?
8. Why must testing and inspecting collection systems be done thoroughly and on a regular basis?
9. Why should the TV camera always be pulled from the upstream manhole to the downstream manhole?
10. What is the purpose of smoke testing?
11. Where should observers look for smoke?
12. What is the purpose of dye testing?
13. What is the purpose of pipeline lamping?

Answers

Vocabulary:

- | | | |
|------|------|------|
| 1. E | 4. A | 7. H |
| 2. B | 5. G | 8. C |
| 3. I | 6. D | 9. F |

Questions:

1. Inflow and infiltration must be controlled to prevent hydraulic overload on the collection system or the wastewater treatment plant.
2. The source of inflow includes deliberate connections and surface drainage.
3. Sources of infiltration can be identified by the use of closed-circuit television, flow metering devices, smoke testing, dye testing and visual inspection.
4. Infiltration problems can be corrected or eliminated by sealing using pressure grouting, digging up and replacing pipe or inserting a plastic or fiber liner.
5. Exfiltration must be controlled because it can cause pollution of groundwaters.
6. Manholes should be inspected to be sure the lid is at the proper elevation, the manhole is structurally sound and the manhole is performing its intended job.
7. Every 1-5 years with those in heavy traffic areas being inspected more often.
8. To reduce the number of stoppages and failures.
9. The TV camera should always be pulled from the upstream manhole to the downstream manhole for the sake of consistency. Also there is a lesser chance of the camera becoming stuck in older lines. Pulling the camera toward the downstream manhole also helps to prevent a buildup of rages and debris in front of the lens.
10. To determine: sources of entry to the collection system of surface waters, proof that buildings or residences are connected to a wastewater collection system, location of illegal connections, location of broken sewers, location of lost manholes and diversion points.
11. Look for smoke from: roof vents, building foundations (especially where the house sewer passes under the foundation), yard drains, rain gutters and inside buildings.
12. To determine if certain facilities or fixtures are connected to the wastewater collection system, such as buildings that don't show smoke from vents during smoke tests and yard drains or storm drains.
13. The purpose of pipeline lamping is to determine whether or not a section of pipe is straight and open.

Section 8

Cross Connection Control




Cross-Connection Control

Outline

- Case studies of backflow incidents
- Basics of Cross-Connection Control
- Hydraulics
- Definitions
- Backflow Preventers
- Applications


Backflow Case Study Human Blood in the Water System

- Blood observed in drinking fountains at a funeral home
- Hydraulic aspirator used to drain body fluids during embalming
- Contamination caused by low water pressure while aspirator was in use




Backflow Case Study Kool-Aid Laced with Chlordane

- Exterminator submerged garden hoses in small buckets while mixing insecticide at the same time a water meter was being installed nearby
- During a new water meter installation chlordane was back siphoned into water lines and became mixed with Kool-Aid
- A dozen children and three adults became sick




Backflow Case Study Propane Gas in the Water Mains

- Gas company initiated repairs on 30,000 gallon liquid propane tank by flushing with fire hydrant
- Vapor pressure of propane residual in the tank exceeded water main pressure
- Hundreds evacuated, two homes caught fire, water supply contaminated





Backflow Case Study EPA Study

- EPA compiled backflow incident data from 1970 to 2001 and found:
 - 459 incidents resulted in
 - 12,093 illnesses
 - Backflow incidents can result in property damage, personal injury, and even death




Authority

- Federal
 - Federal Safe Drinking Water Act
- State
 - Tennessee Safe Drinking Water Act
 - Statute
 - Regulation
- Local
 - Ordinance (City) or Policy (Utility)
 - Plumbing Code
 - Cross Connection Control Plan





Hydraulics and Pressure




- Water can flow through a pipe in either direction
- The direction of flow will depend on the forces (pressures) acting on the water
- Water pressure naturally tends to equalize
- Therefore, water flows down a gradient from high pressure regions to low pressure regions

Head Pressure




27 3/4" = 2.31 Feet of Head


- 27 3/4" of water generates a pressure of one pound per square inch (psi)
- The pressure on the bottom of the container is generated by the weight of the water above it




Normal Flow




No Flow



Normal Flow




Reverse Flow - Backflow



A diagram showing a house with a water supply line. A fire hydrant is connected to the line. The hydrant is labeled '0 psi' and the house supply is labeled '85 psi'. White arrows indicate the normal flow direction from the house to the hydrant. A large splash of water is shown coming from the hydrant, indicating reverse flow.

Backflow


- The undesirable reversal of flow of water or other substances into the potable water distribution supply



- Occurs due to:
 - Backpressure
 - Backsiphonage


Backpressure

- Pressure in downstream piping greater than supply pressure



A diagram showing a pipe with a red arrow pointing left, labeled 'BACKPRESSURE'. A blue arrow below it points right, labeled 'Normal Direction of Flow'. Water is shown splashing out of the pipe.


Backpressure



A diagram showing a pipe with two gauges. The left gauge is labeled '50 psi' and the right gauge is labeled '55 psi'. Red arrows point from the gauges to the pipe. White arrows inside the pipe point left, indicating reverse flow.

Backsiphonage


- Sub-atmospheric pressure in the water system



A diagram showing a pipe with a red arrow pointing left, labeled 'BACKSIPHONAGE'. A blue arrow below it points right, labeled 'Normal Direction of Flow'. Water is shown being drawn into the pipe.

Backsiphonage


What is drawn into the water pipes if backsiphonage occurs?




- As backsiphonage occurs air will be drawn up into the water pipes

Backsiphonage


What is drawn into the water pipes if backsiphonage occurs?




➤ Whatever is in the barrel...



Backsiphonage



Aspirator Effect



➤ As water flows through a pipe, the pressure against the walls of the pipe decreases as the speed of the water increases


➤ If a second pipe is attached there could be a low pressure area created at the point of connection which could siphon water from the attached pipe into the flowing pipe - Backsiphonage

Cross-Connection

➤ An actual or potential connection between a potable water supply and any non-potable substance or source


➤ Cross-connection types:

- Direct
- Indirect



Direct Cross-Connection

➤ A direct cross-connection is subject to backpressure or backsiphonage




Water Make-up Line



Direct Connection

Indirect Cross-Connection

➤ An indirect cross-connection is subject to backsiphonage only



Submerged Inlet



Degree of Hazard

<ul style="list-style-type: none"> ➤ Non-Health Hazard <ul style="list-style-type: none"> ➤ Low hazard ➤ Will not cause illness or death ➤ Pollutant 	<ul style="list-style-type: none"> ➤ Health Hazard <ul style="list-style-type: none"> ➤ High hazard ➤ Causes illness or death ➤ Contaminant
---	--




The Backflow Incident


For backflow to occur three conditions must be met:

1. There must be a cross-connection. A passage must exist between the potable water system and another source.
2. A hazard must exist in this other source to which the potable water is connected.
3. The hydraulic condition of either backsiphonage or backpressure must occur.

Five Means of Preventing Backflow


- Air Gap Separation (AG) Best Method
- Reduced Pressure Principle Assembly (RPZ/RPBP/RP) Best Device
- Double Check Valve Assembly (DCVA)
- Pressure Vacuum Breaker (PVB)/ Spill-Resistant Vacuum Breaker
- Atmospheric Vacuum Breaker (AVB)

Air Gap



➤ An air gap is the vertical separation between the water supply line outlet and the overflow rim of the non-pressurized receiving fixture or tank

Air Gap




- An air gap is the *BEST* method of protection against backflow
- Approved air gap separation must have a vertical unobstructed distance of at least twice the internal diameter of the outlet pipe, but never less than 1 inch

2 X ID,
not <1 inch

Air Gap Separation Limitations

- The air gap is the best method of backflow prevention, but it is easily defeated through modifications or being bypassed
- The air gap separation causes a loss of pressure in the system
- Sanitary control is lost - cannot be installed in an environment containing airborne contamination




Approved Air Gap Separation

- Backflow Protection Against:
 - Backsiphonage
 - Backpressure
 - Contaminant (health hazard)
 - Pollutant (non-health hazard)



BEST METHOD OF PROTECTION


Reduced Pressure Principle Assembly




Normal Flow →

Reduced Pressure Principle Assembly

- The reduced pressure principle backflow prevention assembly (RP) consists of two independently operating check valves together with a hydraulically operating, mechanically independent, pressure differential relief valve located between the check valves, all located between two resilient seated shutoff valves and four properly located test cocks.
- *BEST* device to protect against backflow



RP



RP

- The two check valves loaded in the closed position mechanically keep the water flowing in one direction through the assembly
- The relief valve assembly is designed to maintain a lower pressure in the zone between the two checks than in the supply side of the unit which hydraulically keeps the water flowing in one direction through the assembly
- Water always flows from high pressure to low pressure


RP

- Backflow Protection Against:
- Backsiphonage
- Backpressure
- Contaminant (health hazard)
- Pollutant (non-health hazard)

BEST DEVICE FOR PROTECTION




Double Check Valve Assembly (DC)




Double Check Valve Assembly (DC)

- The double check valve backflow prevention assembly (DC) consists of two independently operating check valves installed between two tightly closing resilient seated shutoff valves and fitted with four properly located test cocks
- Similar to the RP, but has no relief port so it cannot maintain a lower pressure in the zone between the checks and nowhere for the water to go during a backflow incident or failure



Double Check Valve Assembly (DC)


- Since the water in a DC cannot leave the system during a backflow event or assembly failure then it is a higher risk and therefore cannot be used in a high hazard (contaminant) application
- If one check fails the other will continue to protect, but given enough time the second check will fail and backflow will occur



Second check fouled during backpressure

Double Check Valve Assembly (DC)

- Backflow Protection Against:
- Backsiphonage
- Backpressure
- Pollutant only



Proper Installation for DC and RP

- Lowest part of the relief valve should be a minimum of 12 inches above either: the ground, the top of the opening of the enclosure wall, or the maximum flood level
 - Whichever is highest, in order to prevent any part of the assembly from becoming submerged
- Maximum 60" above grade to the center line of assembly, if higher then safe permanent access must be provided for testing and servicing


* Tennessee Cross-Connection Control Manual and Design Criteria for Cross-Connection Control Plans, Ordinances, and Policies (2008) – Appendix B

Proper Installation for DC and RP


- Assemblies should be installed in accordance with manufacturer's installations otherwise it voids the approval for the assembly
- Protected from vandalism and weather (if needed)
- RP requires adequate drainage – **cannot** be installed in a pit or meter box
- Must be accessible for testing and repair



Pressure Vacuum Breaker (PVB)




Pressure Vacuum Breaker (PVB)




- The pressure vacuum breaker or spill resistant vacuum breaker consists of an independently operating check valve loaded in the closed position and an independently operating air inlet valve loaded in the open position and located on the discharge side of the check valve, with tightly closing shutoff valves on each side of the check valves, and properly located test cocks for valve testing

Pressure Vacuum Breaker (PVB)



- Incoming water pressure will compress the spring on the check and flow into the body
- As pressure builds up in the body it will compress the spring on the air valve and close it allowing water to travel downstream


PVB Backsiphonage Condition




- In a backsiphonage condition there is a loss of supply pressure and the check valve is forced closed
- If the body loses pressure the air inlet valve is forced open allowing air into the body of the pressure vacuum breaker and breaking any siphon
- Only to be used to protect against backsiphonage

Installation of PVB

- PVB is not designed to protect against backpressure and cannot have any source of backpressure (including head pressure) downstream of the device
- Needs to be installed **12 inches** above the highest point downstream



Pressure Vacuum Breaker




- Acceptable installation not subject to backpressure

Not acceptable in TN – all irrigation systems must be protected by an RP

Pressure Vacuum Breaker


- Improper installation subject to backpressure





Pump creating higher pressure than supply pressure = Backpressure

Pressure Vacuum Breaker

- Backflow Protection Against:
- Backsiphonage Only
- Contaminant (health hazard)
- Pollutant (non-health hazard)
- Elevation - at least 12" above downstream piping




Atmospheric Vacuum Breaker (AVB)

Atmospheric Vacuum Breaker Exploded View


Atmospheric Vacuum Breaker (AVB)



- The atmospheric vacuum breaker is a device designed to prevent backsiphonage. It consists of a body, a single moving float that acts as a check valve when there is no flow and as an air-inlet valve when flow is present, and an air-inlet opening covered by a cap


Atmospheric Vacuum Breaker (AVB)

- During a backsiphonage condition the float drops by gravity due to the loss of incoming pressure which automatically opens the air inlet, introducing air into the system to break any siphon that has formed




Installation of AVB

- AVB is not designed to protect against backpressure and cannot have any source of backpressure (including head pressure) downstream of the device
- Needs to be installed **6 inches** above the highest point downstream



Atmospheric Vacuum Breaker




- Acceptable installation not subject to backpressure

Not acceptable in TN – all irrigation systems must be protected by an RP

Atmospheric Vacuum Breaker

- Improper installation: downstream shutoff valves
- Shutoff valves downstream of an AVB can cause a continuous use situation
- The float of an AVB subjected to continuous use could begin to adhere to the air inlet and allow backflow



Atmospheric Vacuum Breaker

- Backflow Protection Against:
- Backsiphonage Only
- Contaminant (health hazard)
- Pollutant (non-health hazard)
- Elevation - at least 6"
- Non-Continuous Use



	Indirect		Direct
	Backsiphonage Only		Backpressure and Backsiphonage
	Continuous Use	Non-Continuous Use	
Health Hazard	Air Gap	Air Gap	Air Gap
	RP	RP	RP
	PVB	PVB	
		AVB	
Non – Health Hazard	Air Gap	Air Gap	Air Gap
	RP	RP	RP
	DC	DC	DC
	PVB	PVB	
		AVB	

Testing of Assemblies

- Assemblies must be tested when installed, after repair, and at least annually
- Assembly testing must be conducted by certified personnel
- TDEC issues a certification for all assembly testers
- Backflow tester certification courses are offered through the Fleming Training Center



Cross Connection Control

The ultimate goal of cross connection control is to protect the public drinking water supply



Cross Connection Vocabulary Review

- | | |
|---|---|
| <p>_____ 1. Air Gap</p> <p>_____ 2. Atmospheric Vacuum Breaker</p> <p>_____ 3. Auxiliary Supply</p> <p>_____ 4. Backflow</p> <p>_____ 5. Backpressure</p> <p>_____ 6. Backsiphonage</p> <p>_____ 7. Check Valve</p> <p>_____ 8. Cross Connection</p> <p>_____ 9. Feed Water</p> | <p>_____ 10. Pollutant</p> <p>_____ 11. Overflow Rim</p> <p>_____ 12. Pressure Vacuum Breaker</p> <p>_____ 13. Reduced Pressure Principle Assembly</p> <p>_____ 14. Water Purveyor</p> <p>_____ 15. Differential Pressure</p> |
|---|---|

- A. A valve designed to open in the direction of normal flow and close with the reversal of flow.
- B. A hydraulic condition, caused by a difference in pressures, in which non-potable water or other fluids flow into a potable water system.
- C. The test kit gauge measures this on the backflow prevention assemblies.
- D. In plumbing, the unobstructed vertical distance through the free atmosphere between the lowest opening from any pipe or outlet supplying water to a tank, plumbing fixture or other container, and the overflow rim of that container.
- E. A backflow condition in which the pressure in the distribution system is less than atmospheric pressure.
- F. A substance that would constitute a non-health hazard and would be aesthetically objectionable if introduced into the potable water system.
- G. A mechanical device consisting of two independently operating, spring-loaded check valves with a reduced pressure zone with relief valve between the check valves.
- H. Any water source or system, other than potable water supply, that may be available in the building or premises.
- I. Water that is added to a commercial or industrial system and subsequently used by the system, such as water that is fed to a boiler to produce steam.
- J. A device designed to prevent backsiphonage, consisting of one or two independently operating spring-loaded check valves and an independently operating spring –loaded air-inlet valve.
- K. A backflow condition in which a pump, elevated tank, boiler or other means results in a pressure greater than the supply pressure.
- L. A physical arrangement that connects the potable water supply with any other non-potable water supply.
- M. The top edge of an open receptacle over which water will flow.
- N. A mechanical device consisting of a float check valve and an air-inlet port designed to prevent backsiphonage.
- O. An organization that is engaged in producing and/or distributing potable water for domestic use.

Cross-Connections Review Questions

1. Define a cross-connection.

2. Explain what is meant by backsiphonage and backpressure.

3. List four situations that can cause negative pressure in a potable water supply.

-
-
-
-

4. List six waterborne diseases that are known to have occurred as a result of cross-connections.

-
-
-
-
-
-

5. What is the most reliable backflow-prevention method?

6. Is a single check valve position protection against backflow? Why or why not?

7. How often should a reduced-pressure-zone backflow preventer be tested?

8. In what position should an atmospheric vacuum breaker be installed relative to a shutoff valve? Why?

9. How does a vacuum breaker prevent backsiphonage?

10. List seven elements that are essential to implement and operate a cross-connection control program successfully?

-
-
-
-
-
-
-

Vocabulary Answers:

1. D
2. N
3. H
4. B
5. K
6. E
7. A
8. L
9. I
10. F
11. M
12. J
13. G
14. O
15. C

Review Question Answers:

1. A cross-connection is any connection or structural arrangement between a potable water system and a nonpotable system through which backflow can occur.
2. Backsiphonage is a condition in which the pressure in the distribution system is less than atmospheric pressure. In more common terms, there is a partial vacuum on the potable system.
Backpressure is a condition in which a substance is forced into a water system because that substance is under a higher pressure than system pressure.
3.
 - fire demand
 - a broken water main or exceptionally heavy water use at a lower elevation than the cross-connection
 - a booster pump used on a system
 - undersized piping
4.
 - typhoid fever
 - dysentery and gastroenteritis
 - salmonellosis
 - polio
 - hepatitis
 - brucellosis

5. The most reliable backflow prevention method is an air gap.
6. A single check valve is not considered positive protection against backflow. A check valve can easily be held partially open by debris, corrosion products or scale deposits.
7. Reduced-pressure-zone backflow preventers should be tested at least annually.
8. An atmospheric vacuum breaker must be installed downstream from the last shutoff valve. If it is placed where there will be continuing backpressure, the valve will be forced to remain open, even under backflow conditions.
9. When water stops flowing forward, a check valve drops, closing the water inlet and opening an atmospheric vent. This lets water in the breaker body drain out, breaking the partial vacuum in that part of the system.
10.
 - an adequate cross-connection control ordinance
 - an adequate organization with authority
 - a systematic surveillance program
 - follow-up procedures for compliance
 - provisions for backflow-prevention device approvals, inspection and maintenance
 - public awareness and information programs

Section 9
Safety & Trenching




Safety

Objectives

- General Duty Clause
- Traffic Safety
- Confined Spaces
- Lockout/Tagout
- Electrical Safety
- Fire Protection
- Chemical Safety

Safety


- An accident is caused by either an unsafe act or an unsafe environment.
- Personal cleanliness is the best means of protection against infection

General Duty Clause

- FEDERAL - 29 CFR 1903.1
- Worker Right to Know:
 - EMPLOYERS MUST: Furnish a place of employment free of recognized hazards that are causing or are likely to cause death or serious physical harm to employees. Employers must comply with occupational safety and health standards promulgated under the Williams-Steiger Occupational Safety and Health Act of 1970

Before Leaving the Yard

- Work assignments
- Equipment needs
- Equipment inspection
- Vehicle inspection
 - When backing up a truck, one person should always be at the rear of the truck in view of the driver
 - Mirrors and windows
 - Lights and horn
 - Brakes
 - Tires
 - Trailer hitch/safety chain









Traffic Safety

Traffic Control Zones

- Advanced warning area
- Transition area
- Buffer space
- Work area
- Termination area




Traffic Control Zones




Advanced warning area length:
Urban areas- 1 block
Roadways- 1500 ft
Freeways- ½ to 1 mile

Advanced Warning Area



- This is where you communicate to the motorists that traffic is changing ahead
 - This area will hopefully put the drivers on alert
- Must be long enough to give motorists adequate time to respond to particular work area conditions




Advanced Warning Area




- Typically ½ mile to one mile for highways
- 1500 feet for most other types of roads
- At least one block for urban streets




Transition Area



- Traffic is channeled from the normal highway lanes to the path required to move traffic around the work area
- Use of tapers
 - Channeling devices or pavement markings placed at an angle to direct traffic
- Not required if no lane or shoulder closure is involved



Transition Area




- Types of tapers used in traffic control zones:
 - Lane closure tapers – To slowly angle traffic out of a lane and eventually close it off to motorists
 - Two-way traffic tapers – To control two-way traffic where traffic is required to alternately use a single lane (One Lane Two-Way Closure or Flagger Closure)
 - Shoulder closure taper – to close off shoulder areas from motorists
 - Downstream taper – Installed after the work area to return/direct traffic back into its normal path

Buffer Space

- The buffer space is the open, unoccupied space between the transition and work areas
- Provides margin of safety for both the motorists and the operators in the street
- If a driver does not see the advanced warning signs or fails to negotiate the transition, a buffer space provides room to stop before entering the work area
- Must be kept free of equipment, operators, materials, and vehicles

Work Area

- The portion of the roadway which contains the work activity and is closed to traffic and set aside for exclusive use by operators, equipment, and construction materials
- Delineated by channelizing devices or shielded by barriers to exclude traffic and pedestrians
- Include a lateral buffer space between work activity and traffic if possible




Work Area

- All work must be done within the safety of the work area – no operator should work outside of the work area, including the buffer space
- Avoid gaps in the traffic control that may falsely lead drivers to think they have passed through the work area
- Post **Road Construction Next X Miles** to inform drivers of the length of work area
 - Do Not set up sign until work begins


Termination Area

- Provides short distance for traffic to clear work area and return to normal traffic lanes
- Downstream tapers are optional and may not be advisable when material trucks move into the work area by backing up from the downstream end of the work area
- End of Road Work sign can be used to clearly communicate to the motorists




Traffic Signs

- Always use official signs
- Most permanent warning signs are diamond-shaped with black legends on yellow background
- Temporary signs have an orange background
- Best to use picture direction instead of wording



Traffic Signs

- Signs should be 36 inches by 36 inches for low-speed applications and 48 inches by 48 inches for high-speed applications
- Minimum mounting height on fixed supports should be seven feet from the ground to the bottom of the sign in urban districts and five feet in rural
- Signs mounted on barricades or temporary supports may be installed lower but the bottom of the sign should not be less than one foot above the pavement elevation



Traffic Signs

- All traffic control devices should be constructed to yield upon impact to minimize damage to a vehicle that strikes them and to minimize hazards to motorists and workers
- No traffic control devices should be weighted so heavily that it becomes hazardous to motorists and operators
- Approved ballast for devices is sandbags, but should never be suspended from the device



Channelizing Devices

- Used to warn drivers and alert them to conditions created by work activities in roadway, to protect workers in the traffic control, and to guide drivers and pedestrians
- Include barricades, traffic cones and tubes, drums, and vertical panels
- Devices are not interchangeable because they have different effects on traffic
- Devices must be in acceptable condition



Channelizing Devices

- Barricades are commonly used to outline excavation or construction areas, close or restrict the right-of-way, mark hazards, or mount signs
- Have alternating orange and white stripes marked with reflectors that slope down toward traffic
- Classified as Type I, II, or III by the number of marked panels
- Type I and II are used in areas that traffic continues to move through, Type III are used to partially or completely close a roadway



Channelizing Devices

- Traffic cones and tubes are an effective method of channelizing traffic and best when used during daylight hours
- Can be easily moved by passing vehicles so must be monitored
- Cones are 18-36 inches high and orange in color
- Drums have higher visibility and can have the addition of lights
- Drums are 2 orange and 2 white stripes



Nighttime Traffic Control

- Additional modification to traffic control should be made for use at night
- Increased visibility of devices can be accomplished by use of lights on devices, use of larger devices such as drums, floodlighting for all flagging stations and work areas
- All traffic control devices used at night should have adequate retroreflective areas for high visibility
- All workers must have high visibility clothing approved for use at night – ANSI 107-2004 Class 3

Flaggers – MUTCD Sec. 6E.01

Because flaggers are responsible for public safety and make the greatest number of contacts with the public of all highway workers, they should be trained in safe traffic control practices and public contact techniques




Flaggers – MUTCD Sec. 6E.01

Flaggers should be able to satisfactorily demonstrate the following abilities:

- A. Ability to receive and communicate specific instructions clearly, firmly, and courteously
- B. Ability to move and maneuver quickly in order to avoid danger from errant vehicles
- C. Ability to control signaling devices (such as paddles and flags) in order to provide clear and positive guidance to drivers approaching a TTC zone in frequently changing situations
- D. Ability to understand and apply safe traffic control practices, sometimes in stressful or emergency situations
- E. Ability to recognize dangerous traffic situations and warn workers in sufficient time to avoid injury


Flaggers

- Flaggers shall wear high visibility safety apparel that meets the Class 2 or 3 requirements of the ANSI/ISEA 107-2004
- Apparel background color shall be fluorescent orange-red, fluorescent yellow-green, or a combination of the two
- The retroreflective material shall be orange, yellow, white, silver, yellow-green and shall be visible at a minimum distance of 1000 feet




Flaggers

- The STOP/SLOW paddle should be the primary and preferred hand-signaling device, use of flags should be limited to emergency situations
- Paddle shall have an octagonal shape on a rigid handle, be at least 18 inches wide with letters at least 6 inches high
- Flagging station should be at least 100 feet in front of the workspace with a sign indicating that a flagger is ahead positioned as far in front of the flagger as practical – 500 feet minimum



Flaggers


- Flaggers should:
 - Stand either on the shoulder adjacent to the road or in the closed lane adjacent to the through lane
 - Never stand in a through lane unless traffic has already been stopped
 - Be clearly visible to oncoming traffic at all times
 - Be positioned far enough in advance to warn workers of approaching danger
 - Have a line of sight to other flagger or a way to communicate with the other flagger
 - Stand alone, away from others with no distractions (including cell phones!)




Flaggers

- Flaggers must use proper hand signals to stop, slow, and allow traffic through the traffic closure
- Flagger should identify an escape route to avoid be struck by an errant vehicle


Preferred Method - Paddle



To Stop Traffic






To Release Traffic



To Alert or Slow Traffic


Emergency Use Only - Flag

Flaggers

REMEMBER

Flaggers are responsible for employee and public safety, they must have a sense of responsibility and they must receive appropriate training in traffic control practices








Confined Space

Manhole Hazards

- Atmospheric
- Physical injury
- Infection and disease
- Insects and biting animals
- Toxic exposure
- Drowning

Confined Space Conditions

- Large enough and so configured that an employee can bodily enter and perform assigned work
- Limited or restricted means of entry or exit
- Not designed for continuous employee occupancy

Confined Space Examples

- Water storage tanks
- Chemical hoppers
- Meter Vaults
- Sewers
- Manholes



Equipment Needed for Confined Spaces

- Safety harness with lifeline, tripod and winch
- Electrochemical sensors
- Ventilation blower with hose
 - Should have a capacity of no less than 750-850 cfm





Equipment Needed for Confined Spaces

- PPE
- Ladder
- Rope
- Breathing Apparatus






Permit Required Confined Space

- Contains or has potential to contain hazardous atmosphere
- Contains material with potential to engulf an entrant
- Entrant could be trapped or asphyxiated
- Positions required for entrance into a permit required confined space
 - Supervisor
 - Attendant – at least one person must be outside a permit required space
 - Entrant

Atmospheric Hazards

- Need to have atmosphere monitored!!!
 - Depletion or elimination of breathable oxygen
 - Oxygen deficient atmosphere
 - Minimum oxygen level is 19.5%
 - Explosive or flammable gas or vapor
 - These can develop in the collection system or sewer plant due to legal, illegal or accidental sources
 - Toxic or suffocating gases
 - Comes from natural breakdown of organic matter in wastewater or toxic discharges

Atmospheric Hazards

ATMOSPHERIC TESTING EQUIPMENT - ALARM SET @ 10% LEL

THREE ATMOSPHERIC CONDITIONS CAN EXIST

1. TOO LEAN TO SUPPORT COMBUSTION
2. MIXTURE JUST RIGHT, EXPLOSION OCCURS
3. MIXTURE TOO RICH TO SUPPORT COMBUSTION

* Operation and Maintenance of Wastewater Collection Systems Vol. 1, Seventh Edition – Fig. 3.21, Pg 112

Hydrogen Sulfide – H₂S

- Detected by the smell of rotten eggs
- Loss of ability to detect short exposures
 - Olfactory fatigue
- Not noticeable at high concentrations
- Poisonous, colorless, flammable, explosive and corrosive
- Exposures to 0.07% to 0.1% will cause acute poisoning and paralyze the respiratory center of the body
- At the above levels, death and/or rapid loss of consciousness occur
- S.G. = 1.19
- Alarm set point = 10 ppm (0.001%)

Hydrogen Sulfide – H₂S

%	PPM	Hazard
46	460,000	Upper Explosive Limit (UEL)
4.3	43,000	Lower Explosive (LEL)
0.1	1,000	DEAD
0.07	700	Rapid loss of consciousness
0.01	100	IDLH
0.005	50	Eye tissue damage
0.002	20	Eye, nose irritant
0.001	10	Alarm set point

*IDLH - Immediately Dangerous to Life or Health

Methane Gas – CH₄

- Product of anaerobic waste decomposition
- Leaks in natural gas pipelines
 - Odorless unless natural gas supplied through pipeline, has mercaptans added, but soil can strip the odor
- Explosive at a concentration of 5% or 50,000 ppm
- Spaces may contain concentrations above the Lower Explosive Limits (LEL) and still have oxygen above the 19.5% allowable
- Colorless, odorless, tasteless
- Acts as an asphyxiant – displaces oxygen
 - Coal miners used canaries as early alarms; if bird died, it was time to get out
- S.G. = 0.55
- Alarm set point is 10% LEL = 5000 ppm

Methane Gas – CH₄

%	PPM	Hazard
85	850,000	Amount in natural gas
65	650,000	Amount in digester gas
15	150,000	Upper Explosive Limit (UEL)
5	50,000	Lower Explosive Limit (LEL)
0.5	5,000	Alarm set point (10% of LEL)

Carbon Monoxide - CO

- Decreases amount oxygen present
 - Hazardous because it readily binds with hemoglobin in blood, starving the person's body of oxygen
- ALWAYS VENTILATE
- 0.15% (1500 ppm) DEAD
- Will cause headaches at 0.02% in two hour period
- Maximum amount that can be tolerated is 0.04% in 60 minute period
- Colorless, odorless, tasteless, flammable and poisonous
- By-product of fuel gas
 - Can be hazard in home if using gas heat or gas appliances
- S. G. = 0.97
- Alarm set point at 35 ppm

Carbon Monoxide - CO

%	PPM	Hazard
74	740,000	Upper Explosive Limit (UEL)
12.5	125,000	Lower Explosive (LEL)
0.2	2,000	Unconscious in 30 minutes
0.15	1,500	IDLH*
0.05	500	Sever headache
0.02	200	Headache after 2-3 hours
0.0035	35	8-hour exposure limit
0.0035	35	Alarm set point

*IDLH – Immediately Dangerous to Life or Health

Oxygen – O₂

- ALWAYS ventilate – normal air contains ~ 21%
- Oxygen deficient atmosphere if less than **19.5%**
- Oxygen enriched at greater than **23.5%**
 - Speeds combustion
 - Could be from pure oxygen being used to oxidize hydrogen sulfide
- Leave area if oxygen concentrations approach 22%
- Early warning signs that an operator is not getting enough oxygen:
 - Shortness of breath
 - Chest heaving
 - Change from usual responses

Oxygen – O₂

%	PPM	Hazard
23.5	235,000	Accelerates combustion
20.9	209,000	Oxygen content of normal air
19.5	195,000	Minimum permissible level
8	8,000	DEAD in 6 minutes
6	6,000	Coma in 40 seconds, then DEAD

Oxygen – O₂

- When O₂ levels drop below 16%, a person experiences
 - Rapid fatigue
 - Inability to think clearly
 - Poor coordination
 - Difficulty breathing
 - Ringing in the ears
 - Also, a false sense of well-being may develop

Oxygen – O₂

- In a confined space, the amount of oxygen in the atmosphere may be reduced by several factors
 - Oxygen consumption
 - During combustion of flammable substances
 - Welding, heating, cutting or even rust formation
 - Oxygen displacement
 - Carbon dioxide can displace oxygen
 - Bacterial action

Atmospheric Alarm Units

- Continuously sample the atmosphere
- Test atmospheres from manhole areas prior to removing the cover if pick holes available
- Remove manhole covers with non sparking tools
- **Test for oxygen first**
- **Combustible gases second (methane at 5000 ppm)**
 - Atmospheric alarms with a catalytic element are used to test for explosive conditions.



Atmospheric Alarm Units

- Alarms set to read:
 - Flammable gases exceeding 10% of the LEL
 - H₂S exceeds 10 ppm and/or
 - O₂ percentage drops below 19.5%
 - CO alarm set point is 35 ppm
- Calibrate unit before using
- Most desirable units: simultaneously sample, analyze and alarm all three atmospheric conditions

Atmospheric Alarm Units


- Some physical and environmental conditions that could affect the accuracy of gas detection instruments include:
 - Caustic gases
 - Temperature
 - Dirty air
 - Humidity
 - Air velocity
 - Vibration

Safety Procedures if Explosive Atmosphere Discovered

- Immediately notify supervisor
- Do not remove manhole cover
- Turn off running engines in area
- Route vehicles around area
- Inspect up and downstream of manhole
- Route traffic off the street
- Notify waste and or pretreatment facility
- Cautiously ventilate
- **NO SMOKING IN AREA**



August 13th, 2014 Nashville, TN



Ventilation

- Blowers need to be placed upwind of manhole and at least 10 feet from opening
- Gas driven engine – exhaust must be downwind of manhole
- Air intake should be 2-5 feet above ground service



Infectious Disease Hazards

- Many diseases may be transmitted by wastewater: hepatitis A, cholera, bacterial dysentery, polio, typhoid, amoebic dysentery
- Ingestion (splashes); inhalation (aerosols); contact (cuts or burns)
- Wash hands frequently
- Avoid touching face
- Never eat, drink or smoke without first washing hands



Best method of protection is personal cleanliness!

Written Entry System

- Employer shall document entry permits
- Entry supervisor sign permits
- Permit posted
- Shall not exceed time required
- Retain permits for at least 1 year

Information on Permit Forms

- | | |
|---------------------------------------|--|
| ➤ Space to be entered | ➤ Hazards of permit space |
| ➤ Purpose | ➤ Measures to eliminate, isolate, or control the hazards |
| ➤ Date and authorized duration | ➤ Results of tests |
| ➤ Attendant ID by name | ➤ Rescue and emergency services |
| ➤ Authorized entrants ID by name | ➤ Communications |
| ➤ Entry supervisor name and signature | |

Information on Equipment

- PPE (personal protective equipment)
- Testing equipment

Duties Of Entrants

- Know signs, symptoms, and consequence of exposure
- Properly use equipment
- Alert attendant of warning signs, symptoms and other possible hazards
- Exit when ordered to evacuate by supervisor or attendant

Duties of Confined Space Attendant

- Know signs, symptoms, and consequences of exposure
- Possible behavioral effects of hazards
- Maintain accurate count of entrants
- Remain outside permit space
- Communicate with entrants
- Summon rescue and emergency units

Duties of Confined Space Attendant

- Warn unauthorized persons to stay away
- Perform non-entry rescue
- Do not perform any duties that may interfere with primary duty: monitoring and protecting entrants

Duties of Supervisors and Managers

- Knowledge of signs, symptoms, and consequences of exposure
- Verify appropriate entries, procedure, tests and equipment
- Terminate entries and cancel permits if warranted
- Verify means for summoning rescue
- Ensure that acceptable conditions are maintained and operations remain consistent with entry permit

Required Training

- Employer shall train all employees on hazards, procedures, and skills to perform their jobs safely
- Employees trained before first assigned duty
- Employer shall certify training of employees
- Maintain individual training records of employees

Record Keeping

- Identification and Evaluation of all Hazardous areas in workplace
- Entrance permits filed
- Training Certification
- Written Confined Space Program

General Requirements

- Identify, evaluate, and monitor hazards in permit-required confined spaces
- Post signs "Permit Required"
- Prevent unauthorized entries
- Re-evaluate areas
- Inform contractors
- Have a written program available for employees
- Have proper PPE on hand
- Annual Training (TOSHA requirements)

Confined Space Requirements

- All electrodes removed and machines disconnected from power sources
- Gas supply shut off
- Gas cylinders outside work area
- All employees entering must undergo confined space training
- Ventilation used to keep toxic fumes, gases, and dusts below max levels

Lockout / Tagout



LOTO General Requirements

- Written program
- Utilize tagout system if energy isolating device not capable of being locked out
- Lockout/tagout hardware provided
- Devices used only for intended purposes
- Tagout shall warn **DO NOT START, DO NOT ENERGIZE, DO NOT OPERATE**
- Only trained employees shall perform lockout/tagout

Requirements When Lockout of Equipment

- Before beginning work on any pump, the first thing to be done is to lock it out.
 - The person doing the work should have the **ONLY** key
- Notify employees
- Employees notified after completion of work and equipment re-energized



Recommend Steps for Lockout/Tagout

- Notify employees that device locked and tagged out
- Turn off machine normally
- De-activate energy
- Use appropriate lockout/tagout equipment
- Release any stored energy
- Try to start machine by normal means

Steps for Restoring Equipment

- Check area for equipment or tools
- Notify all employees in the area
- Verify controls are in neutral
- Remove lockout/tagout devices and re-energize device
- Notify employees maintenance and/or repairs are complete and equipment is operationally

Training Requirements

- Employer shall train all employees
- All new employees trained
- Recognition of applicable hazardous energy
- Purpose of program
- Procedures
- Consequences
- ANNUAL REQUIREMENT

Inspections



- Conduct periodic inspection at least annually
- Shall include review between the inspector and each authorized employee
- Recommendation: Frequent walk through of work areas and observation of Maintenance and Operation area

Required Record Keeping

- Written Lockout/Tagout Program
- Training: Annual and New Employees
- Inspections: Annual including new equipment, inspection of devices, and procedures

Most Frequently Cited Workplace Safety Violations 2015

- Fall protection (1926.501)
- Hazard communication (1910.1200)
- Scaffolding (1926.451)
- Respiratory protection (1910.134)
- Lockout/tagout (1910.14)
- Powered industrial trucks (1910.178)
- Ladders (1926.1053)
- Electrical – wiring methods (1910.305)
- Machine guarding (1910.212)



OSHA Says

- Any electrical installations shall be done by a professionally trained electrician.
- Any employee who is in a work area where there is a danger of electric shock shall be trained.
- Employees working on electrical machinery shall be trained in lockout/tagout procedures



Fire Protection




Fire Protection Equipment

- Fire extinguishers shall be located where they are readily accessible
- Shall be fully charged and operable at all times
 - Charged after each use
- All fire fighting equipment is to be inspected at least annually
- Portable fire extinguishers inspected at least monthly, and records kept
- Hydrostatic testing on each extinguisher every five years
- Fire detection systems tested monthly if battery operated

Types of Fire Extinguishers

- Class A 
 - Used on combustible materials such as wood, paper or trash
 - Can be water based
- Class B 
 - Used in areas where there is a presence of a flammable or combustible liquid
 - Shall not be water based
 - Example is dry chemical extinguisher
 - An existing system can be used but not refilled

Types of Fire Extinguishers

- Class C 
 - Use for areas electrical
 - Best is carbon dioxide extinguisher
 - Using water to extinguish a class C fire risks electrical shock
- Class D
 - Used in areas with combustible metal hazards
 - Dry powder type
 - Use no other type for this fire

Types of Fire Extinguishers

Class	Material	Method
A	Wood, paper	Water
B	Flammable liquids (oil, grease, paint)	Carbon dioxide, foam, dry chemical or Halon
C	Live electricity	Carbon dioxide, dry chemical, Halon
D	Metals	Dry Powder

Types of Fire Extinguishers

- Combination ABC are most common
- Have the types of extinguishers available depending upon analyses performed in each area

A
B
C
D

A Common materials such as paper, wood or most other combustibles

B Flammable liquids such as gasoline, paint remover or grease


C Electrical fires

D Combustible metals usually found in industry

Fire Extinguishers

- To operate a fire extinguisher, remember the word PASS
 - **P**ull the pin. Hold the extinguisher with the nozzle pointing away from you
 - **A**im low. Point the extinguisher at the base of the fire
 - **S**queeze the lever slowly and evenly
 - **S**weep the nozzle from side-to-side

Fire Extinguishers



Combo Extinguisher


1. Pull pin. Hold unit upright.
2. Aim at base of fire. Stand back 6ft (2m).
3. Press trigger. Sweep side to side.

Chemical Safety

HAZARDOUS MATERIALS CLASSIFICATION

HEALTH HAZARD 4-Doubtful 3-Extreme danger 2-Hazardous 1-Slightly hazardous 0-Normal material	FIRE HAZARD Flash Points: 4-Below 73°F 3-Below 100°F 2-Below 200°F 1-Above 200°F 0-Will not burn
3	2
W	
1	0
SPECIFIC HAZARD Oxidizer OX Acid ACID Alkali ALK Corrosive COR Use NO WATER W Radiation Hazard ⚠	INSTABILITY 4-May detonate 3-Shock and heat may detonate 2-Violent chemical change 1-Unstable if heated 0-Stable

© NIMC www.nationalmarker.com



Safety Data Sheet

OSHA's Hazard Communication Standard (HCS)

- OSHA's Hazard Communication Standard (HCS) is designed to protect against chemical-source injuries and illnesses by ensuring that employers and workers are provided with sufficient information to anticipate, recognize, evaluate, and control chemical hazards and take appropriate protective measures
 - "Right-to-Know" standard
- This information is provided through safety data sheets (SDSs), labels, and employee training

RTK Labels

HEALTH	<input type="checkbox"/>
FLAMMABILITY	<input type="checkbox"/>
REACTIVITY	<input type="checkbox"/>
PERSONAL PROTECTION	<input type="checkbox"/>


➤ "Right to Know"

- In 1983, OSHA instituted Hazard Communication Standard 1910-1200, a rule that gives employees the right to know the hazards of chemicals to which they may be exposed in the workplace

HCS Labels


- Purpose:
 - Informs workers about the hazards of chemicals in workplace under normal conditions of use and foreseeable emergencies
- Number System:
 - 1-4
 - 1 – most severe hazard ; 4 – least severe hazard
- Information provided on label:

Product Identifier	Precautionary Statement
Signal Word	Pictogram
Hazard Statement	Contact information



National Fire Protection Association (NFPA) 704 Label

- Purpose:
 - Addresses the health, flammability, instability, and special hazards presented from short-term, acute exposures that could occur as a result of an emergency
- Number rating system:
 - 0-4; 0 – least hazardous; 4 – most hazardous
- Information provided on label:



- Health
- Flammability
- Reactivity
- Special Hazards
 - OX → oxidizer
 - W → use NO WATER
 - SA → simple asphyxiant

NFPA vs HCS Degree of Hazard

- NFPA rating system
 - 4 → extreme
 - 0 → minimal
- GHS rating system
 - 1 → highest hazard
 - 4 → lowest hazard

Safety Data Sheet (SDS)


- Must be provided by chemical manufacturer, distributor, or importer
- Formerly known as MSDS
 - Now has consistent user-friendly format
- Sections 1-8 contain general information about the chemical
- Sections 9-11 & 16 contain other technical & scientific information
- Sections 12-15 are not enforced by OSHA, but must be present to be in compliance with GHS

Safety Data Sheet Required Format

<ol style="list-style-type: none"> 1. Product identification 2. Hazard Identification 3. Information on ingredients 4. First-aid measures 5. Fire-fighting measures 6. Accidental release measures 7. Handling and storage 8. Exposure controls 	<ol style="list-style-type: none"> 9. Physical/chemical properties 10. Stability & reactivity 11. Toxicological information 12. Ecological information* 13. Disposal considerations* 14. Transport information* 15. Regulatory information* 16. Other information (including date of SDS or last revision)
---	--


* Not required by OSHA

OSHA Pictograms



Personal Protective Equipment

- Gloves
- Coveralls / Overalls
- Face Shield / Goggles
- Respirator / SCBA
- Boots
- Ear Plugs / Muffs



Terms

- Lower Explosive Level (LEL) – minimum concentration of flammable gas or vapor in air that supports combustion
- Upper Explosive Limit (UEL) – maximum concentration of flammable gas or vapor in air that will support combustion
- Teratogen – causes structural abnormality following fetal exposure during pregnancy
- Mutagen – capable of altering a cell’s genetic makeup







Trenching Safety


Trenching Safety

- Reduction of injury and illness rates.
- Daily exposure to job hazards by thousands of workers.
- Efficiency can be greatly improved.
- OSHA safety standards require:
 - Establishment of a “Safety” program
 - Training be conducted
 - Job hazards be assessed
 - Hazards and precautions be explained




Excavation Hazards

- Cave-ins are the greatest risk
- Other hazards include:
 - Asphyxiation due to lack of oxygen
 - Inhalation of toxic materials
 - Fire
 - Moving machinery near the edge of the excavation can cause a collapse
 - Accidental severing of underground utility lines




Cave-ins

- Hundreds of workers killed annually from cave-ins
- Thousand of workers injured annually from cave-ins
- Fatality rate for trenching is twice the level for general construction




Injury and Death

- Excavating is one of the most hazardous construction operations
- Most accidents occur in trenches 5-15 feet deep
- There is usually no warning before a cave-in




Asphyxiation

- Each time a breath is exhaled the weight of the load restricts inhalation of the next breath
- Slow suffocation usually follows unless rescue is immediate




Cave-ins Result From

- Vibrations
- Adjacent structures
- Freezing and thawing
- Weight of the soil itself
- Addition or removal of water
- Reduction in frictional and cohesive capacities of soil




Density and Water Content

- One cubic yard weighs - 3000 lbs or more
- One cubic foot weighs - 100 lbs or more



How do most deaths occur?

- Instantaneously
- Trenches 5 to 15 feet deep
- With absolutely no warning
- In seemingly safe conditions
- With workers in a bent or lying position



Before you begin excavation:

- The site must be assessed
- Potential hazards must be determined
- Known hazards reduced or eliminated
- Emergency procedures established
- Periodic inspection intervals determined
- Utility locations must be staked or marked

- Regardless of the equipment used, a sewer trench must be kept as narrow as possible

Before you dig

- Call Tennessee One-Call at 811 to locate underground Utility locations must be staked or marked
- State law requires three business days notice for locating lines

APWA UNiform Color code of marked underground utility lines

White	Proposed excavation
Pink	Temporary survey markings
Red	Electric power lines, cables, conduit, and lighting cables
Yellow	Gas, oil, steam, petroleum, or gaseous materials
Orange	Communication, alarm, or signal lines, cables or conduit
Blue	Potable water
Purple	Reclaimed water, irrigation, and slurry lines
Green	Sewer and drain lines

Basic Safety Requirements

- Conduct inspections before each work shift
- Do not travel under elevated loads
- Do not work over unprotected employees
- Wear proper personal protective equipment
- Provide walkways or bridges over trenches

Basic Safety Requirements

- Provide trench exits within 25 feet of workers in trenches more than four feet deep
 - For every 25 feet of trench there needs to be 1 ladder
- Ensure spoilage is at least 2 ft. from trench edges
- Provide protection for trenches 5 feet or deeper
 - Shores needed
- A registered professional engineer (RPE) must design protective systems for excavations deeper than 20 feet


Emergency Procedures

- Immediately call 911, or the Emergency Response Team
- Report:
 - Exact Location
 - Number of Victims
 - Nature of Emergency
 - Trench Measurements
 - Special Hazards




Structural Ramps: Access & Egress

- Used only by people
- Designed by a "competent person"
- Egress required every 25 feet
 - (lateral) ≥ 4ft



Trench Safety

- Trenches more than 5 feet deep
 - Require shoring
 - Or must have a stabilized slope
- In hazardous soil conditions
 - Trenches under 5 feet need protection




Hazardous Atmospheres

- Testing and controls
 - Oxygen deficiency
 - Flammable atmospheres
 - Toxicity
- Emergency rescue equipment
 - Availability
 - Lifelines





Hazards

- Adequate precautions must be taken when working in accumulated water
- Controlling water and water removal must be monitored by a competent person
- Ditches, dikes or comparable means should be used to prevent surface water from entering excavations




Weather Factors - Mother Nature

- Don't underestimate the effects weather can have
- Daily (or hourly) site inspections must be made
- Consider protection from:
 - Lightening
 - Flooding
 - Erosion
 - High winds
 - Hot or cold temperatures



Site Inspections


- Daily inspections must be made by a competent person
 - Excavations
 - Adjacent areas
 - Protective systems
- When evidence is found of a hazardous condition, the exposed employees must be immediately removed from the area



Feature identified by Compliance Officer. Excavation area around feature collapsed into trench within minutes of initiating the inspection.

Fall Protection

- Guardrails must be provided for crossing over excavations if the trench is 6 feet or more in depth
- Barriers must be provided for remotely located excavations



Soil Classification System

- Type A Soils
 - Clay
 - Silty Clay
 - Sandy Clay
 - Clay Loam
- Type B Soils
 - Granular Cohesionless Soils (Silt Loam)
- Type C Soils
 - Gravel
 - Sand
 - Loamy Sand

Soil Classification System

- Must be done by a competent person
- Visual test:
 - Check entire worksite
 - Fissured ground
 - Layered soil
 - Disturbed earth
 - Seepage
 - Vibration
 - Poor drainage

Soil Classification System

- Manual test
 - Plasticity
 - Dry strength
 - Thumb penetration
 - Pocket penetrometer
 - Hand operated shear vane
- Warning:
 - One soil inspection and classification may not be enough
 - Outside disturbances during excavation may change even the best soil classification
 - Inspect the soil after any change in conditions

Requirements for Protective Systems

- Each employee must be protected from cave-ins by an adequately designed system
- Exceptions are:
 - Excavation made in stable rock
 - Excavations less than 5 feet
- Protective systems must have the capacity to resist all loads that are expected to be applied to the system

Materials and Equipment


- Must be free from damage or defects that might impair proper function
- Must be used and maintained in a manner that is consistent with the recommendations of the manufacturer
- Must be examined by a competent person if damage occurs

Installation and Removal of Support

- General requirements:
 - Support systems must be securely connected
 - Support systems must be installed and removed in a manner that protects from collapse
 - Support systems must not be subjected to loads exceeding design specifications


Installation and Removal of Support

- General requirements:
 - Additional precautions must be taken to ensure safety before temporary removal begins
 - Removal must begin at the bottom of the excavation
 - Backfilling must progress together with the removal of support systems from excavations




Protect Employees Exposed to Potential Cave-ins

- Slope or bench the sides of the excavation,
- Support the sides of the excavation, or
- Place a shield between the side of the excavation and the work area




Sloping and Benching Systems

- Employees must not be permitted to work:
 - On the faces of sloped or benched excavations
 - At levels above other employees except when employees at the lower levels are adequately protected from the hazard of falling, rolling or sliding material or equipment



Sloping and Benching Systems

- Temporary spoil piles:
 - 2 FEET MINIMUM




Spoils

- Don't place spoils within 2 feet from edge of excavation
- Measure from nearest part of the spoil to the excavation edge
- Place spoils so rainwater runs away from the excavation
- Place spoil well away from the excavation



Sloping and Benching Systems

- Benching general requirements
 - Various slope angles are allowed by OSHA
 - Appendix B to 1926 Subpart P must be consulted
 - Evacuate the excavation if walls show signs of distress
 - If soil conditions change, re-inspect



Sloping and Benching Systems

➤ The angle of repose is the angle of slope of the unsupported loose soil

90 Degrees	53 Degrees Maximum
STABLE ROCK	TYPE A
45 Degrees Maximum	34 Degrees Maximum
TYPE B	TYPE C

Sloping Example Type A Soils

Sloping Example Type B Soils

Sloping Example Type C Soils


Shoring Systems

Shoring

- General
 - Provides a framework to work in
 - Uses wales, cross braces and uprights
 - Supports excavation walls
- OSHA tables provide shoring data
 - Must know soil type
 - Must know depth and width of excavation
 - Must be familiar with the OSHA Tables

Shoring Systems


- Removal
 - Remove shoring from the bottom up
 - Pull sheeting out from above
 - Backfill immediately after removal of support system



The diagram shows a cross-section of a trench. On the left, there is a vertical wall of sheeting. Behind the sheeting are horizontal wales. Vertical jacks or crossbraces connect the wales to the bottom of the trench. The area to the right of the sheeting is filled with soil.

Hydraulic Trench Support


- Using hydraulic jacks the operator can easily drop the system into the hole
- Once in place, hydraulic pressure is increased to keep the forms in place
- Trench pins are installed in case of hydraulic failure



The photograph shows a worker in a red safety vest and hard hat standing on a metal structure, likely part of a hydraulic trench support system. The worker appears to be adjusting or operating the system. The background is dark, suggesting an excavation site.


Shoring Systems

PNEUMATIC/ HYDRAULIC JACKS



Often used due to ease of installation and removal


SCREW JACK



Inexpensive; time consuming to install (top to bottom)

Shield Systems

- General
 - Shield systems must project at least 18 inches above the lowest point where the excavation face begins to slope




The diagram shows a cross-section of an excavation. A grey rectangular shield is positioned above the soil surface. A vertical double-headed arrow indicates the height of the shield above the soil, labeled 'At Least 18 Inches'.

Shield Systems

- General
 - Shield systems must not be subjected to loads exceeding those which the system was designed to withstand
 - Shields must be installed to restrict hazardous movement
 - Employees must be protected from the hazard of cave-ins when entering or exiting the areas protected by shields
 - Employees must not be allowed in shields when shields are being installed, removed, or moved vertically

Shield Systems

- Systems may be connected
- Systems may be stacked
- Configuration must be consistent with the recommendations of the manufacturer
- Must be examined by a competent person if damage occurs



The diagram shows three shield systems connected together. They are arranged in a row, with each shield overlapping the one next to it. The shields are shown in a perspective view, highlighting their interlocking design.

Trench Shield

- A trench shield was built around this work area



Cave-in Hazard



Inadequate protective system

This excavation has inadequate support posts and egress access



Hazardous Conditions

- The weight and vibrations of the crane make this a very hazardous condition
- They should not be working under this crane



Materials and Equipment

- Equipment used for protective systems must not have damage or defects that impair function
- If equipment is damaged, the competent person must examine it to see if it is suitable for continued use
- If not suitable, remove it from service until a professional engineer approves it for use



Protection from Vehicles

- Install barricades
- Hand/mechanical signals
- Stop logs
- Grade soil away from excavation
- Fence or barricade trenches left overnight



Trenching Summary

- Provide stairways, ladders, ramps or other safe means of access in all trenches **4 feet** or deeper
 - These devices must be located within **25 feet** of all workers
 - Ladders used in trenches shall protrude at least **3 feet** above the trench edge
 - Minimum diameter of rungs on a fixed steel ladder is **¾-inch**
 - Minimum clear length of rungs on a fixed steel ladder is **16 inches**

Trenching Summary

- Trenches **5 feet** deep or greater require a protective system, which can be shielding, shoring or sloping
 - A registered engineer must approve all shielding and shoring
- Trenches **20 feet** deep or greater require that the protective system be designed by a registered professional engineer
- Keep excavated soil (spoils) and other materials at least **2 feet** from trench edges
- The support or shield system must extend at least **18 inches** above the top of the vertical side

TOSHA Standards Requiring Annual Training

Class	Regulation	Who should attend?
Medical & Exposure Records	1910.20(g)(1)	All employees (inform-existence, person responsible, location, right of access)
Emergency Action	1910.38(a)(5) 1910.38(b)(4)	All employees – based upon other standards and requirements
Noise	1910.95(k)	All employees exposed to an 8 hour TWA or greater of 85dBA
Emergency Response	1910.120(q)	Employees who respond to spills of hazardous chemicals
Personal Protective Equipment	1910.132(f)	Employees who wear PPE
Permit-Required Confined Space	1910.146(g)	Employees who enter, attend or supervise P.R. confined spaces
Lock-Out/Tag-Out	1910.147(c)(7)	Employees who work on machinery
First Aid	1910.151(b)	At least one employee on each shift, annual as required by other standards
Fire Brigade	1910.156(c)	All fire brigade members (quarterly and annually)
Portable Fire Extinguishers	1910.157(g)	All employees expected to use fire extinguishers
Fork Lift Trucks	1910.178(1)	Fork lift truck operators
Mechanical Power Presses	1910.217(f)(2)	Operators
Asbestos	1910.1001(j)(1)	All employees exposures at or above PEL or excursion limit
Lead	1910.1025(1)	Anyone with a potential for exposure at any level – copy of appendix A&B. If exposed at or above action level, must be trained
Bloodborne Pathogens	1910.1030(g)(2)	Employees who render first aid
Hazard Communication	1910.1200(h) TDL 800-1-9-.07	Employees exposed or potentially exposed to any type of chemicals
Hazardous Chemicals in Laboratories	1910.1450(f)(2)	Employees exposed to chemicals

Sewer Safety Vocabulary

<p>_____ 1. Aerobic</p> <p>_____ 2. Ambient</p> <p>_____ 3. Anaerobic</p> <p>_____ 4. Competent Person</p> <p>_____ 5. Confined Space</p> <p>_____ 6. Confined Space, Non-Permit</p> <p>_____ 7. Confined Space, Permit- Required</p> <p>_____ 8. Decibel</p> <p>_____ 9. Engulfment</p>	<p>_____ 10. Fit Test</p> <p>_____ 11. IDLH</p> <p>_____ 12. Mercaptans</p> <p>_____ 13. Olfactory Fatigue</p> <p>_____ 14. Oxygen Deficiency</p> <p>_____ 15. Oxygen Enrichment</p> <p>_____ 16. Septic</p> <p>_____ 17. Sewer Gas</p> <p>_____ 18. Spoil</p>
--	--

- A. A condition where atmospheric or dissolved molecular oxygen is not present in the aquatic (water) environment.
- B. A unit for expressing the relative intensity of sounds on a scale from zero for the average least perceptible sound to about 130 for the average level where sound causes pain to humans. Abbreviated dB.
- C. A space which is large enough and so configured that an employee can bodily enter and perform assigned work; has limited or restricted means for entry or exit and it not designed for continuous employee occupancy.
- D. Compounds containing sulfur that have an extremely offensive skunk-like odor; also sometimes described as smelling like garlic or onions.
- E. The use of a procedure to qualitatively or quantitatively evaluate the fit of a respirator on an individual.
- F. An atmosphere containing oxygen at a concentration of less than 19.5% by volume.
- G. A condition where atmospheric or dissolved molecular oxygen is present in the aquatic (water) environment.
- H. A condition produced by anaerobic bacteria. If severe, the wastewater produces hydrogen sulfide, turns black, gives off foul odors, contains little or no dissolved oxygen and the wastewater has a high oxygen demand.
- I. Immediately Dangerous to Life or Health. The atmospheric concentration of any toxic, corrosive or asphyxiant substance that poses an immediate threat to life or would cause irreversible or delayed adverse health effects or would interfere with an individual's ability to escape from a dangerous atmosphere.
- J. Gas in collection lines (sewers) that result from the decomposition of organic matter in the wastewater. When testing for gases found in sewers, test for lack of oxygen and also for explosive and toxic gases.
- K. A person capable of identifying existing and predictable hazards in the surroundings, or working conditions that are unsanitary, hazardous or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate the hazards.
- L. Excavated material such as soil from the trench of a sewer.

- M. The surrounding and effective capture of a person by a liquid or finely divided (flowable) solid substance that can be aspirated to cause death by filling or plugging the respiratory system or that can exert enough force on the body to cause death by strangulation, constriction or crushing.
- N. A condition where a person's nose, after exposure to certain odors, is no longer able to detect the odor.
- O. A confined space that does not contain or, with respect to atmospheric hazards, have the potential to contain any hazard capable of causing death or serious physical harm.
- P. An atmosphere containing oxygen at a concentration of more than 23.5% by volume.
- Q. Surrounding. Ambient or surrounding atmosphere.
- R. A confined space that has one or more of the following characteristics: contains or has the potential to contain a hazardous atmosphere; contains a material that has the potential for engulfing an entrant; has an internal configuration such that an entrant could be trapped or asphyxiated by inwardly converging walls or by a floor that slopes downward and tapers to a smaller cross section; or contains any other recognized serious safety or health hazard.

Safety Questions

1. How can traffic be warned of your presence in the street?
2. What is the purpose of the advance warning area?
3. List six types of traffic control devices.
4. How can explosive or flammable atmosphere develop in a collection system?
5. What types of hazardous atmospheres should an atmospheric test unit be able to detect in confined spaces?

6. If operators are scheduled to work in a manhole, when should the atmosphere in the manhole be tested?

7. When a blower is used to ventilate a manhole, where should the blower be located?

8. List the safety equipment recommended for use when operators are required to enter a confined space.

9. What are some early signs that an operator working in a manhole or other confined space is not getting enough oxygen?

10. How can collection system operators be protected from injury by the accidental discharge of stored energy?

11. How can collection system operators protect their hearing from loud noises?

12. How would you extinguish a fire?

Answers to Vocabulary and Questions

Vocabulary:

- | | | | | |
|------|------|-------|-------|-------|
| 1. G | 5. C | 9. M | 13. N | 17. J |
| 2. Q | 6. O | 10. E | 14. F | 18. L |
| 3. A | 7. R | 11. I | 15. P | |
| 4. K | 8. B | 12. D | 16. H | |

Questions:

1. Traffic can be warned of your presence in a street by signs, flags or flashers and vehicles with rotating flashing lights. Vehicle-mounted traffic guides are also helpful. Flaggers can be used to alert drivers and to direct traffic around a work site.
2. The purpose of the advance warning area is to give drivers enough time to see what is happening ahead and adjust their driving patterns.
3. Types of traffic control devices include: signs, barricades, traffic cones, drums, vertical panels, lighting devices, advance warning arrow boards, flashing vehicle lights, high level warning devices and portable changeable message signs. Flaggers may also be used to control traffic.
4. Explosive or flammable atmospheres can develop at any time in the collection system. Flammable gases or vapors may enter a sewer or manhole from a variety of legal, illegal or accidental sources.
5. An atmospheric test unit should be able to detect flammable and explosive gases, toxic gases and oxygen deficiency.
6. If operators are scheduled to work in a manhole, the atmosphere in the manhole should be tested before anyone enters it, preferably before the cover is even removed, and atmospheric testing should continue for the entire time anyone is working in the manhole.
7. The blower used to ventilate a manhole should be located in an area upwind of the manhole and at least 10 feet from the manhole opening. If the blower has a gas-driven engine, the exhaust must be downwind from the manhole. The air intake to the blower should be 2-5 feet above the ground surface, depending on conditions (higher for dusty conditions).
8. SCBA (self-contained breathing apparatus); safety harness with lifeline, tripod and winch; portable atmospheric alarm unit; ventilation blower with hose; manhole enclosure (if entering a manhole); ladder or tripod with winch; ropes and buckets; hard hats; protective clothing; cones and barricades; first-aid kit; soap, water, paper towels and a trash bag
9. The early warning signs that an operator is not getting enough oxygen include: labored breathing (shortness of breath), chest heaving and change from usual responses
10. Operators can be protected from injury due to the accidental discharge of stored energy by following prescribed lockout/ tagout procedures.
11. Collection system operators can protect their hearing from loud noises by use of approved earplugs, earmuffs and/or person protective equipment.
12. To extinguish a fire, first identify the material burning (class or category) and then use the appropriate method to put out the fire.

Section 10

Pumps




Pumps



California State University: Sacramento

Updated 12-2023

Objectives

- Classification of Pumps
- Positive Displacement Pumps
- Velocity Pumps
- Parts of a Centrifugal Pumps
- Pump Operations




Classification of Pumps

Necessity Of Pumps

- Pumps are required when gravity cannot supply water with sufficient pressure to all parts of the distribution system
- Pumps account for the largest energy cost for a water supply operation

Types of Pumps

- Velocity Pumps
 
- Positive-Displacement Pumps
 


Types of Pumps


- Positive-Displacement Pumps
 - Metering pumps
 - sometimes used to feed chemicals
 - Piston pump
 - Screw pump
- Velocity Pumps
 - Vertical turbine
 - Centrifugal

Positive Displacement Pumps



Positive-Displacement Pumps

- Chemical feed pumps
- Delivers a constant volume with each stroke
- Less efficient than centrifugal pumps
- **Cannot operate against a closed discharge valve**
- Types: piston, diaphragm, gear, or screw pump




Positive-Displacement Pumps

- Metering pumps – most common type of solution feeder
- Delivers precise volume of solution with each stroke or rotation
- Typically have variable-speed motor that can be adjusted to control chemical flow


Reciprocating Pump

- aka Piston Pump
- Piston moves back and forth in a cylinder; liquid enters and leaves through check valves




Rotary Pumps

- Uses lobes or gears to move liquid through pump



Peristaltic Pumps


- Fluid to be pumped flows through flexible tube inside a pump casing
- Rotor inside turns and compresses the tube
- Rotor forces fluid through tube




Screw Pumps

- aka progressive cavity pumps
- Screw pumps are used to lift wastewater to a higher elevation
- This pump consists of a screw operating at a constant speed within a housing or trough
- The screw has a pitch and is set at a specific angle
- When revolving, it carries wastewater up the trough to a discharge point



Incline screw pumps handle large solids without plugging



Positive-Displacement Pumps




Velocity Pumps


Velocity Pumps

- Centrifugal (Volute) Pumps
 - Spinning impeller or propeller accelerates water to high velocity in pump casing (or volute)
 - High velocity, low pressure water converted to high pressure, low velocity water
- Turbine Pumps
 - Velocity head is converted to pressure head by diffuser guide vanes




Velocity Pump Design Characteristics

- Axial - flow designs
 - Propeller shaped impeller adds head by lifting action on vanes
 - Water moves parallel to pump instead of being thrown outward
 - High volume, but limited head
 - Not self-priming




Velocity Pump Design Characteristics

- Radial flow designs
 - Water comes in through center (eye) of impeller
 - Water thrown outward from impeller to diffusers that convert velocity to pressure
 - The discharge is perpendicular to the pump shaft
 - Centrifugal or Turbine



Velocity Pump Design Characteristics

- Mixed - flow designs
 - Has features of axial and radial flow
 - Works well for water with solids



Centrifugal Pump


- Basically, a very simple device: an impeller rotating in a casing
- The impeller is supported on a shaft, which in turn, is supported by bearings
- Liquid coming in at the center (eye) of the impeller is picked up by the vanes and by the rotation of the impeller and then is thrown out by centrifugal force into the discharge

Centrifugal Pumps

- Volute-casing type most commonly used in water utilities
- Impeller rotates in casing - radial flow
- Single or multi-stage
- By varying size, shape, and width of impeller, a wide range of flows and pressures can be achieved

Advantages of Centrifugal Pumps

- Wide range of capacities
- Uniform flow at a constant speed and head
- Low cost
- Ability to be adapted to various types of drivers
- Moderate to high efficiency
- No need for internal lubrication if pumping clean water



Disadvantages of Centrifugal Pumps

- Efficiency is limited to very narrow ranges of flow and head
- Flow capacity greatly depends on discharge pressure
- Generally, no self-priming ability
- Can run backwards if check valve fails and sticks open
- Potential impeller damage if pumping abrasive water

Parts of a Centrifugal Pump




Let's Build a Centrifugal Pump

- First, we need a device to spin liquid at high speeds – an impeller
 - As the impeller spins, liquid between the blades is impelled outward by centrifugal force
 - As liquid in the impeller moves outward, it will suck more liquid behind it through this eye

#1: If there is any danger that foreign material may be sucked into the pump, clogging or wearing of the impeller unduly, provide the intake end of the suction piping with a suitable screen

Impeller

- Bronze or stainless steel
- Closed; some single-suction have semi-open; open designs
- Inspect regularly
- As the impeller wears on a pump, the pump efficiency will decrease




Let's Build a Centrifugal Pump

- Now we need a shaft to support and turn the impeller
 - It must maintain the impeller in precisely the right place
 - But that ruggedness does not protect the shaft from the corrosive or abrasive effects of the liquid pumped, so we must protect it with sleeves slid on from either end

#2: Never pump a liquid for which the pump was not designed

Pump Shaft and Shaft Sleeves

- Pump Shaft
 - Connects impeller to pump; steel or stainless steel
 - Should be repaired/replaced if grooves or scores appear on the shaft
- Shaft Sleeves
 - Protect shaft from wear from packing rings
 - Generally, they are bronze, but various other alloys, ceramics, glass or even rubber-coating are sometimes required



Let's Build a Centrifugal Pump

- We mount the shaft on sleeve, ball or roller bearings
 - If bearings supporting the turning shaft and impeller are allowed to wear excessively and lower the turning units within a pump's closely fitted mechanism, the life and efficiency of that pump will be seriously threatened

#3: Keep the right amount of the right lubricant in bearings at all times.

Bearings

- Anti-friction devices for supporting and guiding pump and motor shafts
- Get noisy as they wear out
- If pump bearings are over lubricated, the bearings will overheat and can be damaged or fail
 - Tiny indentations high on the shoulder of a bearing or race is called brinelling
 - When greasing a bearing on an electric motor, the relief plug should be removed and replaced after the motor has run for a few minutes. This prevents you from damaging the seals of the bearing
- Types: ball, roller, sleeve

Let's Build a Centrifugal Pump

- To connect with the motor, we add a coupling flange
 - Our pump is driven by a separate motor, and we attach a flange to one end of the shaft through which bolts will connect with the motor flange
 - If shafts are met at an angle, every rotation throws tremendous extra load on bearings of both pump and the motor


#4: See that pump and motor flanges are parallel and vertical and that they stay that way.

Couplings

- Connect pump and motor shafts
- Lubricated require greasing at 6-month intervals
- Dry has rubber or elastomeric membrane
- Calipers and thickness gauges can be used to check alignment on flexible couplings


Misalignment of Pump & Motor

- Excessive bearing loading
- Shaft bending
- Premature bearing failure
- Shaft damage
- Checking alignment should be a regular procedure in pump maintenance.
 - Foundations can settle unevenly
 - Piping can change pump position
 - Bolts can loosen
 - Misalignment is a major cause of pump and coupling wear



Common Pump & Motor Connections

- Close-coupled
- Frame mounted
 - Direct coupling
 - Angle drive
 - Belt or chain
 - Flexible coupling



Let's Build a Centrifugal Pump


- Now we need a "straw" through which liquid can be sucked
 - The horizontal pipe slopes upward toward the pump so that air pockets won't be drawn into the pump and cause loss of suction

#5: Any down-sloping toward the pump in suction piping should be corrected



Let's Build a Centrifugal Pump

- We contain and direct the spinning liquid with a casing
 - Designed to minimize friction loss as water is thrown outward from impeller
 - Usually made of cast iron, spiral shape



#6: See that piping puts absolutely no strain on the pump casing.

Mechanical Details of Centrifugal Pumps

- **Casing**
 - Housing surrounding the impeller; also called the volute
 - Designed to minimize friction loss as water is thrown outward from impeller
 - Usually made of cast iron, spiral shape


Let's Build a Centrifugal Pump

- Now our pump is almost complete, but it would leak like a sieve
 - As water is drawn into the spinning impeller, centrifugal force causes it to flow outward, building up high pressure at the outside of the pump (which will force water out) and creating low pressure at the center of the pump (which will draw water in)
 - Water tends to be drawn back from pressure to suction through the space between the impeller and casing – this needs to be plugged

Let's Build a Centrifugal Pump

- So, we add wear rings to plug internal liquid leakage
 - Wear rings fill the gaps without having to move the parts of the pump closer together

#7: Never allow a pump to run dry. Water is a lubricant between the rings and impeller.



Wear Rings

- Restrict flow between impeller discharge and suction
- Leakage reduces pump efficiency
- Installed to protect the impeller and pump casing from excessive wear
- Provides a replaceable wearing surface
- Inspect regularly

#8: Examine wearing rings at regular intervals. When seriously worn, their replacement with greatly improve pump efficiency.

Let's Build a Centrifugal Pump

- To keep air from being drawn in, we use stuffing boxes
 - We have two good reasons for wanting to keep air out of our pump
 - We want to pump water, not air
 - Air leakage is apt to cause our pump to lose suction
 - Each stuffing box we use consists of a casing, rings of packing, seal cage and a gland at the outside end
 - A mechanical seal may be used instead

Packing Rings

- Asbestos or metal ring lubricated with Teflon or graphite
- Provides a seal where the shaft passes through the pump casing in order to keep air from being drawn or sucked into the pump and/or the water being pumped from coming out

Packing Rings


- If new packing leaks, stop the motor and repack the pump
- Pumps need new packing when the gland or follower is pulled all the way down
- The packing around the shaft should be tightened slowly, over a period of several hours to just enough to allow an occasional drop of liquid
 - Leakage acts as a lubricant
- Stagger packing joints
 - 180° if only 2 rings are in stuffing box
 - 120° for 3 rings
 - 90° if 4 rings or more are in set

Packing Rings

- If packing is not maintained properly, the following troubles can arise:
 - **Loss of suction** due to air being allowed to enter pump
 - **Shaft or shaft sleeve damage**
 - Water or wastewater **contaminating bearings**
 - **Flooding** of pump station
 - Rust corrosion and unsightliness of pump and area

Lantern Rings (aka Seal Cage)

- Perforated ring placed in stuffing box
- A spacer ring in the packing gland that forms seal around shaft, helps keep air from entering the pump and lubricates packing



Stuffing Box

#9 – Packing should be replaced periodically. Forcing in a ring or two of new packing instead of replacing worn packing is bad practice. It is apt to dislodge the seal cage.

#10 – Never tighten a gland more than necessary as excessive pressure will wear shaft sleeves unduly.

#11 – If shaft sleeves are badly scored, replace them immediately.

Let's Build a Centrifugal Pump

- To make packing more airtight, we add water seal piping
 - In the center of each stuffing box is a "seal cage"
 - This liquid acts both to block out air intake and to lubricate the packing
 - To control liquid flow, draw up the packing gland just tight enough to **allow approximately one drop every 2-3 seconds** flow from the box

#12 – If the liquid being pumped contains grit, a separate source of sealing liquid should be obtained.

Mechanical Seals



- Located in stuffing box
- Prevents water from leaking along shaft; keeps air out of pump
- **Should not leak**
- Consists of a rotating ring and stationary element
- **The operating temperature on a mechanical seal should never exceed 160°F (71°C)**
- Mechanical seals are always flushed in some manner to lubricate the seal faces and minimize wear
 - The flushing water pressure in a water-lubricated wastewater pump should be **3-5 psi higher** than the pump discharge pressure

Mechanical Seals


- Required instead of packing rings for suction head greater than 60 psi
- Prevents water from leaking along shaft, keeps air out of pump
 - Should not leak any water

Packing vs. Mechanical Seals

- If a pump has packing, water should drip slowly
- If it has a mechanical seal, no leakage should occur




Packing Rings vs. Mechanical Seal

- | | |
|---|--|
| <p>➤ Advantages</p> <ul style="list-style-type: none"> ➤ Less expensive, short term ➤ Can accommodate some looseness | <p>➤ Disadvantages</p> <ul style="list-style-type: none"> ➤ Increased wear on shaft or shaft sleeve ➤ Increased labor required for adjustment and replacement |
|---|--|



Mechanical Seal vs. Packing Rings

- | | |
|---|--|
| <p>➤ Advantages</p> <ul style="list-style-type: none"> ➤ Last 3-4 years, which can be a savings in labor ➤ Usually there is no damage to shaft sleeve ➤ Continual adjusting, cleaning or repacking is not required ➤ Possibility of flooding lift station because a pump has thrown its packing is eliminated; however mechanical seals can fail, and lift stations can be flooded | <p>➤ Disadvantages</p> <ul style="list-style-type: none"> ➤ High initial cost ➤ Great skill and care needed to replace ➤ When they fail, the pump must be shut down ➤ Pump must be dismantled to repair |
|---|--|



Centrifugal Pump Components

saVRec

**CENTRIFUGAL
PUMP
COMPONENTS
EXPLAINED**



Centrifugal Pump Basics

Centrifugal Pump Basics



Pump Operations



Centrifugal Pump Operation

- Pump Starting -
 - Impeller must be submerged for a pump to start
 - Should never be run empty, except momentarily, because parts lubricated by water would be damaged
 - Foot valve helps hold prime
 - Discharge valve should open slowly to control water hammer
 - In small pumps, a check valve closes immediately when pump stops to prevent flow reversal
 - In large pumps, discharge valve may close before pump stops

Centrifugal Pump Operation

- Pump shut down for extended period of time -
 - Close the valve in the suction line
 - Close the valve in the discharge line
 - Drain the pump casing

Flow Control

- Flow usually controlled by starting and stopping pumps
- Throttling flow should be avoided - wastes energy
- Variable speed drives or motor are best way to vary flow
 - Variable speed pumping equipment can be adjusted to match the inflow rate

Monitoring Operational Variables

- Pump and motor should be tested, and complete test results recorded as a baseline for the measurement of performance within the first 30 days of operation

Monitoring Operational Variables

- Suction and Discharge Heads
 - Pressure gauges
- Bearing and Motor Temperature
 - Temp indicators can shut down pump if temp gets too high
 - Check temp of pump by feel
 - Do not touch a hot motor!

Monitoring Operational Variables

- Vibration
 - Detectors can sense malfunctions causing excess vibration
 - Operators can learn to distinguish between normal and abnormal sounds



Monitoring Operational Variables

- Likely causes of vibration
 - Bad bearings or bearing failure
 - Imbalance of rotating elements, damage to impeller
 - Misalignment from shifts in underlying foundation
 - Improper motor to pump alignment

Monitoring Operational Variables



- Speed
 - Cavitation can occur at low and high speeds
 - Creation of vapor bubbles due to partial vacuum created by incomplete filling of the pump

Monitoring Operational Variables

- Cavitation is a noise coming from a centrifugal pump that sounds like marbles trapped in the volute
- A condition where small bubbles of vapor form and explode against the impeller, causing a pinging sound
- Best method to prevent it from occurring is to reduce the suction lift

Suction Cavitation

- Suction Cavitation occurs when the pump suction is under a low pressure/high vacuum condition where the liquid turns into a vapor at the eye of the pump impeller
- This vapor is carried over to the discharge side of the pump where it no longer sees vacuum and is compressed back into a liquid by the discharge pressure
- This imploding action occurs violently and attacks the face of the impeller
- An impeller that has been operating under a suction cavitation condition has large chunks of material removed from its face causing premature failure of the pump

Discharge Cavitation

- Discharge Cavitation occurs when the pump discharge is extremely high
- It normally occurs in a pump that is running at less than 10% of its best efficiency point
- The high discharge pressure causes the majority of the fluid to circulate inside the pump instead of being allowed to flow out the discharge
- As the liquid flows around the impeller, it must pass through the small clearance between the impeller and the pump cutwater at extremely high velocity

Discharge Cavitation

- This velocity causes a vacuum to develop at the cutwater similar to what occurs in a venturi and turns the liquid into a vapor
- A pump that has been operating under these conditions shows premature wear of the impeller vane tips and the pump cutwater
- In addition, due to the high-pressure condition, premature failure of the pump mechanical seal and bearings can be expected and under extreme conditions will break the impeller shaft

Inspection and Maintenance

- Inspection and maintenance prolongs life of pumps
 - Checking operating temperature of bearings
 - Checking packing glands
 - Operating two or more pumps of the same size alternatively to equalize wear
 - Check parallel and angular alignment of the coupling on the pump and motor
 - A feeler gauge, dial indicator calipers are tools that can be used to check proper alignment
- Necessary for warranty
- Keep records of all maintenance on each pump
- Keep log of operating hours


Inspection: Impellers

- Wear on impeller and volute
- Cavitation marks
- Chips, broken tips, corrosion, unusual wear
- Tightness on shaft
- Clearances
- Tears or bubbles (if rubber coated)



Pump Won't Start?

- Incorrect power supply
- No power supply
- Incorrectly connected
- Fuse out, loose or open connection
- Rotating parts of motor jammed mechanically
- Internal circuitry open



Pump Safety

- Machinery should always be turned off and locked out/tagged out before any work is performed on it
- Make sure all moving parts are free to move and all guards in place before restarting
- Machinery creating excessive noise shall be equipped with mufflers



Pump Safety: Meter Vaults & Manholes

- Confined spaces
- Corrosion of ladder rungs
- Explosive atmospheres
- Hydrogen sulfide accumulation
- Slippery surfaces



Pump and Motor Facts

Pump Facts

High-service pump – discharges water under pressure to the distribution system.

Booster pump – used to increase pressure in the distribution system and to fill elevated storage tanks.

Impeller or centrifugal pump used to move water.

Likely causes of vibration in an existing pump/motor installation:

1. bad bearings
2. imbalance of rotating elements
3. misalignment from shifts in underlying foundation

Pump and motor should be tested and complete test results recorded as a baseline for the measurement of performance within the first 30 days of operations.

Calipers and thickness gauges can be used to check alignment on flexible couplings.

Packing/Seals Facts

If new packing leaks, stop the motor and repack the pump.

Pumps need new packing when the gland or follower is pulled all the way down.

The packing around the shaft should be tightened just enough to allow an occasional drop of liquid for cooling.

Joints of packing should be staggered at least 90°.

Mechanical seals consist of a rotating ring and stationary element.

The operating temperature on a mechanical seal should never exceed 160°F or 71°C.

Motor Facts

Motors pull the most current on start up.

In order to prevent damage, turn the circuit off immediately if the fuse on one of the legs of a three-phase circuit blows.

An electric motor changes electrical energy into mechanical energy.

Power factors on motors can be improved by:

1. changing the motor loading
2. changing the motor type
3. using capacitors

Routing cleaning of pump motors includes:

1. checking alignment and balance
2. checking brushes
3. removing dirt and moisture
4. removal of obstructions that prevent air circulation

Cool air extends the useful life of motors.

A motor (electrical or internal combustion) used to drive a pump is called a prime mover.

The speed at which the magnetic field rotates is called the motor synchronous speed and is expressed in rpm.

If a variable speed belt drive is not to be used for 30 days or more, shift the unit to minimum speed setting.

Emory cloth should not be used on electric motor components because it is electrically conductive and may contaminate parts.

Ohmmeters used to test a fuse in a motor starter circuit.

The most likely cause of a three-phase motor not coming to speed after starting – the motor has lost power to one or more phases.

Transformer Facts

Transformers are used to convert high voltage to low voltage.

High voltage is 440 volts or higher.

Standby engines should be run weekly to ensure that it is working properly.

Relays are used to protect electric motors.

Pump Vocabulary

1. Axial-Flow Pump – a pump in which a propeller-like impeller forces water out in the direction parallel to the shaft. Also called a propeller pump.
2. Bearing – anti-friction device used to support and guide a pump and motor shafts.
3. Casing – the enclosure surrounding a pump impeller, into which the suction and discharge ports are machined.
4. Cavitation – a condition that can occur when pumps are run too fast or water is forced to change direction quickly. A partial vacuum forms near the pipe wall or impeller blade causing potentially rapid pitting of the metal.
5. Centrifugal Pumps – a pump consisting of an impeller on a rotating shaft enclosed by a casing having suction and discharge connections. The spinning impeller throws water outward at high velocity, and the casing shape converts this velocity to pressure.
6. Closed-Coupled Pump – a pump assembly where the impeller is mounted on the shaft of the motor that drives the pump.
7. Diffuser Vanes – vanes installed within a pump casing on diffuser centrifugal pumps to change velocity head to pressure head.
8. Double-Suction Pump – a centrifugal pump in which the water enters from both sides of the impeller. Also called a split-case pump.
9. Foot Valve – a check valve placed in the bottom of the suction pipe of a pump, which opens to allow water to enter the suction pipe but closes to prevent water from passing out of it at the bottom end. Keeps prime.
10. Frame-Mounted Pump – a centrifugal pump in which the pump shaft is connected to the motor shaft with a coupling.
11. Impeller – the rotating set of vanes that forces water through the pump.
12. Jet Pump – a device that pumps fluid by converting the energy of a high-pressure fluid into that of a high-velocity fluid.
13. Lantern Ring – a perforated ring placed around the pump shaft in the stuffing box. Water from the pump discharge is piped to this ring. The water forms a liquid seal around the shaft and lubricates the packing.
14. Mechanical Seal – a seal placed on the pump shaft to prevent water from leaking from the pump along the shaft; the seal also prevents air from entering the pump.
15. Mixed-Flow Pump – a pump that imparts both radial and axial flow to the water.
16. Packing – rings of graphite-impregnated cotton, flax, or synthetic materials, used to control leakage along a valve stem or a pump shaft.
17. Packing Gland – a follower ring that compressed the packing in the stuffing box.
18. Positive Displacement Pump – a pump that delivers a precise volume of liquid for each stroke of the piston or rotation of the shaft.

19. Prime Mover – a source of power, such as an internal combustion engine or an electric motor, designed to supply force and motion to drive machinery, such as a pump.
20. Radial-Flow Pump – a pump that moves water by centrifugal force, spinning the water radially outward from the center of the impeller.
21. Reciprocating Pump – a type of positive-displacement pump consisting of a closed cylinder containing a piston or plunger to draw liquid into the cylinder through an inlet valve and forces it out through an outlet valve.
22. Rotary Pump – a type of positive-displacement pump consisting of elements resembling gears that rotate in a close-fitting pump case. The rotation of these elements alternately draws in and discharges the water being pumped.
23. Single-Suction Pump – a centrifugal pump in which the water enters from only one side of the impeller. Also called an end-suction pump.
24. Stuffing Box – a portion of the pump casing through which the shaft extends and in which packing or a mechanical seal is placed to prevent leakage.
25. Submersible Pump – a vertical-turbine pump with the motor placed below the impellers. The motor is designed to be submersed in water.
26. Suction Lift – the condition existing when the source of water supply is below the centerline of the pump.
27. Velocity Pump – the general class of pumps that use a rapidly turning impeller to impart kinetic energy or velocity to fluids. The pump casing then converts this velocity head, in part, to pressure head. Also known as kinetic pumps.
28. Vertical Turbine Pump – a centrifugal pump, commonly of the multistage, diffuser type, in which the pump shaft is mounted vertically.
29. Volute – the expanding section of pump casing (in a volute centrifugal pump), which converts velocity head to pressure head..
30. Water Hammer – the potentially damaging slam that occurs in a pipe when a sudden change in water velocity (usually as a result of too-rapidly starting a pump or operating a valve) creates a great increase in water pressure.
31. Wear Rings – rings made of brass or bronze placed on the impeller and/or casing of a centrifugal pump to control the amount of water that is allowed to leak from the discharge to the suction side of the pump.

Pump and Motor Review Questions

1. Leakage of water around the packing on a centrifugal pump is important because it acts as a (n):
 - a. Adhesive
 - b. Lubricant
 - c. Absorbent
 - d. Backflow preventer

2. What is the purpose of wear rings in a pump?
 - a. Hold the shaft in place
 - b. Hold the impeller in place
 - c. Control amount of water leaking from discharge to suction side
 - d. Prevent oil from getting into the casing of the pump

3. Which of the following does a lantern ring accomplish?
 - a. Lubricates the packing
 - b. Helps keep air from entering the pump
 - c. Both (a.) and (b.)

4. Closed, open and semi-open are types of what pump part?
 - a. Impeller
 - b. Shaft sleeve
 - c. Casing
 - d. Coupling

5. When tightening the packing on a centrifugal pump, which of the following applies?
 - a. Tighten hand tight, never use a wrench
 - b. Tighten to 20 foot pounds of pressure
 - c. Tighten slowly, over a period of several hours
 - d. Tighten until no leakage can be seen from the shaft

6. Excessive vibrations in a pump can be caused by:
 - a. Bearing failure
 - b. Damage to the impeller
 - c. Misalignment of the pump shaft and motor
 - d. All of the above

7. What component can be installed on a pump to hold the prime?
 - a. Toe valve
 - b. Foot valve
 - c. Prime valve
 - d. Casing valve

8. The operating temperature of a mechanical seal should not exceed:
 - a. 60°C
 - b. 150°F
 - c. 160°F
 - d. 71°C
 - e. c and d

9. What is the term for the condition where small bubbles of vapor form and explode against the impeller, causing a pinging sound?
 - a. Corrosion
 - b. Cavitation
 - c. Aeration
 - d. Combustion

10. The first thing that should be done before any work is begun on a pump or electrical motor is:
 - a. Notify the state
 - b. Put on safety goggles
 - c. Lock out the power source and tag it
 - d. Have a competent person to supervise the work

11. Under what operating condition do electric motors pull the most current?
 - a. At start up
 - b. At full operating speed
 - c. At shut down
 - d. When locked out

12. As the impeller on a pump becomes worn, the pump efficiency will:
 - a. Decrease
 - b. Increase
 - c. Stay the same

13. How do the two basic parts of a velocity pump operate?

14. What are two designs used to change high velocity to high pressure in a pump?

15. In what type of pump are centrifugal force and the lifting action of the impeller vanes combined to develop the total dynamic head?

16. Identify one unique safety advantage that velocity pumps have over positive-displacement pumps.

17. What is the multistage centrifugal pump? What effects does the design have on discharge pressure and flow volume?

18. What are two types of vertical turbine pump, as distinguished by pump and motor arrangement, which are commonly used to pump ground water from wells?

19. What type of vertical turbine pump is commonly used as an inline booster pump?

20. Describe the two main parts of a jet pump.

21. What is the most common used of positive-displacement pumps in water plants today?

22. What is the purpose of the foot valve on a centrifugal pump?

23. How is the casing of a double-suction pump disassembled?

24. What is the function of wear rings in centrifugal pumps of the closed-impeller design?
What is the function of the lantern rings?

25. Describe the two common types of seals used to control leakage between the pump shaft and the casing.

26. What feature distinguishes a close-coupled pump and motor?

27. What is the value of listening to a pump or laying a hand on the unit as it operates?

28. Define the term "racking" as applied to pump and motor control.

29. When do most electric motors take the most current?

30. What are three major ways of reducing power costs where electric motors are used?

31. What effect could over lubrication of motor bearings have?
32. Why should emery cloth not be used around electrical machines?
33. What are the most likely causes of vibration in an existing pump installation?
34. What can happen when a fuse blows on a single leg of a three-phase circuit?
35. Name at least three common fuels for internal-combustion engines.
36. List the type of information that should be recorded on a basic data card for pumping equipment.
37. What is the first rule of safety when repairing electrical devices?

Answers:

- | | | | |
|------|------|------|-------|
| 1. B | 4. A | 7. B | 10. C |
| 2. C | 5. C | 8. E | 11. A |
| 3. C | 6. D | 9. B | 12. A |
13. A spinning impeller accelerates water to a high velocity within a casing, which changes the high-velocity, low-pressure water to a low-velocity, high-pressure discharge.
 14. Volute casing and diffuser vanes.
 15. Mixed-flow pump (the design used for most vertical turbine pumps)

16. If a valve is closed in the discharge line, the pump impeller can continue to rotate for a time without pumping water or damaging the pump.
17. A multistage centrifugal pump is made up of a series of impellers and casings (housings) arranged in layers, or stages. This increases the pressure at the discharge outlet, but does not increase flow volume.
18. Shaft-type and submersible-type vertical turbines.
19. A close-coupled vertical turbine with an integral sump or pot.
20. The jet pump consists of a centrifugal pump at the ground surface and an ejector nozzle below the water level.
21. Positive-displacement pumps are generally used in water plants to feed chemical into the water supply.
22. The foot valve prevents water from draining when the pump is stopped, so the pump will be primed when restarted.
23. The bolts holding the two halves of the casing together are removed and the top half is lifted off.
24. Wear rings prevent excessive circulation of water between the impeller discharge and suction area. Lantern rings allow sealing water to be fed into the stuffing box.
25. (1) Packing rings are made of graphite-impregnated cotton, flax, or synthetic materials. They are inserted in the stuffing box and held snugly against the shaft by an adjustable packing gland. (2) Mechanical seals consist of two machined and polished surfaces. One is attached to the shaft, the other to the casing. Spring pressure maintains contact between the two surfaces.
26. The pump impeller is mounted directly on the shaft of the motor.
27. An experienced operator can often detect unusual vibration by simply listening or touching. Vibration, especially changes in vibration level, are viewed as symptoms or indicators of other underlying problems in foundation, alignment and/or pump wear.
28. Racking refers to erratic operation that may result from pressure surges when the pump starts; it is often a problem when the pressure sensor for the pump control is located too close to the pump station.
29. During start-up.
30. (1) Increase system efficiency; (2) spread the pumping load more evenly throughout the day; (3) reduce power-factor charges
31. The bearings may run hot, and excess grease or oil could run out and reach the motor windings, causing the insulation to deteriorate.
32. The abrasive material on emery cloth is electrically conductive and could contaminate electrical components.
33. Imbalance of the rotating elements, bad bearings and misalignment
34. A condition called single-phasing can occur, causing the motor windings to overheat and eventually fail.
35. gasoline, propane, methane, natural gas and diesel oil (diesel fuel)
36. make, model, capacity, type, date and location installed, and other information for both the driver (motor) and the driven unit (pump)
37. Make sure the power to the device is disconnected. This is critical since rubber gloves, insulated tools and other protective gear are not guarantees against electrical shock.

Section 11
Equipment Maintenance



Maintenance

- California State University, Sacramento
- Operation and Maintenance of Wastewater Collection Systems Vol. II

System Maintenance

- A good maintenance program is a must in order to maintain successful operation of a water plant
- Should include everything from mechanical equipment to the care of the plant grounds, buildings and structures
- Mechanical maintenance is of prime importance as the equipment must be kept in good operating condition in order for the plant to maintain peak performance

Preventive Maintenance Records

- Preventive maintenance programs keep equipment in good working condition and correct small malfunctions before they turn into big problems
- A good record keeping system tells when maintenance is due and shows equipment performance
- Equipment service cards and service record cards should be filled out for each piece of equipment in the plant

Equipment Service Card

- Tells what should be done and when
- Should include equipment name
 - e.g. raw pump No. 1
- List each required maintenance service with an item number
- List maintenance services in order of frequency of performance
- Describe each type of service under work to be done

EQUIPMENT SERVICE CARD

Equipment: #1 Raw Pump

Item No.	Work to be done	Frequency	Time
1	Check water seal and packing gland	Daily	
2	Listen for unusual noises	Daily	
3	Operate pump alternately	Weekly	Monday
4	Inspect pump assembly	Weekly	Wednesday
5	Inspect and lube bearings	Quarterly	1, 4, 7, 10
6	Check operating temperature of bearings	Quarterly	1, 4, 7, 10
7	Check alignment of pump and motor	Semi-annually	4, 10
8	Inspect and service pump	Semi-annually	4, 10
9	Drain pump before shutdown		

Service Record Card

- Tells what was done and when it was done
- Should have date and work done, listed by item number and signed by the operator who performed the service


SERVICE RECORD CARD					
Equipment: #1 Raw Pump					
Date	Work Done (Item No.)	Signed	Date	Work Done (Item No.)	Signed
1-6-23	1-2-3	J.D.			
1-7-23	1-2	J.D.			
1-8-23	1-2-4-5-6	P. K.			

Electrical Equipment






Beware of Electricity

- Do not attempt to install, troubleshoot, maintain, repair, or replace electrical equipment, panels, controls, wiring, or circuits unless
 - You know what you are doing
 - You are qualified
 - You are authorized



Fundamentals of Electricity





Volts


- Also known as electromotive force (EMF)
- The electrical pressure available to cause a flow of current (amperage) when a circuit is closed
- Voltage (E) is the force that is necessary to push electricity or electric current through a wire
- Two types:
 - Direct current (DC)
 - Alternating current (AC)

Direct Current (DC)

- Flow in one direction and is essentially free from pulsation
- Used exclusively in automotive equipment, certain types of welding equipment, and a variety of portable equipment
- Found in various voltages
 - 6, 12, 24, 48, and 110 volts
- All batteries are DC




DIRECT CURRENT (DC)




Alternating Current (AC)

- Voltage and current periodically change direction and amplitude
- Current goes from zero to maximum strength, back to zero, and to the same strength in the opposite direction
- Hertz describes the frequency of cycles completed per second
- Classified as
 - Single phase
 - Two phase
 - Three phase or polyphase




Alternating Current – Single Phase

- Found in lighting systems, small pump motors, various portable tools, and throughout homes
- Usually 120 volts and sometimes 240 volts
- Only one phase of power is supplied to the main electrical panel




Alternating Current – Three Phase

- Generally used with motors and transformers
- Usually is 208, 220, 240 volts, or 440, 460, 480, and 550 volts
- Used when high-power requirements or larger motors are used
- Efficiency is higher and less maintenance is required
- Generally, all motors with > 2 HP are three phase



Alternating Current – Circuit Breakers

- Used to protect electric circuits from overloads
- Metal conductors that de-energize the main circuit is overheated by too much current passing through



Amps


- The measurement of current or electron flow and is an indication of work being done or “how hard the electricity is working”
- The practical unit of electrical current

Watts (W) and Kilowatts(kW)


- The units of measurement of the rate at which power is being used or generated
- In DC circuits, watts equal the voltage times the current
Watts = (volts)(amps)
- In AC polyphase circuits, you have to include the power factor and the $\sqrt{3}$
Watts = (volts)(amps)(power factor)(1.73)
- Power factor is the ratio of actual power passing through a circuit to the apparent power
 - Usually somewhere near 0.9

Conductors and Insulators

- Conductor - a material that allows the flow of electric current e.g. copper
- Insulator - a material that will not allow the flow of electricity e.g. rubber
 - Insulation commonly used to prevent the loss of electrical flow by two conductors coming into contact with each other



Electricity Simplified




Quantity	Symbol	Unit of Measurement	Unit Abbreviation
Current	I	Ampere (Amp)	A
Voltage	V or E	Volt	V
Resistance	R	Ohm	Ω

Tools, Meters and Testers




Voltage Testing

- Multimeter used for checking voltage
- Use meter that has sufficient range to measure voltage you would expect to find
- Tells if AC or DC and intensity or voltage
- Used to test for open circuits, blown fuses, single phasing of motors, grounds, etc.




Ammeter

- Records the current or “amps” flowing in the circuit
- Two common types:
 - Clamp-on type – used for testing
 - Clamped around a wire supplying a motor
 - In-line type – installed in a panel or piece of equipment
 - Connected in line with the power lead or leads



Megger

- Used for checking the insulation resistance on motors, feeders, bus bar systems, grounds, and branch circuit wiring
- Connected to a motor terminal at the starter
- Test results show if the insulation is deteriorating or cut
- Three types
 - Crank operated
 - Battery operated
 - Instrument



Ohmmeters

- Used to measure the resistance in a circuit
- Also called circuit testers
- Electrical circuit must be OFF to use ohmmeter
- Ohmmeter supplies own power



Equipment Protective Devices



Fuses


- A protective device having a strip or wire of fusible metal that will melt and break the electrical circuit when subjected to excessive temperature
- Common types:
 - Current-limiting fuses – used to protect power distribution circuits
 - Dual-element fuses – used for motor protection circuits
- Be sure to replace fuses with proper size and type indicated for that circuit

Fuses




Circuit Breakers

- A protective device consisting of a switch that opens automatically when the current of the voltage exceeds or falls below a certain limit
- Can be reset unlike a fuse
- Can be visually inspected to find out if it has been tripped





Overload Relays

- Heater strips open on current rise (overheating) and open the control circuit
 - This opens the power control circuit which de-energizes the start and stops power to the motor
- Also known as heaters or “thermal overloads”
- Range from 100-110% of the motor nameplate ratings
- Should never exceed 125% of the motor rating
- Never increase the rating of the overload relay
 - Find the problem that is causing it to trip and repair it
- Ground – an electrical connection to earth or a large conductor that is at the earth’s potential or neutral voltage




Auxiliary Electrical Power

- Standby power generation – three types
 - Engine driven generator
 - Batteries
 - Alternate power source
- Emergency lighting
- Batteries

Compressors

- A device used to increase the pressure of air or gas
- Consists of a suction pipe with a filter and a discharge pipe that connects to an air receiver



- Can be simple diaphragm type or complex rotary, piston, or sliding vane type

Compressor Maintenance

- Inspect the suction filter of the compressor monthly
 - Clean or replace filter every 3-6 months
- Lubrication must be inspected daily
 - Oil should be replaced every 3 months
- Cylinder or casing fins should be cleaned weekly
- Inspect unloader
 - If not working properly, compressor will not start, stall, or burn off belts if belt driven
- Test the safety valves weekly

Compressor Maintenance


- Drain the condensate from air receiver daily
 - If has automatic drain, inspect periodically
- Inspect belt tension on compressor
 - Should be able to press the belt down, in the center, with your hand approximately 3/4 inch
- Examine operating controls
 - Make sure compressor is starting and stopping at the proper settings
- Ensure portable compressors have oil in tool oiler reservoir
- Clean thoroughly each month

Valves




Gate Valves

- Basic parts: operator (handle), shaft packing assembly, bonnet, valve body with seats, stem, and disc
- Valve disc is raised/lowered by a threaded shaft
- Disc is screwed down until it wedges itself between two machined valve seats
- Not used to control flows
- Either rising stem or non-rising stem type



Gate Valves – O & M


- 1. Open valve fully
- 2. Operate all large valves at least yearly to ensure proper operation
- 3. Inspect valve stem packing for leaks
- 4. If the valve has a rising stem, keep stem threads clean and lubricated
- 5. Close valves slowly in pressure lines to prevent water hammer
- 6. If a valve will not close by using the handwheel, check for the cause; Using a "cheater" bar will only aggravate the problem

Gate Valves - Maintenance

Frequency	Service
Annually	Replace packing: Remove all old packing from stuffing box. Insert new split ring packing while staggering the ring splits.
Semi-annually	Operate valve: Operate inactive gate valves to prevent sticking
Annually	Lubricate gearing: Lubricate gate valves as recommended by manufacturer
Semi-annually	Lubricate rising stem threads: Clean threads on rising stem gate valves and lubricate with grease
Annually	Reface leaky gate valve seats: Remove bonnet and clean examine disc body thoroughly. Check and service all parts of valve completely. Remove all old packing a clean out stuffing box. Do not salvage old gasket. After cleaning and examining all parts, determine whether valve can be repaired or must be replaced. Test repaired valve before putting back in line.


Globe Valves

- Use a circular disc to make a flat surface contact with a ground-fitted valve seat
- Internal design enables valve to be used in a controlling /throttling mode
- Can be of rising or nonrising stem type
- O & M similar to gate valve




Ball Valves

- A valve consisting of a ball resting in a cylindrical seat
- A hole is bored through the ball to allow water to flow when the valve is open
- When the valve is rotated 90°, the valve is closed
- Should be operated fully open or fully closed
 - Throttling can lead to damage to the seal




Eccentric Valves

- Uses a cam shaped plug to match an eccentric valve seat
- As the valve is closed, the plug throttles the flow yet maintains a smooth flow rate
- Excellent for controlling the flows of slurries and sludges



Butterfly Valves


- Used primarily as a control valve
- Uses a machined disc that can be opened to 90° to allow full flow through valve
- Closed valve is forced against the continuous rubber seat




Check Valves

- Allows water to flow in only one direction
- Three types:
 - Swing check – a movable disc (clapper) rests at a right angle to the flow and seats against a ground seat
 - Wafer check – a circular disc that hinges in the center of the disc. Flow collapses the disc and flow stoppage allows the disc to return to its circular form
 - Lift check – uses a vertical lift disc or ball. Flow lifts the disc/ball and allows water to flow through.
 - Foot valves are nearly always vertical lift valves

Check Valves




Swing Check Valve



Check Valve Lift Type ASA-Model

Lift Check Valve




Wafer Check Valve

Check Valves - Maintenance

Frequency	Service
Annually	Inspect disc facing: Open valves to observe condition of facing on swing check valves
Annually	Check pin wear: Check pin wear on balanced check valve, since disc must be accurately positioned in seat to prevent leakage

Valve Video



Equipment Maintenance Vocabulary

<p>_____ 1. Amperage</p> <p>_____ 2. Brinelling</p> <p>_____ 3. Cavitation</p> <p>_____ 4. Circuit</p> <p>_____ 5. Circuit Breaker</p> <p>_____ 6. Current</p>	<p>_____ 7. Fuse</p> <p>_____ 8. Jogging</p> <p>_____ 9. Mandrel</p> <p>_____ 10. Megger</p> <p>_____ 11. Resistance</p> <p>_____ 12. Voltage</p>
--	---

- A. A safety device in an electric circuit that automatically shuts off the circuit when it becomes overloaded. The device can be manually reset.
- B. Tiny indentations (dents) high on the shoulder of the bearing race or bearing. A type of bearing failure.
- C. A special tool used to push bearing in or to pull sleeves out. Also can be a gage used to measure for excessive deflection in a flexible conduit.
- D. A protective device having a strip or wire of fusible metal that, when placed in a circuit, will melt and break the electric circuit if heated too much. High temperatures will develop in the fuse when a current flows through the fuse in excess of that which the circuit will carry safely.
- E. The formation and collapse of a gas pocket or bubble on the blade of an impeller or the gate of a valve. The collapse of this gas pocket or bubble drives water into the impeller or gate with a terrific force that can cause pitting on the impeller or gate surface. This is accompanied by loud noises that sound like someone is pounding on the impeller or gate with a hammer.
- F. The electrical pressure available to cause a flow of current (amperage) when an electric circuit is closed.
- G. The frequent starting and stopping of an electric motor.
- H. A movement or flow of electricity.
- I. An instrument used for checking the insulation resistance on motors, feeders, bus bar systems, grounds and branch circuit wiring.
- J. The strength of an electric current measured in amperes. The amount of electric current flow, similar to the flow of water in gallons per minute.
- K. That property of a conductor or wire that opposes the passage of a current, thus causing electrical energy to be transformed into heat.
- L. The complete path of an electric current, including the generating apparatus or other source; or, a specific segment or section of the complete path.

Equipment Maintenance Questions

1. What are some of the uses of a voltage tester?
2. How often should motors and wirings be megged?
3. An ohmmeter is used to check the ohms of resistance in what control circuit components?
4. What are the two types of safety devices found in main electrical panels or control units?
5. What is the most common pump driver used in lift stations?
6. Why should inexperienced, unqualified or unauthorized persons and even qualified and authorized persons be extremely careful around electrical panels, circuits, wiring and equipment?
7. Under what conditions would you recommend the installation of a screw pump?
8. What are the advantages of a pneumatic ejector?

9. What is the purpose of packing?

10. What is the purpose of the lantern ring?

11. How often should impellers be inspected for wear?

12. What is the purpose of wear rings?

13. What causes cavitation?

14. How often should the suction filter of a compressor be cleaned?

15. How often should the condensate from the air receiver be drained?

16. What is the purpose of lubrication?

17. What precautions must be taken before oiling or greasing equipment?

18. If an ammeter reads higher than expected, the high current could produce
 - a. "Freezing" of motor windings
 - b. Irregular meter readings
 - c. Lower than expected output horsepower
 - d. Overheating and damage equipment

19. The greatest cause of electric motor failures is
 - a. Bearing failures
 - b. Contaminants
 - c. Overload (thermal)
 - d. Single phasing

20. Flexible shafting is used where the pump and driver are
 - a. Coupled with belts
 - b. Difficult to keep properly aligned
 - c. Located relatively far apart
 - d. Required to be coupled with universal joints

21. Never operate a compressor without the suction filter because dirt and foreign materials will cause
 - a. Deterioration of lubricants
 - b. Effluent contamination
 - c. Excessive water
 - d. Plugging of the rotors, pistons or blades

Answers to Vocabulary and Questions

Vocabulary:

- | | | |
|------|------|-------|
| 1. J | 5. A | 9. C |
| 2. B | 6. H | 10. I |
| 3. E | 7. D | 11. K |
| 4. L | 8. G | 12. F |

Questions:

1. A voltage tester can be used to test for voltage, open circuits, blown fuses, single phasing of motors and grounds.
2. At least once a year and twice a year if possible
3. Coils, fuses, relays, resistors and switches
4. Fuses and circuit breakers
5. A.C. induction motor
6. You can seriously injure yourself or damage costly equipment.
7. To pump fluctuating flows with large solids and rags.
8. They can handle limited flows with relatively large solids. Maintenance is not as complicated as the maintenance on most pumps; however, maintenance must be performed when scheduled.
9. To keep air from leaking in and water leaking out where the shaft passes through the casing
10. To allow outside water or grease to enter the packing for lubrication, flushing, and cooling and to prevent air from being sucked or drawn into the pump
11. Every 6 months or annually, depending on pumping conditions; if grit, sand or other abrasive material is being pumped, inspections should be more frequent
12. They protect the impeller and pump body from damage due to excessive wear.
13. Cavitation can be caused by a pump operating under different conditions than what it was designed for, such as off the design curve, poor suction conditions, high speed, air leaks into suction end and water hammer conditions.
14. The frequency of cleaning a suction filter on a compressor depends on the use of a compressor and the atmosphere around it. The filter should be inspected at least monthly and cleaned or replaced every three to six months. More frequent inspections, cleanings and replacements are required under dusty conditions such as operating a jackhammer on a street.
15. Daily
16. To reduce friction between two surfaces and to remove heat caused by friction
17. Shut it off, lock it out and tag it so it can't be started unexpectedly and injure you
18. D
19. C
20. C
21. C

Section 12


Pipeline Cleaning & Maintenance




Pipeline Cleaning & Maintenance

Purpose


- Operate and maintain collection system to function as intended
- Primary purpose is to maintain the capacity of the sewer
- Potential problems can be found during routine cleaning and maintenance
- Minimize the number of
 - Stoppages per mile
 - Odor complaints
 - Lift station failures




High velocity cleaner with vacuum device to remove grit & debris


Stoppages

- Stoppages are caused by obstructions such as:
 - Roots
 - Debris
 - Grease
 - Broken pipe
 - Joint failure
 - Improper taps
 - Sticks








CLEAN SEWER (10')



SEWER WITH GREASE-BUILD UP

Stoppages

- Debris found when removing stoppages includes:
 - Solidified grease
 - Detergents
 - Sticks
 - Rags
 - Plastic bags
 - Broken pipe
 - Brick
 - Rock
 - Sand
 - Silt
 - Eggshells

Factors Effecting Sewer Cleaning Methods

- Wastewater characteristics
- Fluctuations in flow
- Sewer diameter or configuration
- Alignment or sewer grade
- Pipe materials
- Physical condition of sewer
- Location and accessibility of the pipe and records of previous cleaning

Solids

- Solids which settle out in sewers lead to
 - Corrosive conditions
 - Odors
 - Stoppages
 - Toxic hydrogen sulfide gas
- Numerous odor complaints often indicates that a sewer needs to be cleaned

Hydraulic Cleaning

- Using water pressure to clean sewers dates back over 100 years, but has recently undergone vast improvements with the development of self-propelling, high velocity cleaners (HVCs)
 - Also called jetters, hydraulic cleaners, hydro jets, flushers and jet trucks
- Water under pressure to produce high water velocities
 - High velocity cleaner
 - Ball or kite
 - Scooter
 - Flushing



High Velocity Cleaner - HVC

- HVCs force high pressure water through the nozzle at the end of the hose to scour the pipe walls
- The water pressure is also used to advance the nozzle head through the pipe
- The head cleans the invert and the walls of the pipe and moves the debris downstream where it can be captured and removed at a manhole



High Velocity Cleaner - HVC

- Effectively removes light grease and detergents, roots, sand, sludge and other light debris
 - Not as effective as power rodding machines for removing heavy roots and hardened grease
 - Not as effective as power bucket machines in removing packed debris in large diameter pipes
- HVCs operate most effectively in pipes ranging from 4 to 20 inches in diameter
- In pipes larger than 20 inches in diameter the cleaning effectiveness decreases as the pipe diameter increases
- Most commonly used as a preventive maintenance tool to keep sewers clear

High Velocity Cleaner - Equipment

- Equipment: Water tank, high pressure water pump, pump power source, hose reel with 500 or more feet and flushing nozzles
 - Trailer mounted system – ¾ inch diameter hose, delivers water flows from 25-40 GPM and operates at pressure ratings from 1500-2000 psi
 - Truck mounted system – 1 inch diameter hose delivering 50-100 GPM and pressure ratings up to 3000 psi
- The first 10 feet of hose behind the nozzle will be the first to wear from the impact of materials, to provide maximum protection a braided, steel-reinforced leader hose should be installed on the nozzle end

High Velocity Cleaner - Equipment

- Flushing nozzle: the selection of the nozzle is based on the work to be performed as the different designs accomplish different functions
- The angle of discharge from the nozzle is given in degrees, most common are 15, 35 and 45 degrees
 - The lower degrees provide better thrust, but higher degrees provide better cleaning capabilities
- Weekly nozzle inspection should be performed to ensure proper operation
- Drain the pump daily in cold weather



High Velocity Cleaner - Equipment


- 5 basic categories of nozzles:
 - Basic drilled nozzles – used for breaking blockages and cleaning debris
 - Rotational or spinning nozzles – best at cleaning grease and clearing light to medium roots (Brand names – Warthog and Bulldog)
 - Bottom or floor cleaners – remove heavy solids that have settled in the pipe invert
 - Specialty nozzles – designed for a single purpose (Ex. hydraulic root cutters)
 - High performance – engineered to provide a more powerful stream of water using less power with less maintenance

High Velocity Cleaner - Equipment

- Regardless of the nozzle chosen a finned nozzle extension should be used (attaches between the nozzle and the hose)
- The finned extension accomplishes two goals:
 - Helps to protect the nozzle from wear resulting from running on the rough surface of the pipe
 - Helps prevent the nozzle from turning up a lateral or service connection or turning around in the pipe



High Velocity Cleaner - HVC



High Velocity Cleaner - Operation

- HVCs water tank filled from a fire hydrant nearby
- When using a hydrant, a special hydrant wrench must be used to operate the main hydrant valve
 - Never use a pipe wrench on a hydrant valve because the valve nut is brass and is easily damaged
 - Never use a cheater bar on the hydrant wrench
- A gate valve should be installed on the hydrant to regulate the flow of water and eliminate the need to open and close the hydrant's main valve repeatedly which could cause damage to the valve or cause water to discharge from the hydrant weep hole that could undermine the hydrant

High Velocity Cleaner - Operation

- Once the gate valve is installed and in the closed position, fully open the hydrant's valve and then open the gate valve to allow water to run
 - Continue flushing until the water is clear from any rust
- Once the water is running clear, close the gate valve slowly to avoid water hammer in the water main
- Fill the water tank by slowly opening the gate valve to avoid disturbing any rust
 - A properly installed air gap must be used to prevent a cross connection between the HVC tank and the water system

High Velocity Cleaner - Operation

- A flushing nozzle is installed at the end of the hose and is lowered into the downstream manhole of the section of sewer to be cleaned
- The rear facing jets on the nozzle allow the flushing nozzle and hose to be pushed forward through the line to the next manhole (usually not more than 300 ft away)
- As the nozzle travels through the line the high velocity water dislodges sediment, roots, grease, sand, silt and sludge and back-flushes it to the downstream manhole
- A debris trap in the downstream manhole is used to catch and remove the debris

High Velocity Cleaner - Operation

- When cleaning a large diameter sewer pipe a sand trap is placed in the downstream pipe of the manhole to prevent large amounts of debris from accumulating downstream
- Water and debris entering the manhole builds up in the manhole and the water drains over the top of the trap while the solids settle out and remain in the manhole
 - Debris shovels, grabbers or vacuums can be used to remove the debris



High Velocity Cleaner - Operation

- Continue sending the nozzle end up the line and bring it back to the downstream manhole enough times to reach the upstream manhole and return without bringing back debris
- Keep the nozzle moving and the pump operating at all times to avoid creating stoppages, especially in smaller diameter lines
 - If you travel too far up the line, enough debris could be dislodged that the nozzle can't move downstream fast enough resulting in a stoppage

High Velocity Cleaner - Operation

- The exact distance the cleaning nozzle has moved forward must be known at all times
- Regularly check to ensure that the nozzle is threaded securely onto the skid or leader hose
 - If the nozzle detaches there will be an immediate drop in the water pressure
- While using an HVC to clear a stoppage once the nozzle reaches the stoppage pull the hose back a few feet by hand and let go
 - The nozzle will shoot forward quickly and give a pounding effect on the stoppage

High Velocity Cleaner - Safety

- Use extreme caution when operating forward spraying nozzles
 - The pressure of a forward spraying nozzle can propel itself out of the line and cause serious operator injury
- If fresh soil or broken parts of the sewer pipe are washed into the downstream manhole stop the operation
 - Continued cleaning could result in a large hole developing under the street which could lead to street collapse
- A bend in the line will prevent you from pulling the nozzle back under full pressure, reduce the pressure until you pass the bend

High Velocity Cleaner - Safety


- When clearing stoppages with an HVC avoid using the surcharged upstream manhole as it is difficult to know that the nozzle is secure in the invert and will not exit the manhole under high pressure and endanger operators and possibly damage the machine
 - Always use the dry downstream manhole to clear stoppages
- Always be aware of what the nozzle is doing in the pipe and be on guard for it to turn around in large diameter pipes
 - Debris or pieces of pipe can cause a nozzle to flip over backward and move back toward the operator

High Velocity Cleaner




Cleaning with a Sewer Ball

- Preventive maintenance
- Spinning ball and high velocity water move debris downstream
- Effectively removes grease, sand, grit and other debris



Cleaning with a Sewer Ball

- Don't use in areas with steep grade hills (basement flooding)
- Large sewers use kite, tire, or scooter instead of ball
- Cannot be use in areas with protruding taps or sewers with badly offset joints



Cleaning with Kites and Bags

- Force mains and other larger diameter sewers, where HVCs are not effective, require the use of kites and bags
- Both are capable of washing ahead of themselves a full pipe of deposits
- Head pressure is built up upstream of the kite or bag and the velocity of water flowing around the outside of the bag or through the outlet of the kite will create sufficient cleansing velocity
- Equipment: water tank truck, dump truck and a power drum winch machine


Sewer Scooter

- The scooter is a self-propelled tool the uses water pressure to effectively clean sewers at a cost that is considerably less than other cleaning methods
- The scooter is a framework on small wheels with a circular metal shield at one end that is rimmed with a rubber flange
- The top half of the shield is hinged and controlled by a chain-spring system while the lower half is fastened with bolts to the front of the frame
- Head pressure is created upstream of the scooter and the flow of water around the device creates hydraulic cleaning action while being controlled by the upper half of the shield

Sewer Scooter

- Most effective in cleaning larger lines over 18 inches in diameter
- Effectively removes grease, grit, bricks, and rock
- Available in sizes from 6 - 96 inches
- Equipment: Tank truck, debris traps, control lines, control cable guide, power drum winch, scooter
 - Sewer up to 12 inches in diameter – hand winch
 - Sewers 15 inches and larger require a power drum winch and steel cable due to the tremendous pressure of water behind the head shield

Sewer Scooter - Operation



Sewer Scooter - Operation

- A control rope or cable is fastened to the control chain of the scooter and the scooter is lowered into the upstream manhole
- After the head shield is inserted into the pipe, install the lower manhole jack or control cable guide and secure firmly
 - This allows the control cable to take the strain without rubbing on the sharp edge of the pipe during the cleaning operation
- With the scooter inserted in the pipe and the head shield raised it will act as a plug and a head of water will begin building up in the manhole
- The water level in the manhole is controlled by pulling firmly on the control line to lower the head shield and allow water to pass


Sewer Scooter - Operation

- At the start of the operation test the folding mechanism by giving the control line a short, smooth pull back 2 or 3 ft
 - If the buildup of water in the manhole in the upstream manhole starts to go down, you know the folding mechanism is working
- Allow the scooter to work its way downstream, keeping steady tension on the control line to maintain a continuous flow of water and a smooth cleaning operation
- Attention must be given to the amount of water in the manhole above the invert, the best cleaning action results when the depth of water in the manhole is three times the pipe diameter

Sewer Scooter - Operation

- Scooter cleaning efficiency increases as the pipe diameter increases due to the increase in head pressure which increases the high velocity flow around the head shield
 - If the flow in the sewer is insufficient for effective cleaning, then additional water can be added from a tank or hydrant
- If the scooter slows or stops during the operation this is usually due to a build up of material in front of the scooter
 - To clear the material, give the control line a short, smooth pull back of 4 or 5 feet allowing the top half of the shield to fold back and a surge of water will be released to flush the accumulated material downstream

Flushing Operation



Flushing Operation


- May control odors at beginning of sewer where low flows may lead to solids accumulation
- May also control insects and rodents in sewer
- Also used with mechanical cleaning (bucket machines & power rodders)
- Air gap device needed if hydrant used as water source
- Safety considerations:
 - Traffic
 - Atmosphere in manholes (toxic & explosive gases)
 - Avoid flooding of houses & businesses

Mechanical Cleaning


- Mechanical equipment that scrapes, cuts, pulls, or pushes material out of pipe
 - Bucket machines
 - Power rodders
 - Hand rodders
 - Porcupines
 - Swabs




Swabs or poly pigs



Porcupines are used to scour pipe walls of hardened debris, roots, & grease



Power Bucket Cleaning



Power Bucket Cleaning

- Provides means to clean larger sewers
- Final cleanup using porcupine to scrub sewer line
- May require hydraulic cleaning afterwards to remove smaller debris (sand, grit)
- Working machine located at the upstream manhole when cleaning debris from large lines
- Always pull porcupine downstream to avoid sealing off the line and causing the sewer to back up

Power Bucket Cleaning

- Power bucket machines are an excellent maintenance tool for removing large amounts of debris from the sewer, especially in large lines
- In smaller sewers with lower flows, the working machine is usually located at the downstream manhole
 - Working from this manhole reduces the possibility of a stoppage developing in the sewer below the work area
- Often the working machine is located at the upstream manhole when clearing debris from larger lines

Bucket Machine Maintenance

- Proper lubrication cable scroll and level wind system
- Inspect belt and chain tensions
- Inspect gear clearance
- Watch for frayed cable
- Watch for loose cable clamps



Bucket Machine Equipment



Power Rodder



- Power rodding machines use a steel rod to push or pull various clearing tools through sewers
- Used for:
 - Routine preventive maintenance
 - Scheduled clearing of grease deposits, roots and debris accumulations in flat lines
 - Threading cable for CCTV inspection and bucket machines
 - Emergency use for clearing stoppages
- One of the most widely used methods for clearing collection systems





Power Rodder

- Can perform tasks that are difficult with hydraulic cleaning methods such as heavy root removal, grease and grit deposit removal and stoppage relief
 - Power rodders do not remove silt, sand and sludge as effectively as hydraulic cleaning methods
 - After clearing a sewer with a power rodder it should be cleaned hydraulically to restore the line to full capacity
- Due to the tendency for rods to bend or coil in large diameter pipes they are most effective in pipes that are 15 inches in diameter or smaller

Power Rodder

- Power rodders are typically classified as either sectional or continuous type machines
- Both types of machines are effective in clearing sewer lines up to 15 inches in diameter and up to distances of 750-1000 feet depending on the diameter of the rod





Power Rodder - Sectional

- Sectional power rodder is designed to use sections of rod that are mechanically attached to each other
 - Industry standard refer to sectional rod diameter sizes in fractions
 - Rod size can be either a 5/16 or 3/8 inch diameter
 - Available in lengths of 36 inches, 39 inches and 48 inches
 - Capable of clearing lines effectively in diameters up to 12 inches and distances up to approximately 750 feet

Power Rodder – Continuous

- Continuous power rodders are designed to use a single continuous rod
 - Continuous rod diameters given in decimal form
 - Most common rod diameter sizes are 0.312 inch, 0.375 inch and 0.401 inch
 - Rod storage is usually between 1000 and 1500 feet



Power Rodder Type Differences



- Continuous rodding machines are quickly and easily loaded, while loading a full sectional reel may require several hours of coupling all of the sections together
- Sectional rods are pushed through the drive head by a positive drive, but continuous rods are pushed by roller that can slip and cause wear
- Continuous rodders cover longer distances and are less likely to break than sectional rodders due to the transfer of torque down the continuous length of the rod
 - Sectional rod couplings and nuts can work loose or increase friction

Power Rodder Type Differences

- Continuous rods must be cleaned as it passed through the drive rollers to prevent damage and wear, but sectional rods are more forgiving
 - Both types should be cleaned as they are being retrieved to prevent grit from entering the roller system
- Repairs to a broken sectional rod can be made quickly in the field, but a continuous rod break is difficult to repair, and the broken section must be discarded resulting in a reduction in the operating length

Power Rodder Type Differences


- The broken end of the continuous rod cannot be reused and the remaining portion on the reel may be too short to use effectively resulting in the replacement of the entire reel
- A broken continuous rod is also more difficult to retrieve than a broken sectional rod because there are no couplings for the pick-up tool to grab


Sectional steel rod
Used to push or pull various cleaning tools through the sewer

Power Rodding Tools

Square bar corkscrew
 Primarily used to relieve stoppages in pipes over 6 inches in diameter. An effective stoppage tool due to the open structure of the blade that allows materials to pass through the tool




Auger
 Used to pilot a hole through roots, grease and other solids in the pipe. Primarily used in conjunction with other tools to open a path in the line so that another tool, such as a root saw, can be used more easily. Effective in cleaning misaligned pipes because the direction of rotation can be reversed to navigate bad joints to travel to blockages




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition – Figure 5.11

Power Rodding Tools


Double point corkscrew
 Used to engage and retrieve root masses, cans, plastic bottles, fabrics and other solid debris from a pipe. The double points allow the tool to bite into material and retrieve it



Spring blade cutter
 Used as a finishing or pull-back tool after a root saw or auger has removed the bulk of roots or grease from the line. The tool is installed at the manhole away from the rodding machine and is slowly pulled backward through the pipe at a high rotation speed. The blades are designed to scour the pipe walls to remove the balance of materials left behind. This tool should be operated only while being pulled




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition – Figure 5.11




Power Rodding Tools

Sand leader
 Used to rotate and remain above sand and other built-up deposits to thread a line with cable or attach a different tool from the next manhole or access point




Sand corkscrew
 Used in pipes where sand has plugged the line. The first screw portion pilots the tool into the sediments; the second screw portion further enlarges the access point and allows water to enter the material to loosen it




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition – Figure 5.11

Power Rodding Tools

Root saw
 Used exclusively to cut through root masses in the pipe after the auger has piloted a hole in the line. Available in many different configurations for different kinds of root cutting from small curtain or "veil" roots to large root intrusions




Spearheads or boring tools
 Used to break up stubborn stoppages, break glass, pierce cans and break up packed silt, sand or industrial debris




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition – Figure 5.11

Power Rodding Tools

Porcupine
 Used as a finishing tool to scour the pipe after cleaning operations. This tool should be operated only while being pulled, and it requires a winch and tag line for safety




Pilot bullet
 Used primarily on the end of the string of a rod to guide the rod easily through the rod guide hose. Installed after the line has been clean and the rod is pulled back into the machine. This tool also can be used for stoppages and threading a cable into a pipe




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition – Figure 5.11

Power Rodding Tools

Pick-up tool
Used to retrieve sectional rods that have broken in a sewer line. Tool slowly turns and locks on the rod coupling, allowing the string of rod to be removed



Assembly wrench
Used on the coupling nut to install and change tools or to change sectional rod sizes



*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition - Figure 5.11

Power Rodding Tools


Assembly turning handle
Used to provide a firm, safe hold on the rod coupling so that the assembly wrench can turn the coupling nut



Swivel
Used when towing a cable through a pipe. The swivel action allows the cable or rod to twist independently and prevents knotting of the cable




Sectional rod coupling
Used to attach steel rods to each other




*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition - Figure 5.11

Power Rodding Tools

Rod guide hose
Used on all power rodders to protect and support the rod as it travels from the machine to the bottom of the manhole




Lower manhole brace
Used with the rod guide hose to prevent the bell end of the hose from pushing back out of the pipe when an obstruction is encountered. This brace attaches to the guide hose bell and, when placed against the opposite wall of the manhole, prevents the guide hose from pushing out of the pipe invert



*Tool descriptions from Operation and Maintenance of Wastewater Collections Systems Vol. 1, Eighth Edition - Figure 5.11

Power Rodding Tools

- Tools for the rodding machine are designed to be rotated clockwise in the pipe to clear material
 - Corkscrew, boring tools and augers can be rotated counter-clockwise to back them out of the accumulated material or to travel over misaligned joints
- Corkscrew and boring tools should be rotated slowly at about 25 RPM
- Root saws need to rotate faster at 25-50 RPM
- Finishing or pull back tools need to rotate at about 55-60 RPM as they are being slowly pulled back



Power Rodder Machine Operation

- Start at the top of the system when clearing a long section of the system
 - Any debris lost downstream during the operation will be going into a pipe section that you will clear next
- **Always test the manhole atmosphere for explosive gases before rodding operation because sparks from the rodding could cause an explosion**
- Install a lower manhole rod guide in the manhole being used and a debris trap in the downstream manhole

Power Rodder Machine Operation

- If the rodding machine is being set up to clear a stoppage use a square bar corkscrew from the dry manhole, after material has broken loose examine it to determine which tool would work best to completely clear the stoppage
- It is usually better to change a tool from the far manhole which will save the time of removing the rod guide hose from the machine manhole
 - Pull the end of the rod out of the manhole, shut off power to the rodding machine before handling, replace the tool, wait until the new tool reaches the invert before turning power back on

Power Rodder Machine Operation

- To remove roots: auger → root saw → finishing tool
- Select an auger that is one size smaller than the pipe and run it upstream to the far manhole
 - The root saw can be the same size as the pipe and is slowly pulled downstream at a high RPM
 - Run the saw back up to the upstream manhole and change to the finishing tool (Ex. spring blade cutter) and slowly pull it back downstream at a high RPM



Power Rodder Machine Operation

To remove grease: small auger → pipe sized auger

- Select an auger that is one size smaller than the pipe and run it upstream to the far manhole
- At the upstream manhole change to an auger that is the same size as the pipe and pull it back to the machine
 - You could run the rod back to the upstream manhole and switch to a finishing tool to pull back through for a final cleaning
- A good practice is to flush the line after grease removal by using either an HVC or flush from an upstream hydrant

Power Rodder Machine Operation

- Properly place the rodding machine so that there are no bends in the guide hose
 - When a rod is forced to stay in one place in a severe bend it will heat up as it is rotated, when the hot metal reaches the cool water, it can be damaged resulting in likely spot for the rod to break
- The forward pressure on the rod should be limited to 350 pounds
 - Too much pressure may make the rod bend in the pipe and break or reverse itself causing a tangle

Power Rodder Machine Operation

- The tool will usually stop rotating when it engages material and if you do not back off the rod will twist into a loop and continue to coil, this is called over torque


Never handle a rod when it is under tension

Twisted rods are very dangerous and need to be treated carefully


- To increase the effectiveness of a clearing operation in areas of low flow, add additional flow from the upstream manhole
 - Flow in the section of sewer being cleared is essential for cooling the rotating tool and flushing removed debris

Recovering Broken Rods



- When a rod breaks begin recovery by measuring the amount of rod pulled back to determine the approximate location of the broken rod
- For sectional rods remove the broken half at the coupling and install the pick-up tool to recover the rod remaining in the line, then couple the two rods together again
- Continuous rod breaks are far more difficult because the tool coupling is also lost in the line and a new one will need to be fashioned, then the pick-up tool can be used



Poly Pig





- Poly pigs, also called pigs or swabs, are a common method of cleaning force mains
- A poly pig is inserted into the main and pushed through the pipe by pressurizing behind the pig
 - Poly pigs are available in various densities and surface coatings for different kinds of cleaning
 - Ice is also currently being used – Ice pigging


Types of swabs and pigs

Poly Pig





- The capacity in a force main is reduced when slime builds up on the walls of the pipe or when solids settle in the invert
- As the poly pig is forced through the main it scours the pipe wall clean to regain full capacity

Poly Pig



- A launching or entry point must be available to insert the poly pig and an access point at the end of the force main is needed to retrieve the poly pig after the operation
- Poly pigs are flexible enough that they can usually negotiate around corners and bends
 - Obstructions in the force main such as a butterfly valve will cause the pig to become stuck
 - Carefully review as-built drawings of the line to clean to avoid any obstructions
 - Poly pigs can be equipped with a radio beacon device which allows operators to track its progress through the pipe




Chemical Application

- Chemicals can be useful aids for cleaning and maintaining collection systems
- Chemicals can be used to control roots, grease, rodents, insects, odors and corrosion
 - Chemicals will not immediately clear stoppages

Review the SDS First!
Do not mix unknown chemicals





Root Control

- Roots are drawn to sewer lines by vapor trails that escape into the soil through very small cracks in the pipe
 - Tiny roots enter the sewer line one cell at a time and quickly grow by feeding on the nutrient rich environment inside
 - As the roots grow, they expand the cracks leading to breaks and fill the pipe creating stoppages
 - Roots that grow from the top of the pipe are called "veils" and catch passing grease and debris, creating a blockage




Root Control

- Power rodders are most effective method to remove roots using root saw
- Chemical root control agents applied by flooding or foaming destroy existing roots in sewers and can prevent regrowth for periods of 3-5 years
 - First ingredient is a fumigant that penetrates the cell walls of existing roots causing decay
 - Second ingredient is a growth inhibitor that chemically attaches itself to the interior of the pipe
 - Both are needed for good root control



Grease

- Fats, Oils and Greases (FOG) and soaps cool, solidify and form a coating or deposit on the walls of a sewer creating a reduction in capacity and can lead to stoppages
- Sources: restaurants, hospitals, industries and homes with garbage disposals



Grease

- Rate of buildup depends on amount in the wastewater, flow, velocity and sewer size
 - Sewers > 18 in typically have fewer grease problems
- Solutions: grease-eating bacteria, power rodders, high velocity cleaning (HVC)
- Inspect & clean grease traps as needed
- Ultimate solution is to educate sewer users about the problems created by soap and FOG discharge into sewers



Odors

- Odors from the collection systems are primarily from the production of hydrogen sulfide (H₂S) and most odor control programs focus on reducing or eliminating H₂S production in the system
- The production of H₂S can be due to low-velocity flows, long sewer lines, high temperatures or poorly maintained collection systems




Why Control Hydrogen Sulfide?

- Paralysis of respiratory system may lead to death of collection system operators
- Corrosion which could lead to possible collapse of the sewer, structures and equipment
- Loss of system capacity
- Creates a flammable and explosive atmosphere under certain circumstances
- Most common source of odor complaints
 - H₂S has a rotten-egg odor from the sulfur

Hydrogen Sulfide Production

- H₂S is produced under anaerobic conditions by bacteria in the slime layer below the water line that convert sulfate to sulfide
 - Anaerobic – no free oxygen available for organisms to use
- The sulfide is dissolved in the wastewater until disturbed and is then released as H₂S gas which is highly dangerous to operators and creates an explosive environment
 - H₂S LEL (lower explosive limit) is 4.3% and UEL (upper explosive limit) is 46%
- The H₂S gas is used by bacteria above the water line to produce sulfuric acid (H₂SO₄) can cause severe corrosion
 - H₂SO₄ is corrosive to concrete, Fe, Cu, Zn, Pb, Cd

Hydrogen Sulfide Production




Factors that Contribute to Hydrogen Sulfide Production

- Sulfate concentration
- Concentration of organic matter
- Oxygen
 - Critical DO is 0.1 to 1.0 mg/L
- Amount of slime on pipe walls
 - Sulfide production is faster in warmer wastewater temperatures
- Lower stream velocity leads to thicker slime layer
- Temperature
- pH

More on Hydrogen Sulfide

- Exposure for 2 min at 0.01% impairs sense of smell-*olfactory fatigue*
- Specific gravity 1.19
- Maximum safe 15-minute exposure: 20 ppm (OSHA)
- Greatest problem at wastewater pH < 5
- A concentration of 1 ppm in turbulent wastewater can produce a concentration of 300 ppm in the atmosphere



Controlling Odors

- Many collection system municipalities are developing and implementing odor control plans which incorporate measures to reduce the generation and release of odors
- Odor control plans include:
 - Odor complaint response and investigation
 - Routine sewer maintenance
 - Chemical addition
 - Air withdrawal and treatment from the collection system
 - Sewer construction and repair
 - Ongoing monitoring of sewer air pressure and odor conc.

Complaint Response & Investigation

- After receiving an odor complaint operators need to investigate and identify the source
 - Some odor complaints are non-sewer related such as standing water, stormwater catch basins or owner plumbing problems
- Once identified determine and implement necessary actions to eliminate the odor which could include sewer cleaning, sealing maintenance holes and inspecting trap maintenance holes for structural integrity and functionality
- Document the complaint and response, then inform the complaining customer according to your procedure

Routine Sewer Maintenance

- Routine maintenance is necessary to allow wastewater to flow freely in the system
- Obstructions slow the flow and cause debris to settle out resulting in the production of H_2S
- Preventive maintenance includes
 - Sewer cleaning and root control
 - Trap manhole inspection and cleaning
 - Siphon inspection and cleaning
 - Sealing manholes

Chemical Odor Control Technologies

- Chemical or "liquid phase" control technologies limit the production of H_2S by preventing sulfide from forming in the wastewater in the system
- Aeration
 - Pure oxygen can be injected into force mains
 - Injection of compressed air
 - Oxidizes existing sulfides in water
 - Prevents downstream sulfide formation (keeps water aerobic)
 - Cheapest chemical available - it's free

Chemical Methods of Odor Control

- Hydrogen peroxide (H_2O_2) addition keeps the wastewater aerobic and oxidizes H_2S
- Requires a conditioning program because the slimes are not directly affected by normal doses of H_2O_2
 - Dose with sodium hydroxide (NaOH) also called caustic soda or calcium hydroxide ($Ca(OH)_2$) also called lime
 - Lime dosage at about 8000 mg/L over 1 hour will kill the slimes over periods of 1–14 days
- H_2O_2 Dose:
 - 35% conc. 13-15 mg/L per mg/L H_2S
 - 50% conc. 11-13 mg/L per mg/L H_2S

Chemical Methods of Odor Control

- Nitrate addition
 - Calcium nitrate ($Ca(NO_3)_2$) or Bioxide® adds nitrate to the wastewater stream and makes it available to the bacteria
 - Bacteria use the nitrate as an oxygen source before sulfate in anaerobic or anoxic water conditions resulting in less H_2S being produced
- Masking agents
 - Overpower the odor
 - Do not correct the problem



Chemical Methods of Odor Control

- Chlorine is the most widely used chemical for hydrogen sulfide control and lift stations are often used for injection sites
- Chlorine gas (Cl_2), Calcium hypochlorite ($Ca(OCl)_2$ solid; HTH) or Sodium hypochlorite (NaOCl; liquid bleach) can be used
- Chlorine doses of 10-20 mg/L are effective in controlling the production of H_2S
 - Toxic to most organisms in the wastewater resulting in less oxygen being consumed keeping it aerobic and directly eliminating the bacteria that produce H_2S

Chemical Methods of Odor Control

- Sodium hydroxide (NaOH)
 - Periodic treatment to inactivate bioslime
 - Increase pH to > 12.5 for 30 min
 - Safety considerations while handling
 - NaOH concentration is typically 3-6 % and care must be taken not to overfeed
- Iron salts
 - React with dissolved sulfide to form metal precipitate to prevent release of H_2S to air
 - Corrosive acid solution
 - Storage tanks for iron salts must be fiberglass or steel lined with rubber
 - Pipes must be PVC
 - Pumps must be plastic or rubber-lined to prevent corrosion

Chemical Methods of Odor Control

- Magnesium hydroxide (Thioguard®)
 - Raises WW pH>8, so sulfide is not produced
 - Binds up sulfide in solution forming magnesium polysulfide
 - Adds alkalinity
 - Nonhazardous & environmentally safe
- Improves treatment plant performance
 - Controls odors
 - Addition of alkalinity aids nitrification
 - Cationic-improves sludge settleability and removal of TSS and BOD


Thiobacillus

Acid Attacks Concrete

$$H_2S + O_2 = H_2SO_4$$


$$SO_4^{2-} \rightarrow HS^- \rightarrow H_2S$$

Magnesium hydroxide also sprayed on crown to stop corrosion




Air Treatment and Air Flow Control

- Conventional carbon adsorption system, scrubbers
 - Odorous air is directed through a vessel containing activated carbon
 - Hydrogen sulfide, other reduced sulfur compounds and volatile organic compounds (VOCs) are attracted to and adhere to the pore structure of the carbon and are removed from the air stream
 - Relieves the air pressure in the system while preventing the release of odors




Air Treatment and Air Flow Control

- Air is introduced into a bed of compost or peat (media)
- Bacteria living in media biologically oxidize odors
- Other odors captured by media are chemically oxidized



Left: Biofilters can treat odors in air vented from sewer



Right: Manhole insert can treat odors at one manhole

Cleaning & Maintenance Vocabulary

<p>_____ 1. Air Gap</p> <p>_____ 2. BOD</p> <p>_____ 3. Balling</p> <p>_____ 4. Bucket</p> <p>_____ 5. Flushing</p> <p>_____ 6. High-Velocity Cleaner</p> <p>_____ 7. Hydraulic Cleaning</p> <p>_____ 8. Insecticide</p> <p>_____ 9. Kite</p>	<p>_____ 10. Mechanical Cleaning</p> <p>_____ 11. Pesticide</p> <p>_____ 12. Porcupine</p> <p>_____ 13. Rod</p> <p>_____ 14. Rodenticide</p> <p>_____ 15. Scooter</p> <p>_____ 16. Sewer Ball</p> <p>_____ 17. Swab</p>
---	---

- A. A machine designed to remove grease and debris from the smaller diameter sewer pipes with high-velocity jets of water.
- B. Clearing pipe by using equipment that scrapes, cuts, pulls or pushes the material out of the pipe. These include bucket machines, power rodders and hand rods.
- C. A sewer cleaning tool the same diameter as the pipe being cleaned. The tool is a steel cylinder having solid ends with eyes cast in them where a cable can be attached and pulled by a winch. Many short pieces of cable or bristles protrude from the cylinder to form a round brush.
- D. A method of hydraulically cleaning a sewer or storm drain by using the pressure of a water head to create a high cleansing velocity of water around the ball.
- E. Any substance or chemical formulated to kill or control insects.
- F. A sewer cleaning tool whose cleansing action depends on the development of high water velocity around the outside edge of a circular shield. The metal shield is rimmed with a rubber coating and is attached to a framework on wheels. The angle of the shield is controlled by a chain-spring system that regulates the head of water behind it and thus the cleansing velocity of the water flowing around the shield.
- G. A special device designed to be pulled along a sewer for the removal of debris from the sewer. It has one end open with the opposite end having a set of jaws.
- H. A spirally grooved, inflatable, semi-hard rubber ball designed for hydraulic cleaning of sewer pipes.
- I. Any substance or chemical designed or formulated to kill or control animal pests.
- J. A circular sewer cleaning tool almost the same diameter as the pipe being cleaned. As a final cleaning procedure after a sewer line has been cleaned with a porcupine, this is pulled through the sewer and the flushing action of water flowing around the tool cleans the line.
- K. An open vertical drop, or vertical empty space, between a drinking (potable) water supply and the point of use. This gap prevents backsiphonage because there is no way wastewater can reach the drinking water.
- L. Any substance or chemical used to kill or control rodents.

- M. Cleaning pipe with water under enough pressure to produce high water velocities using: a high-velocity cleaner; a ball, kite or similar sewer cleaning device; a scooter; or flushing.
- N. A device for hydraulically cleaning sewer lines. Resembling an airport windsock and constructed of canvas-type material, it increases the velocity of a flow at its outlet to wash debris ahead of it.
- O. The removal of deposits of material that have lodged in sewers because of inadequately velocity of flows. Water is discharged into the sewers at such high rates that the larger flow and higher velocities are sufficient to remove the material.
- P. A light metal rod, three to five feet long with a coupling at each end. They are joined and pushed into a sewer to dislodge obstructions.
- Q. Biochemical Oxygen Demand. The rate that organisms use the oxygen in water or wastewater while stabilizing decomposable organic matter under aerobic conditions.

Cleaning & Maintenance Questions

1. What are the major causes of stoppages?
2. What is the most effective method of removing grease buildups?
3. How can a stoppage caused by roots be cleared?
4. List three sewer line hydraulic cleaning methods.
5. What kinds of deposits in sewers can be removed by balling?
6. Where is the additional water obtained to provide the necessary head for a balling operation when flows in the sewer are low?

7. What are the uses of high-velocity cleaning machines?
8. Where should you start to clean the sewers in a given area or subdivision?
9. Which direction does the nozzle travel in the sewer?
10. Scooters can be used to remove what kinds of material from sewers?
11. How are force mains often cleaned?
12. Identify two sewer line mechanical clearing techniques.
13. What is the purpose of the porcupine tool?
14. Chemicals can be used to control what types of problems in wastewater collection systems?
15. What are the causes or sources of grease problems?
16. What problems are created by the presence of hydrogen sulfide?

17. What are the sources of hydrogen sulfide?

18. What are three potential methods of chemical control of sulfide?

Answers to Vocabulary and Questions

Vocabulary:

- | | | | | |
|------|------|-------|-------|-------|
| 1. K | 5. O | 9. N | 13. P | 17. J |
| 2. Q | 6. A | 10. B | 14. L | |
| 3. D | 7. M | 11. I | 15. F | |
| 4. G | 8. E | 12. C | 16. H | |

Questions:

1. Major causes of stoppages include obstructions such as roots, grease, debris, broken pipe or joint failures. Vandals, construction work, forces of nature and intersecting flows can also cause stoppages.
2. High-velocity cleaners are effective tools for removing grease buildups in sewers up to 15 inches in diameter. A parachute or bag may be a better method for larger diameter sewers.
3. A stoppage caused by roots can be cleared by either a power rodder or a hand rodder. A high-velocity cleaner is also effective with a special head and proper operation.
4. Balling, high-velocity cleaner, flushing, sewer scooter, kites, tires and poly pigs
5. Deposits of grit and grease
6. Fire hydrants or water truck
7. Open stoppages, remove grease, clean lines of debris and wash manholes and wet wells
8. Start at the top or highest point in the collection system.
9. Direct nozzle upstream
10. Large objects such as brick, sand, gravel and rocks
11. Poly pigs are frequently used
12. Bucket machines, power rodders and hand rods
13. Final cleanup since the bristles produce a scrubbing action.
14. Chemicals can be used to control roots, grease, odors, corrosion, rodents and insects.
15. Restaurants, industries and homes with garbage disposals
16. Paralysis of the respiratory center and death of operators; rotten egg odor; corrosion and possible collapse of sewers, structures and equipment; loss of capacity of the sewer
17. Hydrogen sulfide comes from the reduction of sulfate to sulfide by bacteria in the slimes on sewers under anaerobic conditions.
18. Chlorine compounds, hydrogen peroxide, iron salts, air, sodium hydroxide, magnesium hydroxide, nitrates.

Section 13
Underground Repair




Underground Repair

Why Repairs are Needed

- Repairs to sewer lines, laterals, and manholes are necessary to correct damage, deterioration or to remove and obstruction. The causes of the problems result from:
 - Poor or outdated system design or layout – deterioration could occur due to conditions that could have been prevented during the design phase
 - Wrong pipe materials for the loading conditions
 - Blind connections with no manhole

Why Repairs are Needed

- Poor construction practices – collapsed and damaged pipe may be the result of incorrect construction methods (bedding & backfill), use of improper or poor-quality materials, or other nearby excavation work
- Offset joints and sagged pipe can be caused by using improper pipe bedding or backfill
- Joints may also become offset due to heavy traffic loading, seismic activity or dramatic changes in groundwater elevations
- Corrections to offset joints and sags involve point repairs or open-cut replacements


Why Repairs are Needed

- Improperly connected or defective taps can prevent sewer lines from functioning properly
 - Protruding and misaligned taps can cause a restriction in flow, build up of material and could prevent inspection and cleaning equipment from passing through
 - Hammer (break-in) taps and illegal taps can weaken the pipe structure and create openings for roots, debris and water to enter the system
 - Often result in fill material entering into the main line and causing future problems




Why Repairs are Needed

- Repair of a protruding tap may require the section of line to be removed, replaced with a new section, and reconnected to the building sewer
- Some protruding taps can be removed by a mechanical cutting tool
- Protruding taps can be avoided by cutting the hole in the main line and installing a proper saddle tap




Protruding tap cutter



Saddle tap

Why Repairs are Needed

- Damage caused by others – outside utilities, contractors, plumbers and other parties can damage sewer mains, laterals, manholes and other structures
- Sewer mains and laterals can be pierced by horizontal directional drilling equipment during the installation of gas lines, fiber optic cables, installation of signs, fence posts, telephone poles and guide wire anchors
- Cross bore – when an existing utility or underground structure intersects with a secondary utility which compromises the integrity of the utilities or structures



Why Repairs are Needed

- Aging infrastructure – typical problems found are roots, offset joints and sags
- Many collection system repairs result from a system failure or disruption
- A utilities inspection and preventative maintenance crew may also discover problems during routine work
- Once a repair need has been identified, a work order is generated detailing all the important information about the repair; person generating request, priority, map, manhole info, pipe size and depth, distances from manholes, work requested

Repair Job Planning

- Proper planning ensures the safety of personnel and the proper execution of the repair work. Job planning should include:
 - Site visit – done by supervisor or crew leader prior to starting the job to confirm site location, access issues, traffic control needed, utilities in the area (overhead & underground), equipment and tools needed, required safety equipment and private property considerations
 - Utility locating (Call 811) – any job involving digging requires contacting all utilities with underground infrastructure and requesting for them to identify and physically mark the locations
 - Contact is done through local One Call Centers (811)



Repair Job Planning

- Utilities will send a locator to mark the approximate location of buried utility lines – different color paints are used for different utilities
- All utility markings are subject to a tolerance zone which is a horizontal space from the outside wall or edge of an underground line or pipe that is centered from the temporary mark
 - **An excavator should always assume that the underground facility could be anywhere within the tolerance zone on either side of the temporary mark**
 - **It is the operator's responsibility to have all utilities marked and ensure other utility lines are not damaged**



Repair Job Planning

- Other plan elements include a traffic control plan, bypass pumping plan and a public relations plan
- Environmental considerations
 - Care must be taken to minimize runoff from your excavation spoils by immediately hauling off the spoils or by placing them so that runoff cannot enter a stormwater system or stream
 - Asbestos cement (AC) pipe, also called transite pipe, must not be cut, drilled, or crushed as harmful asbestos fibers may be released into the air and cause a risk to utility workers and a public health risk
 - National Emission Standards for Hazardous Air Pollutants (NESHAP) regulates work with AC pipe – created by the EPA under the Clean Air Act

Sewer Main Line Repairs

- Main line repairs are required when a sewer line repeatedly shows partial or complete stoppage of flow
- Partial stoppages may only require a mechanical or hydraulic cleaning
- Examples: broken and collapsed pipe, pipe with deep sags, severely offset joints, and shifted service line connections

Sewer Main Line Repairs

- The following describes the procedures for repairing a 2 ft section of 8-inch-diameter main line that is located under the roadway
 - Most small-diameter pipeline of different materials will have a very similar process
 - The preliminary field investigation has been completed including; site visit, utility locating, marking of the repair area, notifications sent to nearby businesses and residents
 - All safety considerations have been made (PPE) and temporary traffic control has been set up

Cutting Pavement

- Repair crew members verify the repair locations by measuring the distance from the designated manhole
 - The distance from manhole to manhole and other important distances are measured to verify the repair location
- Repair crew marks off the area of the pavement to be cut with a chalk line
- An air compressor and a pavement breaker are used to cut the pavement
- The upstream and downstream manholes are opened, and the flow is recorded as well as the depth to the top of the pipe
 - These depths will tell the backhoe operator approximately how deep to excavate

Excavating the Repair Area

- The backhoe operator removes the road surface, subbase rock and soil down to about 2 ft and loads it into a dump truck for disposal
- During the excavation the soil is observed for any change in texture or other signs that could indicate the presence of cross trenches or other underground utilities
- The spoil pile of excavated material to be reused after the pipe repair is kept at least 2 ft from the edge of the trench – 4 ft is recommended.
- The backhoe operator excavates until reaching approximately 6 inches above the sewer main line being careful to avoid damaging the main

Repairing the Pipe

- After shoring is installed and the trench is determined to be safe a ladder is secured in the trench and is left there as long as anyone is in the trench
- All hand tools are lowered into the trench by rope to provide control and avoid injuries from items falling on the operator in the trench
- The operator uses a shovel to dig alongside the pipe and to dig under the main line about 1.5 ft in each direction around the pipe length to be replaced
- Wastewater flow can be bypassed around the section using plugs and pumps, but care must be taken not to surcharge into the surrounding homes and businesses

Repairing the Sewer Pipe

- Before cutting the pipe, the operator in the trench must wear all proper PPE including safety glasses, steel-toed rubber knee-high boots, gloves and an atmospheric alarm unit to monitor for any dangerous gases building up from motorized equipment or wastewater
- Plastic pipe can be cut with either a hand saw or a portable concrete saw, but concrete pipe must be cut with a concrete saw
- The pipe is cut at approximately 1 ft from each side of the break in the main line
- The operator wraps the cutter around the main and cuts the pipe two or three times at both locations
 - This is necessary to prevent the undamaged pipe from chipping or cracking when the damaged section of the pipe is broken free

Repairing the Sewer Pipe

- A miner's pick is used to break out the damaged pipe and the pieces are removed using a bucket and a rope
- After the operator inspects the pipe in both directions from the cut, the distance between the cut ends is measured
- The replacement section of pipe is cut ½-inch shorter than the measured distance to leave ¼-inch gap at each end of the repair section to provide room for the centering stop of the band couplings
- The pipe used for repair does not have to be made of the same material as the original pipe
 - Band couplings are available to connect almost all pipe material combinations and help align and to center the pipes with each other

Repairing the Sewer Pipe

- Bedding material is lowered into the trench, and it is placed in the void under the pipe with enough room at the cut ends to slide the band couplings around the existing main line
- The band couplings are centered on the new section of pipe and the ends are marked
- The couplings are lubricated as per the manufacturer's instructions and then they are slid completely onto the new pipe so that the ends are flush or even

Repairing the Sewer Pipe

- The new section is lowered in line with the existing ends and the couplings are slid over the existing ends to the mark
 - The coupling's center stop should drop into the ¼-inch gap
 - If the couplings do not seat, the pipe section is rotated until it does
- The stainless-steel bands on the couplings are tightened using a special torque speed wrench designed for that coupling
 - If the wrong wrench is used, the pipe or bands can be damaged

Bedding, Backfilling and Compaction

- The bedding material is moved into place by shovel and compacted until it completely covers the pipe by 6 – 12 inches
 - Controlled density fill (CDF) may be used above the bedding in paved areas because it does not require compaction and will not settle over time
- The dump truck fills the trench with road rock to a level about 1 foot above the pavement and then rolled over until even with the pavement
- A pneumatic tamper is used to compact the road rock to 1 or 1 ½ inches below the pavement level
- The work area is cleaned up and the repair area is closed off by barricades with flashers until the paving crew can complete the patch job

Trenchless Repairs

- Trenchless repairs allow the entire pipe section to either be replaced or lined with minimal disruption to the ground surface above the pipe
- Trenchless repairs include
 - Cured-in-Place Pipe (CIPP)
 - Slip Lining
 - Pipe Bursting
 - Grouting
 - Spray-on Liners

Trenchless Repairs

- Chemical grouting is the most widely used method for sealing leaking pipe joints and for sealing circumferential cracks
 - Not used for collapsed pipe sections or broken pipes
- Grout sealing is used in areas unsuitable for excavation and also used in new construction to pass acceptance testing
- Grouting can be used in the repair of main line sewers, pipe joints, lateral sealing, manholes, wet wells, lift stations and can also be used for soil stabilization around effected areas

Chemical Grouting



- Desirable characteristics of grout are:
 - Resistant to organic solvents, mild acids and alkalis
 - Returns to shape after deformation
 - Non-toxic when cured
 - Not rigid or brittle when exposed to freeze/thaw conditions or arid conditions (dry)
 - Non-corrosive and no neurotoxin ingredients
- Two basic groups: Gels and Foams

Chemical Grouting - Foam

- The foam grout forms in place as a gasket and cures to a hard consistency, but retains a rubber-like flexibility
- The seal takes place in the crack or joint and there is only minimum penetration outside the pipe to infiltrate the soil surrounding the area
- The grout is injected directly into a leaking crack, fracture, hole or joint and will expand to fill the void resulting in a tight, impermeable, elastomeric seal
- Foam grouts are more suitable for use if there are significant voids outside the joint area
- Generally, foam grouts are more expensive, more difficult to install and have a significantly longer cure time than gels


Chemical Grouting - Gel

- The gel grout is made to penetrate outside the pipe and to infiltrate the surrounding soil
- The mixture cures to an impermeable condition around the effected area



Chemical Grouting Procedure


- The area to be grouted must be clean of grease, debris and roots
 - Mechanical and hydraulic cleaning must take place before grouting procedure begins
- The surrounding pipe must not have significant deterioration that would interfere with the sealing of the packer or suffer more damage from the pressure of the packers



Chemical Grouting Procedure

1. Locate the repair area with CCTV
2. Pull the packer into position, center the repair area
3. Inflate the packer sleeves until a seal is formed against the inside of the pipe
4. Air test the repair area
5. If the area fails the air test, pump the grout and catalyst solutions under pressure into the void between the inflated sleeves and into the soil if a gel grout is used
6. Inflate the packing element to force the sealing material into the defective area
7. Hold the packing element in the inflated position until the area is cured
8. Deflate the packer sleeves and move the packer to the next area

Chemical Grouting Video




Chemical Grouting – Alternative Methods

- In large-diameter sewers, pressure grouting is accomplished using pipe grouting rings or predrilled injection holes.
 - An operator manually places the ring over the joint and inflates it to isolate the area
 - Sealing grout is pumped into the small void between the pipe wall and the ring
 - After the grout cures, the sealing ring is removed and used on the next joint

Chemical Grouting – Alternative Methods

- The probe injection method uses a hand-held probe but no sealing rings
- This method can be applied to manhole repair
- Holes are drilled into or area
- Grout is pumped directly into the area with hand-held probe

Chemical Grouting Procedure



Manhole Repairs

- Manholes must be maintained and kept in good working condition to enable maintenance personnel to easily access the system
- Manhole frames and covers should be secure and the top should be at the same grade as the surrounding street
 - Manholes can be elevated so they are above the high-water mark in a floodplain or in unimproved easements
- Manhole cones and barrels must be free from cracks and damage from corrosion

Manhole Repairs

- Bottom flow channels should be smooth with shelf areas located above the flowing wastewater and sloped to prevent debris from becoming trapped during surcharge conditions
- Carefully inspect the entire manhole and look for:
 - Structural failures
 - Cracks
 - Missing bricks or mortar
 - Signs of corrosion
 - Condition of trough, benches, and channels
 - Relative elevation of the manhole cover

Raising Manhole Frames and Covers

- Site needs to be prepared
 - Obstacles need to be removed (shrubs, fencing, etc.)
 - Lid needs to be exposed
 - Atmospheric testing
- Determine how far the manhole should be raised
 - Use a straight rod or a 2 in X 4 in board
 - Use a level to be sure that the rod is parallel to grade
 - If the distance is 3 inches or more, a grade ring should be used
 - Two common sizes: 3 inches and 6 inches and 4 inches wide

Raising Manhole Frames and Covers

- After resetting the frame, the grade ring will bring the lid to desired height
- If the manhole needs to be raised more than 3 inches, some utilities prefer to excavate down to the manhole barrel and raise the barrel
 - Attempting a confined space entry into a 2-ft diameter manhole for an extended distance is very difficult

Raising Manhole Frames and Covers



Repairing Manhole Bottoms & Inverts

- After all safety precautions have been taken, the manhole must be thoroughly washed from the casting down to and including the bottom
 - This will clear the walls of roots, mud, grease, debris and pests
- An operator will enter the manhole and inspect the casting, grade rings, cone and barrels for seepage, deterioration and cracks
- The condition of the channel is inspected to determine what actions are needed to correct flow or leakage problems

Repairing Manhole Bottoms & Inverts

- Problems encountered at the bottom of manholes range from having no concrete bottom to improperly constructed channels
- Improperly constructed channels:
 - Flat bottom
 - Basin bottom
 - Low inflow invert elevation
 - High outflow invert elevation – causes a sump or backwater problem

Repairing Manhole Barrels


- Available techniques to repair cracks or leaks include:
 - Patching – usually done during adverse or wet conditions, requires a quick-setting concrete
 - Grouting – uses a quick-setting cementitious grout that is hand applied or sprayed over the surface
 - Lining – involves installing a liner into the manhole structure or applying a sprayed lining material inside the manhole barrel

Repairing Manhole Barrels



Drop Lines in Manholes


- A service lateral that enters a manhole at a higher elevation than the main flow line or channel causes corrosion, odors, splashing, and difficult working conditions



- These higher elevation discharges are usually required to be connected using an inside drop pipe
- The most common type of pipe used for inside drop lines is PVC SDR 35

Drop Lines in Manholes

- An inside drop line connection consists of a tee attached to the incoming pipe that sits flush against the manhole wall with a length of pipe that runs from the tee to the manhole bottom and a 90-degree elbow to direct the flow into the channel at the correct angle



Drop Lines in Manholes

➤ If possible, a sewer line should be connected to a sewer main when it is constructed; however, if the service line must discharge directly to the manhole, then an outside drop line should be used

- Inside drop lines
- are more
- economical after
- the collection
- system is
- constructed and
- in operation



Underground Repair Vocabulary

- | | |
|--------------------------|-----------------------|
| _____ 1. Angle of Repose | _____ 6. Hydrophobic |
| _____ 2. Annular | _____ 7. Sheeting |
| _____ 3. Cross Braces | _____ 8. Spoil |
| _____ 4. Gunitite | _____ 9. Stringers |
| _____ 5. Hydrophilic | _____ 10. Vacuum Test |

- A. Having a strong affinity (liking) to water.
- B. Solid material, such as wooden 2-inch planks or 1¹/₈ –inch plywood sheets or metal plates, used to hold back soil and prevent cave-ins.
- C. The angle between a horizontal line and the slope or surface of unsupported material such as gravel, sand or loose soil. Also called the “natural slope.”
- D. Horizontal shoring members, usually square, rough cut timber, that are used to hold solid sheeting, braces or vertical shoring members in place. Also called wallers.
- E. Shoring members placed across a trench to hold other horizontal and vertical shoring members in place.
- F. Excavated material such as soil from the trench of a sewer.
- G. Having a strong aversion (dislike) for water.
- H. A testing procedure that places a manhole under a vacuum to test the structural integrity of the manhole.
- I. A ring-shaped space located between two circular objects. For example, the space between the outside of a pipe liner and the inside of a pipe.
- J. A mixture of sand and cement applied pneumatically that forms a high-density, resistance concrete.

Underground Repair Questions

1. Why might a sewer line have to be dug up?

2. Why should other utility companies be notified before any excavation?

3. Why are sewer repairs sometimes necessary?

Answers to Vocabulary and Questions

Vocabulary:

- | | | |
|------|------|-------|
| 1. C | 5. A | 9. D |
| 2. I | 6. G | 10. H |
| 3. E | 7. B | |
| 4. J | 8. F | |

Questions:

1. Sewer lines may have to be dug up because they are damaged, blocked, or to retrieve equipment stuck in the line.
2. All utilities in an area should be contacted before excavation so other underground utilities will not be damaged and possibly cause a serious injury (from electric shock or a gas explosion) to operators, the public or property.
3. Wastewater collection system repairs are necessary to correct damage to sewer.

Section 14


Sewer Renewal & Rehabilitation



Sewer Pipeline Rehabilitation

Sewer Pipeline Rehabilitation

- Cured in Place Pipe (CIPP)
- Fold and Form
- Pipe Bursting
- Sewer System Evaluation
- Excavate and Replace
- Grouting
- Sliplining



HDPE pipe sliplining job shown

Why Rehabilitate?

- Restore structural integrity:
 - Corrosion
 - Deterioration
 - Damage from stress & live loads
- Control excess I/I during rainfall or high groundwater




Sewer System Evaluation

- Helps reduce hydraulic load to sewer and treatment facility. I/I causes:
 - Increased treatment costs
 - Bypassing of untreated wastewater
 - Structural failure weakened collection system
- Primary tool for identifying high I/I: flow monitoring

Techniques to Determine Sewer Condition

- CCTV: most effective method to identify & quantify defects
- Pipe flow tests
- Computer flow models
- Visual inspection
 - Smoke tests- quick, inexpensive
 - Dye testing
 - Lamping

Excavate and Replace

- Oldest and most common method
- Corrects misalignment of pipe
- Sometimes only method if defect is severe
- Should be considered on every job
- Exfiltration may contaminate groundwater used as drinking water source

Excavate and Replace

- Same problems apply as with all new construction.
- Increases hydraulic capacity
- Repair bad service connections
- Eliminate sources of stormwater entry
- Removal incidental I/I
- Stop exfiltration

Common Construction Problems

- Traffic disruption much longer than with other methods.
- Restoration includes paving, driveways, sidewalks, fences, landscaping.
- Often more expensive, too.
- Other issues:
 - Shoring
 - Excavation dewatering
 - Noise



Internal Sealing

- Internal sealing is effective when the sewer line to be repaired has cracks and leaking joints




Chemical Grouting

- Most widely used method to seal leaking joints and circumferential cracks
- Remove roots and grease first
- Dig up joint or do low pressure air test to determine success of chemical grouting



Sliplining

- New liner of smaller diameter placed inside existing pipe
- Not completely trenchless as insertion pit must be dug
- Continuous (shown): 40 ft sections butt-fusion welded
 - Also segmental and spiral wound
- Laterals reconnected by remote-cutter or excavation




Sliplining Features

- Insertion pit required for segmented & continuous
- Reduced pipe diameter
- Not well suited for small diameter pipes
- Requires little technical skill
- Excellent corrosion resistance

Spiral Wound Sliplining Process

- Annular space is grouted to prevent leaks and provide structural integrity
- Spiral wound pipe with interlocking edges to connect segments




Spiral Wound Sliplining Process



Cured-in-Place Pipe (CIPP)

- Pipe is cleaned and CCTV inspection is done
- Custom made felt tube is impregnated with thermosetting resin
- Weight of water pushes tube into damaged pipe & turns it inside out
- Laterals are cut internally




Cured-in-Place Pipe (CIPP)

- Flexible fabric liner coated with thermosetting resin
 - Each sock is custom made for specific job
 - Keep ≤ 40°F and out of direct sunlight
 - Heat may cause resin to react and begin to harden
 - UV light deteriorates material




Cured-in-Place Pipe (CIPP)

- Pipe inverted with water (shown) or air
- Laterals are reconnected with robotic cutter positioned and controlled by operator watching TV monitor
 - Laterals easily found since line was televised after cleaning and prior to start of rehab project



CIPP Features

- No grouting or excavation required
- New pipe has no joints or seams
- Bypass or diversion of flow required
- Must allow adequate curing time
- Small decrease in pipe diameter, but improved flow capacity due to smooth surface
- Proprietary



Fold and Formed Pipe


- HDPE or PVC pipe is deformed in shape & inserted into host pipe
- Liner is pulled through existing line, heated and pressurized to original shape
- Bypass or diversion of flow required
- Laterals reconnected internally
- No grouting or excavation
- No joints or seams

U-Liner® Installation

- Host pipe is thoroughly cleaned and inspected with CCTV
- Pipe is uncoiled into upstream manhole and pulled through host pipe via cable from downstream manhole. Pipe is cut to the appropriate length and manifolds are attached at both ends

U-Liner® Installation

- Heat and pressure are applied to conform new pipe to host pipe
- Individual service connections are restored with internal cutter. Device is remote-controlled, video monitored, and cuts precisely



Pipe Bursting

- Insertion pit is excavated
- Deteriorated host pipe is broken outward by means of an expansion tool and new pipe (black) is towed behind the bursting machine
- Laterals reconnected by excavation after job is done

Bursting Heads

- Pneumatic (static) head has no moving internal parts and expands existing pipe through pulling
- This model features a cutter to aid in shattering the host pipe

Hydraulic head pulsates as the bursting device is pulled through the pipe

Pipe Bursting Features

- New pipe is PE, PP, PVC or GFR
- No reduction in capacity; can often upsize the new pipe
- Bypass or diversion of flow
- Insertion pit required
- Not suitable for all materials: can replace vitrified clay, cast iron, unreinforced concrete, & some PVC

Pipe Bursting

Pipe Bursting

Pipe Bursting

Sewer Renewal Vocabulary

- | | |
|-------------------------|---------------------|
| _____ 1. Annular | _____ 4. Inflow |
| _____ 2. Flow Isolation | _____ 5. Piezometer |
| _____ 3. Infiltration | _____ 6. Surge |

- A. The seepage of groundwater into a sewer system, including service connections. Seepage frequently occurs through defective or cracked pipes, pipe joints, connection or manhole walls.
- B. A ring-shaped space located between two circular objects. For example, the space between the outside of a pipe liner and the inside of a pipe.
- C. The supply of water to be carried is greater than the capacity of the pipes to carry the flow. The surface of the wastewater in manholes rises above the top of the sewer pipe and the sewer is under pressure or a head, rather than at atmospheric pressure.
- D. Water discharged into a sewer system and service connections from such sources as, but not limited to, roof leaders, cellars, yard and area drains, foundation drains, cooling water discharges, drains from springs and swampy areas, around manhole covers or through holes in the covers, cross connections from storm and combined sewer systems, catch basins, storm waters, surface runoff, street wash waters or drainage.
- E. A procedure used to measure inflow and infiltration (I/I). A section of sewer is blocked off or isolated and the flow from the section is measured.
- F. An instrument used to measure the pressure head in a pipe, tank or soil.

Sewer Renewal Questions

- 1. What causes sewers to lose their structural integrity?

- 2. What problems are common to all types of sewer construction?

- 3. Why should a lateral be lined?

4. What is the oldest and most common method of sewer rehabilitation?

5. What is the most common method of sealing leaking pipe joints and circumferential cracks?

True-False

6. Flows greater than the expected base flow can be considered to come from inflow and infiltration sources.
True
False

7. Smoke testing is a slow and expensive method of detecting illegal I/I sources in a sewer system.
True
False

Multiple Choice

8. The first step in defining a sewer rehabilitation program is to:
 - a. Analyze condition of the system
 - b. Collect flow measurement data
 - c. Conduct an inventory of the system
 - d. Set goals of rehabilitation program

9. Exfiltration can be a serious problem in areas where exfiltration flow can:
 - a. Cause flooding of surface water
 - b. Contaminate groundwater used for public drinking water supply
 - c. Overload lift stations
 - d. Reduce scouring velocities in sewers

10. The CIPP saturated liner should be kept:
 - a. At ambient temperature until installation
 - b. At or below 40° F (4° C)
 - c. Out of direct sunlight
 - d. Dry until installation
 - e. B and C

11. When a service connection has suffered total collapse and is in a crushed condition, the service connection is restored by:
 - a. Chemical grout
 - b. Cured-in-place pipe
 - c. Excavation and replacement
 - d. Sliplining

12. When manhole walls have suffered deterioration due to hydrogen sulfide attack, they can be repaired with:
 - a. Coating processes
 - b. Excavation and replacement
 - c. Grout
 - d. Paint
 - e. Sliplining

Answers to Vocabulary and Questions

Vocabulary:

- | | |
|------|------|
| 1. B | 4. D |
| 2. E | 5. F |
| 3. A | 6. C |

Questions:

1. Due to corrosion and deterioration, damage also results from undue stress and live loads placed on sewers.
2. Traffic disruption, disruption to properties, paving damage, shoring requirements, excavation dewatering, noise, flow control and restoration
3. Laterals are lined if infiltration, exfiltration or root intrusion is a problem.
4. Excavation and replacement
5. Chemical grouting
6. True
7. False
8. C
9. B
10. E
11. C
12. A

Section 15
Rules & Regulations

**RULES
OF
THE TENNESSEE DEPARTMENT OF ENVIRONMENT AND CONSERVATION
BOARD OF WATER AND WASTEWATER OPERATOR CERTIFICATION**

**CHAPTER 0400-49-01
RULES GOVERNING WATER AND WASTEWATER OPERATOR CERTIFICATION**

TABLE OF CONTENTS

0400-49-01-.01	Application for Certificate	0400-49-01-.08	Classification of Wastewater Treatment Plants and Wastewater Collection Systems
0400-49-01-.02	Examinations		
0400-49-01-.03	Fees		
0400-49-01-.04	General	0400-49-01-.09	Classifications and Qualifications of Wastewater Treatment Plant Operators and Wastewater Collection System Operators
0400-49-01-.05	Definitions		
0400-49-01-.06	Classifications of Water Treatment Plants and Water Distribution Systems		
0400-49-01-.07	Classifications and Qualifications of Water Treatment Plant Operators and Water Distribution System Operators	0400-49-01-.10	Continuing Education
		0400-49-01-.11	Summary Suspension and Revocation of Certificate
		0400-49-01-.12	Civil Penalties

0400-49-01-.01 APPLICATION FOR CERTIFICATE.

- (1) Application for certification by examination.
- (a) A separate application for each certification shall be made on an original form approved by the Board for that purpose and available upon request from the Secretary of the Board.
- (b) An application for certification must be submitted to the Secretary of the Board and include the following items:
1. A sworn application signed by the applicant.
 2. Payment of a non-refundable \$100 fee for each application for examination.
 3. A copy of any verifying document in support of an application must be submitted with the application unless the applicant has previously provided such documentation to the Secretary of the Board. This includes, but is not limited to, proof of high school education or equivalent of the applicant. College transcripts, if needed to document experience credit, must be submitted directly from the college and/or university to the Secretary to the Board. Credit for enrollment in special training courses and programs will only be granted to an applicant upon verification that he/she satisfactorily completed all course or program requirements. If training credit is requested, a copy of a course attendance card, a class roster, or a certificate of completion must be submitted to the Secretary. Verification of work experience must be provided in a written document signed by a certified operator of a similar or higher classification, familiar with the applicant's work experience. However, if no such person is available, it may be documented by a person in authority with the system. The Board may exempt applicants from the verification of work experience requirement where there are unusual circumstances.
- (c) A complete application must be received by the Secretary sixty (60) days or more in advance of the scheduled examination date for consideration. Applications received less than sixty (60) days prior to an examination date will be reviewed for the next examination. Upon written request by an applicant, the Board may choose to review,

(Rule 0400-49-01-.02, continued)

- (5) An applicant shall be notified in writing whether his/her examination score was satisfactory for the issuance of a certificate.
- (6) An applicant who fails to achieve a satisfactory score may reapply for the next examination by submitting an abbreviated application for examination with fees, but he/she shall not be eligible to take another examination for the particular operator classification which he/she failed until five months have elapsed from the date that examination was taken.
- (7) All examinations shall be administered by the Board or its authorized representatives who are empowered to maintain the integrity of all examinations.
- (8) (a) An applicant shall be guilty of cheating upon a written examination who does an act including, but not limited to, the following:
 - 1. violates paragraph (2) of this rule; or
 - 2. without express authorization from examination officials,
 - (i) removes examination materials furnished by the Board or the written examination itself, in whole or in part, from the examination room, or
 - (ii) aids another applicant in answering examination questions during a written examination; or
 - 3. violates the examination rules.
- (b) Upon a determination by the Commissioner that an applicant is guilty of cheating upon a written examination for a particular operator classification, the applicant shall not be issued an initial certificate of competency for that classification.
- (c) An applicant shall be ineligible to again apply for certification in that same operator classification for one year from the date the determination of cheating becomes final.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03. Amendments filed January 18, 2017; effective April 18, 2017.

0400-49-01-.03 FEES.

- (1) Fees for Certification
 - (a) Fees for certification shall be required of each applicant and paid in advance as follows:
 - 1. Application fee for each operator examination or reciprocity request applied for\$100
 - 2. Discount annual renewal fee for each operator certificate:
(Payment prior to February 1).....\$50
 - 3. Standard annual renewal fee for each operator certificate:
(Payment from February 1 through June 30.).....\$100
 - (b) No application fee will be returned.

(Rule 0400-49-01-.03, continued)

- (c) Upon payment of an application fee and approval by the Board, an applicant may take any one scheduled examination during the following twelve (12) months. If an applicant chooses not to take or fails to appear for, the first examination offered after receiving approval, the applicant must register on a form approved by the Board to be scheduled for a subsequent exam within the established time. The registration must occur sixty (60) days in advance of the examination he/she wishes to take. If an applicant does not take the examination within twelve (12) months of the Board's approval, he/she must reapply by submitting a new application with fees in order to be considered to take a subsequent examination.

 - (d) Each year a certified operator shall submit to the Board for the following year a completed certificate renewal application and a fee for the renewal of each operator certificate he/she possesses. Applications received prior to February 1 of each year shall be subject to discount renewal fees. Applications received February 1 through June 30 of each year shall be subject to standard renewal fees. Any person failing to meet the June 30 deadline may, within sixty (60) days of the deadline, request that the Board grant a variance. A variance may be granted when the delay was caused by Board or staff error, Board action, or documented postal error. A completed certificate renewal application or appropriate annual renewal fee for an expired certificate not received by the Board by June 30 shall preclude the recertification of the operator in his/her expired classification until he/she shall have fulfilled all the requirements for the issuance of an initial certificate in that classification, including the satisfactory completion of a written examination. When an operator classification is upgraded, the certificate he/she was upgraded from becomes void; and no additional fee payment is necessary until renewal.
- (2) Fees for Cross Connection Control Training Registration
- (a) Fees for Cross Connection Control Training registration shall be required of each person and paid in advance as follows:
 - 1. Registration fee for a Cross Connection Control Basic Class (full time employees of public water systems as defined in T.C.A. § 68-221-703 and Department employees who assist with cross connection control training or testing classes are exempt).....\$275
 - 2. Registration fee for a Cross Connection Control Renewal Class (full time employees of public water systems as defined in T.C.A. § 68-221-703 and Department employees who assist with cross connection control training or testing classes are exempt)..... \$110
 - (b) No registration fee will be returned.
 - (c) The registration fee must be received thirty (30) days in advance of the class he/she wishes to take.
- (3) Fees for Cross Connection Control Testing Application
- (a) Fees for Cross Connection Control Testing Application shall be required of each person and paid in advance as follows:
 - 1. Application for a Cross Connection Control Basic Test (Department employees who assist with cross connection control training or testing are exempt).....\$60

(Rule 0400-49-01-.03, continued)

2. Application fee for Cross Connection Control Renewal Test (Department employees who assist with cross connection control training or testing are exempt).....\$60
- (b) Application fees are not refundable or transferable.
- (c) The application for testing conducted by the Department must be received a minimum of thirty (30) days in advance of the test he/she wishes to take, however, applications from private institutions may be received the day the test materials are submitted to the Fleming Training Center.
- (d) Prior to sitting for a test, an applicant must present proof of completion of training accepted by the Department for the appropriate test. Basic training may be accepted by the Department if it has a minimum class length of 480 minutes (300 minutes minimum in classroom), including but not limited to the following topics: hydraulic and backflow principles, theory of backflow and cross connection, codes and regulations of a cross connection control program, responsibilities and actions in a cross connection control program and mechanical equipment for cross connection control. Acceptable training must also provide a minimum of one working practice station and test kit for each three students. Renewal training may be accepted by the Department if it has a minimum class length of 300 minutes (180 minutes minimum in classroom) including but not limited to the following topics: hydraulic and backflow principles, theory of backflow and cross connection, codes and regulations of a cross connection control program, responsibilities and actions in a cross connection control program and mechanical equipment for cross connection control. Acceptable training must also provide a minimum of one working station and test kit for each three students.
- (e) An applicant must take the test within twelve (12) months of receipt of the training certificate.

Authority: T.C.A. §§ 4-5-201 et seq., 68-203-101 et seq., 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03. Amendments filed January 18, 2017; effective April 18, 2017.

0400-49-01-.04 GENERAL.

- (1) Certification under T.C.A. §§ 68-221-901 et seq., being the “Water and Wastewater Operator Certification Act,” is available to any operator of a water treatment plant, a wastewater treatment plant, a water distribution system, or a wastewater collection system who meets the minimum qualifications of a given classification.
- (2) Each person in direct charge at a water treatment plant, a wastewater treatment plant, a water distribution system, or a wastewater collection system shall hold a certificate in a grade equal to or higher than the grade of the treatment plant, distribution system, or collection system he/she operates. The grade of a facility will be established by the criteria set forth in this chapter of rules.
- (3) All operating personnel making process control/system integrity decisions about water quality or quantity that affect public health must be certified. A designated certified operator must be available for each operating shift.
- (4) Each water supply system and wastewater system required to have a certified operator shall, no later than the first day of August annually, inform the Board, through its designated agent, the Division of Water Resources, in writing of the name of each person who is a certified operator in direct charge of any water treatment plant, wastewater treatment plant, water

(Rule 0400-49-01-.04, continued)

distribution system or wastewater collection system it operates. A system shall notify the Division of Water Resources in writing within thirty (30) days of its loss of the services of a certified operator in direct charge.

- (5) A certified operator shall be responsible for keeping the Board Secretary informed of his/her current address.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-.05 DEFINITIONS.

- (1) "Available" means that a certified operator must be on site or able to be contacted as needed to initiate the appropriate action in a timely manner, based on system size, complexity and the quality of either the source water or the receiving stream.
- (2) "Board" means the board of certification as described in T.C.A. § 68-221-905.
- (3) "Commissioner" and "Department" mean the Commissioner of the Tennessee Department of Environment and Conservation or his/her duly authorized representative.
- (4) "Operating Shift" is that period of time during which operator decisions that affect public health are necessary for proper operation of the system.
- (5) "Process control/system integrity decisions" means decisions regarding the manipulation of equipment, chemicals or processes that determine the quality and quantity of the water supplied by a water treatment plant or a water distribution system, or the quality of the effluent from a wastewater treatment plant or the integrity of a wastewater collection system.
- (6) "Person in direct charge" as used in these rules means the person or persons expressly designated to be in direct charge and so named in writing to the Board's authorized representative by each water supply system and wastewater system, whose decisions and directions to system personnel control the manipulation of equipment and thereby determine the quality and quantity of the water supplied by a water treatment plant or a water distribution system, or the quality of the effluent from a wastewater treatment plant or the integrity of a wastewater collection system.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-.06 CLASSIFICATION OF WATER TREATMENT PLANTS AND WATER DISTRIBUTION SYSTEMS.

- (1) Water treatment plants shall be classified by the Board or its authorized representative into one of five groups, designated either as Small Water, Grade I, II, III, or IV. These classifications shall be made according to the number of population served, the type of treatment plant, and the complexity of treatment required for a particular water.
- (2) The classification of a water treatment plant or a water distribution system may be changed by the Board or its authorized representative because of changes in the conditions or the circumstances upon which the original classification was based. Notice of such a classification change shall be given to the management officers of the plant or system.
- (3) Types of Water Systems:

(Rule 0400-49-01-.08, continued)

Push-button or visual methods for simple tests such as pH, settleable solids	3 pts.
Additional procedures such as DO, COD, BOD, gas analysis, titrations, solids, volatile content	5 pts.
More advanced determinations such as specific nutrients, total oils, phenols, etc	7 pts.
Highly sophisticated instrumentation such as atomic absorption and gas chromatography	10 pts.

These terms describe the minimum level of effluent quality attainable for treated wastewater under standard design conditions in terms of the arithmetic mean of the values for effluent samples collected in a period of thirty (30) consecutive days for the following parameters: five-day biochemical oxygen demand (BOD₅); total suspended solids (TSS); and acidity/alkalinity (pH).

1. "Equivalent to secondary wastewater treatment" means the 30-day average for BOD₅ does not exceed 45 mg/l and there is no ammonia limit.
 2. "Secondary wastewater treatment" means the 30-day average for BOD₅ does not exceed 30 mg/l and there is no ammonia limit.
 3. "Advanced secondary wastewater treatment" means that the biochemical oxygen demand is expressed as the carbonaceous form (CBOD₅) that is equal to or greater than 10 mg/l and is equal to or less than 25 mg/l; and there is an ammonia limit.
 4. "Tertiary wastewater treatment" means that the CBOD₅ is less than 10 mg/l and there is an ammonia limit.
- (b) Grade I Collection System. This classification is for a wastewater collection system that uses collector and/or transmission lines to transport wastewater to a treatment plant and which serves no more than five thousand (5,000) service connections.
- (c) Grade II Collection System. This classification is for a wastewater collection system that uses collector and/or transmission lines to transport wastewater to a treatment plant and which serves more than five thousand (5,000) service connections.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-.09 CLASSIFICATIONS AND QUALIFICATIONS OF WASTEWATER TREATMENT PLANT OPERATORS AND WASTEWATER COLLECTION SYSTEM OPERATORS.

- (1) (a) Grade IV Wastewater Treatment Plant Operator

Certification as an operator in this classification will be made only upon the satisfactory completion by the applicant of the requirements of either parts 1 or 2 of this subparagraph.

1. An applicant must have a bachelor degree in engineering, chemistry or a related science from an accredited college or university, must have twelve (12) months of operating experience at a Grade III or a Grade IV Wastewater Treatment plant, and must satisfactorily complete a written examination.

(Rule 0400-49-01-.09, continued)

- Pumps
- Lift stations
- Valves
- Lines and equipment
- Pipeline installation
- Service connection installation
- Leak detection
- TV crew activities
- Line repairs
- Line cleaning
- Manhole maintenance
- Pretreatment

(5) Summary of Wastewater Treatment Plant and Collection System Operator Education and Experience

Wastewater Treatment Plant Operators

Classification	Experience			Maximum Training or College Classwork Substitution	Maximum Related Work Substitution
	Experience needed with:	HS Education	BS Degree		
Grade IV	Gained at a Grade III or IV Wastewater Plant	*60 months	12 Months	36 Months	24 Months
*Regardless of the substitution allowances, a minimum of 1 year of actual work experience is required					
Grade III	Gained at a Grade II or III Wastewater Plant	12 Months		3 Months	
Grade II	Gained at a Grade I or II Wastewater Plant	12 Months		3 Months	
Grade I	Gained at a Grade I Wastewater Plant	12 Months		3 Months	
	Gained at Biological/Natural and Grade I Wastewater Plant	12 Months 6 Months			
Grade BNS	Gained at a BNS Wastewater Plant	12 Months		3 Months	

COLLECTION SYSTEM OPERATORS

Classification	Experience		Maximum Training or College Classwork Substitution	Maximum Related Work Substitution
	Experience needed with:	HS Education		
Grade II	Gained at a Collection I or II System	12 Months	3 Months	
Grade I	Gained at a Collection I or II System	12 Months	3 Months	

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-10 CONTINUING EDUCATION.

At least once during every continuing education period each certified operator shall satisfactorily complete the required number of continuing education hours approved by the Board for the particular type of certificate he/she holds. The continuing education period for a certified operator shall begin either with the date the certified operator obtained his/her certificate or the date the certified operator last satisfactorily completed the required number of continuing education hours and shall end at the conclusion of the annual continuing education term three (3) calendar years thereafter. An annual continuing education

(Rule 0400-49-01-.10, continued)

term shall begin each year on October 1 and shall end on September 30 of the following year. The failure of an operator to satisfactorily complete the required number of continuing education hours approved by the Board Secretary during his/her continuing education period shall be grounds for the denial of his/her application for the renewal of his/her certificate. An operator shall notify the Board Secretary upon his/her satisfactory completion of the continuing education requirement by furnishing appropriate documentation of course completion. Notification by the operator is not necessary in those cases where an agency notifies the Board Secretary of such activity. An operator that fails to satisfactorily complete the required number of continuing education hours during his/her continuing education period due to an unusual event such as an incapacitating illness or similar unavoidable circumstances may make a written request to the Board for an extension of time to do so. All requests by an operator for an extension of time to meet the continuing education requirement must be made in writing to the Board either within two (2) months of the elapsed continuing education period or by the date of return of the operator to active employment, whichever is later. All such requests must be accompanied by complete supporting documentation of the circumstances causing the failure to meet the continuing education requirement.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-.11 SUMMARY SUSPENSION AND REVOCATION OF CERTIFICATE.

- (1) An operator's certificate may be revoked when:
 - (a) In accordance with paragraph (2) of this rule, an operator has not used reasonable care, judgment, or the application of his/her knowledge in the performance of his/her duties as a certified operator, or
 - (b) In accordance with paragraph (3) of this rule, an operator is incompetent to perform those duties properly; or
 - (c) In accordance with paragraph (4) of this rule, an operator has practiced fraud or deception.
- (2) An operator shall be deemed to have not used reasonable care, judgment, or the application of his/her knowledge in the performance of his/her duties if he/she does not comply with the laws, rules, permit requirements, or orders of any governmental agency or court which govern the water supply system or the wastewater system he/she operates. Such acts of noncompliance include but are not limited to the following:
 - (a) The intentional or the negligent failure by the operator or persons under his/her supervision to act that results in a water supply system facility or a wastewater system facility not operating in the manner in which it is capable of being operated for the performance of its designed function.
 - (b) The intentional or the negligent failure by the operator or persons under his/her supervision to comply with the monitoring, sampling, analysis, or reporting requirements for a water supply system facility or a wastewater system facility.
 - (c) The intentional or the negligent unlawful discharge of wastes from a water supply system facility or a wastewater system facility.
 - (d) The intentional or the negligent failure by the operator or persons under his/her supervision to notify the Department of conditions: which may affect the quantity or quality of water being supplied to the customers of a water supply system; which cause the pollution of the waters of the State of Tennessee; or, which are violative of a standard of water quality promulgated by any governmental agency.

(Rule 0400-49-01-.11, continued)

- (3) An operator shall be deemed to be incompetent to perform his/her duties properly when he/she does not possess the basic skills and knowledge necessary to operate a water supply system facility or a wastewater system facility including laboratory functions or if he/she fails to have a system of verification and oversight of employees under his/her charge. Incompetency shall be determined by examining the technical skills of the operator in operating the type of facility of which he/she is in direct charge.
- (4) An operator shall be deemed to have practiced fraud or deception as follows:
 - (a) Obtained his/her certificate through fraud, deceit, or the submission of inaccurate data regarding his/her qualifications upon his/her application for a certificate.;
 - (b) Has practiced fraud or deception during the performance of his/her duties as a certified operator; or
 - (c) Has prepared and/or signed reports of laboratory analysis results for the system that:
 1. Contain inaccurate data and are known or should be known by the operator to be false; or,
 2. Contain inaccurate data because the operator has not used reasonable care, judgment, or the application of his/her knowledge either in the performance of the laboratory analysis or in the preparation of the laboratory analytical reports.
- (5) Revocation
 - (a) The Commissioner may initiate the process to revoke a certificate when he/she believes an operator has engaged in any of the activities set forth in paragraph (1) of this rule.
 - (b) The Commissioner shall give notice by mail to the affected operator of facts or conduct that warrants revocation of the certificate and give the affected operator an opportunity to show compliance with these rules by conducting an informal hearing as provided in T.C.A. § 4-5-320(c).
 - (c) After the T.C.A. § 4-5-320(c) informal hearing, if the Commissioner determines that the affected operator has failed to demonstrate compliance, the Commissioner shall issue a notice of hearing for revocation and include a recommendation to the Board to revoke and reinstate or not to reinstate the certificate. Any recommendation of reinstatement of the certificate shall include terms for such reinstatement.
 - (d) The notice of hearing for revocation shall contain the information required by part 1 of this subparagraph and be served in accordance with part 2 of this subparagraph.
 1. The notice shall include:
 - (i) A statement of the time, place, nature of the hearing, and the right to be represented by counsel;
 - (ii) A statement of the legal authority and jurisdiction under which the hearing is to be held, including a reference to the particular sections of the statute and rules involved; and

(Rule 0400-49-01-.11, continued)

(iii) A short and plain statement of the facts or conduct that warrant a revocation. (If the Commissioner is unable to state the matters in detail at the time the notice is served, the initial notice may be limited to a statement of the issues involved. Thereafter, upon timely, written application a more definite and detailed statement shall be furnished ten (10) days prior to the time set the hearing.)

2. A copy of the notice of hearing shall be:

(i) Served upon the operator no later than thirty (30) days prior to the hearing date; and

(ii) Served by personal service, return receipt mail or equivalent carrier with a return receipt,

A person making personal service on the operator affected shall return a statement indicating the time and place of service, and a return receipt must be signed by the operator affected. However, if the affected operator evades or attempts to evade service, service may be made by leaving the notice or a copy of the notice at the affected operator's dwelling house or usual place of abode with some person of suitable age and discretion residing therein, whose name shall appear on the proof of service or return receipt card. Service may also be made by delivering the notice or copy to an agent authorized by appointment or by law to receive service on behalf of the affected operator, or by any other method allowed by law in judicial proceedings.

(6) Summary Suspension and Revocation

(a) The Commissioner may initiate the process of summary suspension and revocation of the certificate when the Commissioner believes that an emergency action is needed to protect the public health, safety or welfare.

(b) The Commissioner shall give a notice to the affected operator by any reasonable means and shall inform the affected operator of the intended action, the acts or conduct that warrants summary suspension and revocation of the certificate and hold an informal hearing, as provided in T.C.A. § 4-5-320(d), to give the operator an opportunity to address the issue of whether there is an emergency.

(c) The Commissioner shall appoint a hearing officer to conduct this T.C.A. § 4-5-320(d) hearing and the hearing shall be recorded and transcribed.

(d) After the informal hearing as provided in T.C.A. § 4-5-320(d), if the Commissioner determines that an emergency action is warranted, the Commissioner shall issue an Order of Summary Suspension and a notice of hearing for revocation and include a recommendation to the Board to reinstate or not to reinstate the certificate. Any recommendation of reinstatement of the certificate shall include terms for such reinstatement.

(e) The Order of Summary Suspension and the notice for revocation shall contain the information required by part (5)(d)1 of this rule and be served in accordance with part (5)(d)2 of this rule.

(f) When the Commissioner has issued an Order of Summary Suspension and Notice of Revocation, the Board shall conduct its revocation hearing and render a decision within ninety (90) days of the operator's summary suspension. In the event the Board does

(Rule 0400-49-01-.11, continued)

not render its decision within ninety (90) days of the operator's summary suspension, the Order of Summary Suspension shall expire and no longer be in force or effect. However, the Commissioner may reissue an Order of Summary Suspension in accordance with this paragraph, for a period not to exceed ninety (90) days.

- (7) The revocation hearing before the Board shall be held in accordance with T.C.A. §§ 4-5-301 et seq. and Rule Chapter 1360-04-01 Uniform Rules of Procedure for Hearing Contested Cases Before State Administrative Agencies.
- (8) The Board may revoke the certificate of an operator when it is found that the operator has practiced fraud or deception; that reasonable care, judgment or the application of such operator's knowledge was not used in performance of such operator's duties; or that the operator is incompetent to properly perform such operator's duties. If the certificate is revoked and is to be reinstated, the Board shall determine the timing, terms and conditions for reinstatement.
- (9) An operator who receives an order of the Board for the revocation of his/her certificate may appeal the order to the Chancery Court of Davidson County within sixty (60) days.
- (10) An operator whose certificate is revoked for failure to use reasonable care, judgment or the application of operator knowledge in performing the operator's duties or for incompetency shall be ineligible to again apply for certification as an operator for a minimum of one (1) year. An operator whose certificate is revoked for practicing fraud or deception, willfully violating regulations or permit conditions, or falsifying records and reports shall be ineligible to again apply for certification as an operator for a minimum of five years. When an operator whose certificate has been revoked has applied for a certificate after the minimum time has passed, the Board shall determine whether the operator has taken appropriate action to address the circumstances that were the cause of the revocation. The Board may request records and review his/her experience, education, training and past performance. The Board may request the former operator's presence at a meeting of the Board and interview him/her to assess the potential of future violations. After the reviews, the Board shall decide to accept or refuse the application.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

0400-49-01-.12 CIVIL PENALTIES.

- (1) The Commissioner may assess the civil penalty authorized by law against a municipality, utility district, corporation, or any person operating a water supply system or a wastewater system if the competency of the person in direct charge of a system facility has not first been certified in accordance with these rules.
- (2) A certified operator may be assessed the civil penalty authorized by law for the same acts and omissions that would constitute grounds for the revocation of his/her certificate by the Board.
- (3) Prior to issuing an order that assess a civil penalty, in accordance with paragraphs (1) and (2) of this rule the Commissioner may hold a show cause meeting with the person or entity to whom the order is proposed to be issued.

Authority: T.C.A. §§ 4-5-201 et seq. and 68-221-901 et seq. **Administrative History:** Original rule filed May 21, 2014; effective August 19, 2014. Rule renumbered from 1200-05-03.

**RULES
OF THE
DEPARTMENT OF ENVIRONMENT AND CONSERVATION
DIVISION OF WATER RESOURCES**

**CHAPTER 0400-40-16
PUBLIC SEWERAGE SYSTEMS**

TABLE OF CONTENTS

0400-40-16-.01	Definition of Terms	0400-40-16-.04	Interconnections or other Connections with Potable Water Supply
0400-40-16-.02	Supervision over Construction of Public Sewerage Systems	0400-40-16-.05	Investigations, Reports, and Recommendations, Standards, and Orders
0400-40-16-.03	Supervision over Operation of Public Sewerage Systems		

0400-40-16-.01 DEFINITION OF TERMS.

- (1) **Public Sewerage System.** The conduits, sewers, and all devices and appurtenances by means of which sewage is collected, pumped, treated and disposed of finally. This shall include systems owned by municipalities, utility districts, those corporately owned, state owned, and all others serving the public, including industrial wastes discharged into public systems.
- (2) **Sewage.** All water carried wastes from residences, buildings, institutions, or industrial establishments that are connected to a public sewerage system, together with such ground, surface, or storm water as may be present.
- (3) **Department.** The Tennessee Department of Environment and Conservation through its executive officer, the Commissioner of Environment and Conservation, or his designated representative.
- (4) **Person.** Any and all persons, natural or artificial, including any individual, firm or association, and any municipal or private corporation organized or existing under the laws of this or any other state or country.

Authority: T.C.A. §§ 68-221-101 et seq. and 4-5-201 et seq. **Administrative History:** Original rule filed September 17, 2013; effective December 16, 2013. Rule renumbered from 1200-05-02.

0400-40-16-.02 SUPERVISION OVER CONSTRUCTION OF PUBLIC SEWERAGE SYSTEMS.

- (1) **Preliminary Informations.**

Whenever any new construction or any change of an existing system is contemplated, a statement concerning the proposed construction or change together with such preliminary plans, reports, operating cost data, construction cost estimates, and any other necessary data shall be submitted to the Tennessee Department of Environment and Conservation. These data will be reviewed by the Department to determine if sufficient information has been provided for review of the project and if the proposed project meets the Department's general design criteria and if additional changes will be necessary prior to preparation of the final plans and specifications. The Department's approval should be obtained in writing prior to preparation of the final plans and specifications.

- (2) **Sewage Samples.**

Whenever any new construction or changes of an existing system involving the treatment works is contemplated representative samples of the sewage shall be properly collected and

(Rule 0400-40-16-.02, continued)

analyses are directed by the Department. These data and any other pertinent information shall be submitted to the Department.

(3) Final Plans.

Before work is commenced on any new construction or change of an existing system, final plans and specifications and cost estimates, together with such additional data as may be necessary to determine the suitability of the works, shall be submitted to the Tennessee Department of Environment and Conservation, and no part of the work shall be started until the Department has given its written approval. All such plans should be submitted at least 30 days prior to the date upon which action of the Department is desired. After construction has been completed, a set of "As Built" plans shall be submitted to the Department.

(4) Revision of Plans.

All changes in the plans and specifications requested by the Department must be made and approved by the Department prior to construction. In case it is necessary or desirable to make any additional changes in the approved plans and specifications, revised plans and specifications, together with a statement of the reasons for the changes, shall be submitted to the Tennessee Department of Environment and Conservation for review and no part of the work affected by the change shall be started until the Department has given its approval in writing.

(5) Work in Conformity with Plans and Specifications.

A copy of the approved plans and specifications shall be available at the job site at all times during construction. All work on new construction or changes of existing systems shall be done in conformity with the approved plans and specifications. The consulting or design engineer shall provide adequate inspection during construction to ascertain that all work is done in accordance with the approved plans and specifications.

The Department's representative shall have access to the project at all times during construction. If the Department's representative observes work being done in a manner that does not conform to the approved plans and specifications, a request will be made through the engineer's representative or directly to the contractor to cease all work until the nonconformity with the approved plans and specifications has been rectified.

(6) Records of Existing Works.

Whenever there is any question concerning the suitability of existing structures, equipment or other parts of the sewerage system to perform the function for which intended, the Department may require the submission of plans or other data necessary to ascertain the details of such works in relation to their possible direct or indirect effect upon public health.

(7) Sewer Use Ordinance.

The governing body of each public sewerage system shall enact an ordinance that will state:

- (a) the type materials, construction, and inspection of service lines connecting to the public sewer,
- (b) the limits of the physical and chemical characteristics of the sewage that will be discharged to the system by the users, and
- (c) any surcharges that will be assessed when the limits of the physical and/or chemical characteristics are violated.

(Rule 0400-40-16-.02, continued)

A copy of the proposed ordinance must be submitted to and approved by the Department. Such ordinance must be on file with the Department prior to the placing into operation the sewerage facilities.

(8) Ownership and Operational Organization.

Prior to the approval of final plans and specifications for sewerage facilities that are not owned and operated by a municipality or public utility district, the Department must receive evidence of the ownership of the system by a satisfactory organization that will be responsible for the operation and maintenance (such organization as a corporation set up under the General Corporation Act of 1969, an organization that has a charter from the Tennessee Public Service Commission, or a title deed on FHA insured loans) of the system.

(9) Other Utilities.

No other utility lines or systems are to be placed in the same trench as sewer lines, and potable water lines should be placed a minimum horizontal distance of ten (10) feet from the sewer lines.

Authority: T.C.A. §§ 68-221-101 et seq. and 4-5-201 et seq. **Administrative History:** Original rule filed September 17, 2013; effective December 16, 2013. Rule renumbered from 1200-05-02.

0400-40-16-.03 SUPERVISION OVER OPERATION OF PUBLIC SEWERAGE SYSTEMS.

(1) Records and Reports.

Daily records of the operation and maintenance of sewerage facilities, data on laboratory analyses of samples collected in accordance with the sampling program provided by the Department, and any other pertinent information shall be submitted to the Tennessee Department of Environment and Conservation on forms supplied by the Department. Reports may be required weekly, monthly, or as deemed necessary to ascertain the continuous satisfactory operation of the facilities.

(2) Samples.

Such samples of sewage or water from the receiving stream shall be submitted to the Tennessee Department of Environment and Conservation when and in such manner as may be directed from time to time.

(3) Supervision and Operation.

The supervision, operation, and maintenance of sewerage systems shall be of such character as in the opinion of the Tennessee Department of Environment and Conservation will produce satisfactory results as judged by current standards of the Department. Evidence of competency may be required if and when deemed necessary by the Commissioner to insure proper operation and maintenance of any public sewerage system.

(4) Bypassing.

There shall not be discharged any untreated sewage or inadequately treated wastes to a ditch, stream or lake except in cases where an absolute necessity exists for a short duration and the consent of the Tennessee Department of Environment and Conservation has been received in writing prior to the time of discharge.

(Rule 0400-40-16-.03, continued)

Authority: T.C.A. §§ 68-221-101 et seq. and 4-5-201 et seq. **Administrative History:** Original rule filed September 17, 2013; effective December 16, 2013. Rule renumbered from 1200-05-02.

0400-40-16-.04 INTERCONNECTIONS OR OTHER CONNECTIONS WITH POTABLE WATER SUPPLY.

Interconnections.

No person shall install, permit to be installed or maintain an interconnection or other connection between any part of the sewerage system or any appurtenance and a potable water supply or a public water supply in such manner that sewage or waste may find its way into or otherwise contaminate any potable or public water supply.

Authority: T.C.A. §§ 68-221-101 et seq. and 4-5-201 et seq. **Administrative History:** Original rule filed September 17, 2013; effective December 16, 2013. Rule renumbered from 1200-05-02.

0400-40-16-.05 INVESTIGATIONS, REPORTS, AND RECOMMENDATIONS, STANDARDS, AND ORDERS.

(1) Investigations.

The Department of Environment and Conservation will make such routine or special investigations as may be considered necessary to insure proper construction, operation and maintenance of public sewerage systems and to insure compliance with these regulations. The owners or operators of public sewerage systems shall arrange to assist the Department in making such investigations and otherwise cooperate by furnishing any pertinent data. When the Department makes written recommendations concerning the sewerage facilities, the recommendations should be followed when at all possible.

(2) Reports and Recommendations.

Reports of investigations, together with recommendations regarding needed improvements or other matters relating to any public sewerage system, shall be prepared and forwarded to the official responsible for such system as often as deemed necessary by the Director of the Division.

(3) Standards.

The Department shall prepare and disseminate such information concerning public sewerage systems as it may deem necessary or desirable to insure the proper collection and disposal of sewage. It shall prepare, adopt, or utilize such standards as necessary to evaluate results of sewage disposal through any public sewerage system in Tennessee.

(4) Special Orders.

Whenever it is the judgment of the Tennessee Department of Environment and Conservation, based upon investigations, that a public sewerage system is an actual or potential menace to public health, because of faulty design, inadequacy, improper supervision, or inefficient operation, and that effective measures are not being carried out to correct these defects, the Department may issue an order for their correction, and such order or orders shall be complied with within the time limit specified in the order.

(5) Enforcement by Department.

Whenever in the judgment of the Tennessee Department of Environment and Conservation any standards, policies, general or special orders, rules, or regulations issued by it to control

(Rule 0400-40-16-.05, continued)

public sewerage systems are violated, an authorized representative of the Department may cause to be issued a warrant in the appropriate court for the violation.

Authority: T.C.A. §§ 68-221-101 et seq. and 4-5-201 et seq. **Administrative History:** Original rule filed September 17, 2013; effective December 16, 2013. Rule renumbered from 1200-05-02.



Design Criteria for Sewage Works



Revised March 1, 2016



State of Tennessee
Department of Environment and Conservation
Division of Water Pollution Control
<http://tn.gov/environment/wpc/>

CHAPTER 2

Sewers and Wastewater Pumping Stations

2.1 General Requirements for Collection Systems

- 2.1.1 Construction Approval
- 2.1.2 Ownership
- 2.1.3 Design
- 2.1.4 Overflows
- 2.1.5 Calculations

2.2 Design Considerations

- 2.2.1 Design Period
- 2.2.2 Basis of Design
- 2.2.3 Design Factors

2.3 Design and Construction Details

- 2.3.1 Gravity sewers
- 2.3.2 Materials
- 2.3.3 Pipe Bedding
- 2.3.4 Joints
- 2.3.5 Leakage Testing
- 2.3.6 Visual Inspection
- 2.3.7 Low Pressure Systems
- 2.3.8 Manholes

2.4 Special Details

- 2.4.1 Protection of Water Supplies
- 2.4.2 Backflow Preventers
- 2.4.3 Sewers in Relation to Streams
- 2.4.4 I inverted Siphons

2.5 General Requirements for Wastewater Pumping stations

- 2.5.1 Location and Flood Protection
- 2.5.2 Pumping Rate and Number of Units
- 2.5.3 Grit and Clogging Protection
- 2.5.4 Pumping Units
- 2.5.5 Flow Measurement
- 2.5.6 Alarm System
- 2.5.7 Overflows and/or Bypasses

2.6 Special Details

- 2.6.1 General
- 2.6.2 Wet Well - Dry Well Stations
- 2.6.3 Suction Lift Stations
- 2.6.4 Submersible Pumps
- 2.6.5 Grinder and Effluent Pumps

2.7 Operability and Reliability

- 2.7.1 Objective
- 2.7.2 Backup Units
- 2.7.3 Power Outages
- 2.7.4 Emergency Power Supply (for Treatment Plants as well as Pumping stations)
- 2.7.5 Storage

2.8 Force Mains

- 2.8.1 Size
- 2.8.2 Velocity
- 2.8.3 Air Release Valve
- 2.8.4 Termination
- 2.8.5 Materials of Construction
- 2.8.6 Pressure Tests
- 2.8.7 Anchorage
- 2.8.8 Friction Losses
- 2.8.9 Water Hammer
- 2.8.10 Isolation and Valving

APPENDIX

Appendix 2-A: Design Basis for Wastewater Flow and Loadings

2.1 General Requirements for Collection Systems

2.1.1 Construction Approval

In general, construction of new sewer systems or extensions of existing systems must ensure that the downstream conveyance system and the receiving wastewater treatment plant are either:

- a. Capable of adequately conveying or processing the added hydraulic and organic load, or
- b. Capable of providing adequate conveyance or treatment facilities on a time schedule acceptable to the Division

2.1.2 Ownership

Sewer systems including pumping stations integral to gravity sewer and low-pressure sewer designs require ownership by a responsible party, such as a public entity, for operation and maintenance.

2.1.3 Design

The design and construction of new sewer systems must achieve total containment of sanitary wastes and exclusion of infiltration and inflow (I/I). This includes installing pipe with watertight joints, watertight connections to manholes, and watertight connections to service laterals or service lateral stubs and trench design that minimizes the potential for migration of water along the trench. However, the new sewer system and appurtenances must be able to convey the wastewater load, including existing I/I, from upstream areas as appropriate.

2.1.4 Overflows

The Division of Water Resources (Division) will not permit overflows in separate sanitary sewers or new overflows in existing combined sewers. The Division will not permit overflows in new interceptor sewers intercepting existing combined sewers. An alarm system to signal existing overflow conditions and procedures for reporting overflows may be required.

2.1.5 Calculations

The Division requires the submittal of all computations and other data used for design of the sewer system.

2.2 Design Considerations

2.2.1 Design Period

2.2.1.1 Collection sewers (Laterals and Submains)

The Division requires collection sewers for the ultimate development of the tributary areas.

2.2.1.2 Main, Trunk, and Interceptor Sewers

The Division requires certain design factors for trunk sewers:

- a. Possible solids deposition, odor, and pipe corrosion that might occur at initial flows
- b. Population and economic growth projections and the accuracy of the projections
- c. Comparative costs of staged construction alternatives
- d. Effect of sewer sizing on land use and development

2.2.2 Basis of Design

The Division's design requirements for new sewer systems are on the basis of per capita flows or alternative methods.

2.2.2.1 Per Capita Flow

The Division requires the use of Appendix 2-A. Substitutions or additions to the information presented in this table are acceptable if better or more accurate data is available.

The Division requires the following:

- a. Lateral and Submains: Minimum peak design flow should be not less than 400 percent of the average design flow.

"Lateral" - a sewer that has no other common sewers discharging into it.

"Submain" is defined as a sewer that receives flow from one or more lateral sewers.

- b. Main, Trunk, and Interceptor sewers: Minimum peak design flow should be not less 250 percent of the average design flow.

"Main" or "trunk" is defined as a sewer that receives flow from one or more submains.

"Interceptor" - a sewer that receives flow from a number of main or trunk sewers, force mains, etc.

2.2.2.2 Alternative Methods

The Division allows alternative methods other than on the basis of per capita flow rates. Alternative methods may include the use of peaking factors of the contributing area, allowances for future commercial and industrial areas, separation of infiltration and inflow from the normal sanitary flow (for new sewers serving existing upstream sewers), and modification of per capita flow rates (based on specific data). There should be no allowance for infiltration or inflow into newly constructed or proposed sewers.

2.2.3 Design Factors

The Division requires consideration of the following factors:

- a. Peak wastewater flows from residential, commercial, institutional, and industrial sources
- b. Potential for groundwater infiltration from existing upstream sewers
- c. Topography and depth of excavation
- d. Treatment plant location
- e. Soils conditions
- f. Pumping requirements
- g. Maintenance, including manpower and budget
- h. Existing sewers
- i. Existing and future surface improvements
- j. Controlling service connection elevations
- k. Proximity to surface streams, including minimizing the potential for draining or diversion of stream water into the pipe trench
- l. Watertight and exclude groundwater and surface water.

2.3 Design and Construction Details

2.3.1 Gravity Sewers

The Division requires gravity sewers to be approximately one-half full when conveying the anticipated peak daily dry weather flow and does not surcharge when conveying the anticipated peak wet weather flow.

2.3.1.1 Minimum Size

The minimum size of new public sewers should be 8 inches (nominal) in diameter.

2.3.1.2 Depth

Generally, sewers should not be less than 2 ½ feet deep but should be sufficiently deep to prevent freezing and physical damage.

2.3.1.3 Roughness Coefficient

The Division requires that a roughness coefficient “n” value of 0.013 be used in Manning’s formula for the design of all sewer facilities unless a roughness coefficient specific to the given pipe material is available. The roughness coefficient selected must consider the long-term condition of the sewer. However, the Division requires an “n” value equal to or greater than 0.011.

2.3.1.4 Slope

Sewers must be self-cleansing and capable of transporting most solids to the desired point, usually a treatment facility. Two methods are approved for design in the State of Tennessee: 1) Tractive Force and 2) Traditional (Ten-State Standards). For reasons of economical design and long-term maintenance, the Division prefers the Tractive Force Method.

Tractive Force Method:

ASCE and WEF (WEF Manual of Practice No. FD-5 *Gravity Sanitary Sewer Design and Construction*, 2007, Section 5.6) now advocates a transition to the tractive force approach for self-cleansing design. “Tractive Force (TF) design is a major improvement over traditional methods to achieve self-cleansing in gravity sewers. This approach results in a self-cleansing pipe slope value (S_{min}) for the design minimum flow rate (Q_{min}) in each sewer reach. Q_{min} is the predicted largest 1-hour flow rate in the reach during the lowest flow week over the sewer design life. Past design practices seldom included accurate estimation of Q_{min} values, but good estimates of Q_{min} are crucial for TF design. The engineer should show in the engineering report the calculations for Q_{min} for new sewer pipe projects. As compared to traditional minimum slopes, S_{min} slopes via the TF method are flatter for sewers carrying typical to larger Q_{min} values and steeper for sewers carrying smaller Q_{min} values.” (Merritt, LaVere B., *Tractive Force Design for Sanitary Sewer Self-Cleansing*, ASCE, May 2009)

Once a good estimate has been developed for Q_{min} , then Table 2-1 (WEF, 2007, Table 5.5, page 148) for calculating minimum slopes for a typical condition in sewers is provided to assist designers with applying TF principles.

Table 2-1 Tractive Force Equations for Minimum Slope

Sewer Size (inches)	When n is Variable* value of $S_{min} =$ (Q in cfs)
8	$0.000848 Q_{min}^{-0.5707}$
10	$0.000887 Q_{min}^{-0.5721}$
12	$0.000921 Q_{min}^{-0.5731}$
15	$0.000966 Q_{min}^{-0.5744}$
18	$0.001004 Q_{min}^{-0.5754}$
21	$0.001038 Q_{min}^{-0.5761}$
24	$0.001069 Q_{min}^{-0.5768}$
27	$0.001097 Q_{min}^{-0.5774}$
30	$0.001123 Q_{min}^{-0.5778}$
36	$0.001169 Q_{min}^{-0.5787}$
42	$0.001212 Q_{min}^{-0.5812}$

3Based on Darcy-Weisbach

Traditional Method:

The Traditional Method for conventional gravity sewers requires mean velocities, when flowing full, of not less than 2.0 feet per second. Table 2-2 provides minimum slopes when using the traditional method; however, slopes greater than these are desirable.

Table 2-2 Minimum Slope from Traditional Method

Sewer Size (inches)	Minimum Slope* (feet per 100 feet)
8	0.40
10	0.28
12	0.22
15	0.15
18	0.12
21	0.10
24	0.08
27	0.067
30	0.058
36	0.05 **
42	0.042***

* Great Lakes Upper Mississippi River Board, 1997.

** Recommended steeper – to give velocity of 2.1 ft/sec (WEF, 2007)

*** Recommended steeper – to give velocity of 2.3 ft/sec (WEF, 2007)

Under special condition, the using the Traditional Method, the Division may allow slopes slightly less than those required for the 2.0 feet-per-second velocity when flowing full may be permitted. Such decreased slopes will only be considered where the depth of flow will be 0.3 of the diameter or greater for design average flow. Whenever such decreased slopes are proposed, the design engineer should furnish with his report his computations of the depths of flow in such pipes at minimum, average, and daily or hourly rates of flow. The maintaining wastewater agency must recognize and accept in writing the problems of additional maintenance caused by decreased slopes.

Uniform slope between manholes is required.

A minimum of 5 feet of horizontal separation between gas mains is required.

Anchors are required for sewers on 20 percent slope or greater. Secure anchors will have a minimum two-foot thick tightly compacted clay collar or equal. Suggested minimum anchorage spacing is as follows:

- a. Not over 36 feet center to center on grades 20 percent and up to 35 percent.
- b. Not over 24 feet center to center on grades 35 percent and up to 50 percent.
- c. Not over 16 feet center to center on grades 50 percent and over.

2.3.1.5 Alignment

Straight alignment between manholes is required for gravity sewers. However, curved sewers may be approved where circumstances warrant but only in large (i.e., 24" and larger) diameter segments.

2.3.1.6 Increasing Size

When a smaller sewer joins a larger one, the Division requires the alignment to maintain the same energy gradient. An approximate method for securing these results is to match the crowns of the sewers entering/ exiting the manhole or junction structure.

2.3.1.7 High-Velocity Protection

Where velocities greater than 15 feet per second are expected, the Division requires protective measures against internal erosion or displacement by shock.

2.3.2 Materials

The Division will consider any generally accepted material for sewers. The material selected should be adapted to local conditions such as character of industrial wastes, possibility of septicity, soil characteristics, abrasion and similar problems. The Division requires careful consideration of pipes and compression joint materials subjected to corrosive or solvent wastes. Chemical/stress failure and stability in the presence of common household chemicals such as cooking oils, detergents and drain cleaners are factors.

The specifications should stipulate need to keep clean the pipe interior, sealing surfaces, fittings and other accessories. Pipe bundles should be stored on flat surfaces with uniform support. The protection of stored pipe is required. Pipe with prolonged exposure (six months or more) to sunlight requires a suitable covering (canvas or other opaque material). The Division requires care be given to gaskets. Ensure that gasket not be exposed to oil, grease, ozone (produced by electric motors), excessive heat and direct sunlight. Consult with the manufacturers for specific storage and handling recommendations.

2.3.2.1 Rigid Pipe

Rigid pipe includes, but is not be limited to, concrete pipe. Any rigid pipe should have a minimum crushing strength of 2000 pounds per lineal foot. All pipes should meet the appropriate ASTM and/or ANSI specifications.

2.3.2.2 Semi-rigid Pipe

Semi-rigid pipe includes, but is not be limited to, ductile iron. All pipes should meet the appropriate ASTM and/or ANSI specifications.

2.3.2.3 Flexible Pipe

Flexible pipe includes, but is not be limited to, ABS solid wall pipe, polyvinyl chloride pipe (PVC), polyethylene pipe (PE), fiberglass composite pipe, reinforced plastic mortar pipe (RPM) and reinforced thermosetting resin pipe (RTR). PVC pipe should have a minimum Standard Dimension Ratio (SDR) of 35. The Division requires that all other flexible pipe have the same calculated minimum deflection under identical conditions as the SDR 35 PVC pipe.

To calculate the flexible pipe deflection under earth loading use the formula presented in the ASCE/WPCF publication, Design and Construction of Sanitary and Storm Sewers.

All pipes should meet appropriate ASTM and/or ANSI specifications. ASTM D-3033 and D-3034 PVC pipes differ in wall thickness and have non-interchangeable fittings.

2.3.3 Pipe Bedding and Backfilling

The Division requires that all sewers designs provide protection from damage from superimposed loads. The width and depth of the trench require allowances be made for loads on the sewer. Backfill material up to three feet above the top of the pipe should not exceed 6 inches in diameter at its greater dimension.

The Division requires ductile iron pipe in roadways where cover is less than 4 feet. In such cases, a minimum cover of six inches is required.

The Division requires ductile iron pipe or relocation when the top of the sewer is less than 18 inches below the bottom of a culvert or conduit.

2.3.3.1 Rigid Pipe

Bedding Classes A, B, or C as described in ASTM C-12 or WPCF MOP No. 9 (ASCE MOP No. 37) should be used for all rigid pipe, provided the proper strength pipe is used with the specified bedding to support the anticipated load. The Division requires the use of ASTM-C-12 (placement of bedding and backfill).

2.3.3.2 Semi-Rigid Pipe

The Division requires the use of Bedding Classes I, II, III, or IV (ML and CL only) as described in ASTM D-2321 for all semi-rigid pipe provided with the specified bedding to support the anticipated load.

The Division requires ASTM-A-746 be used to install ductile iron pipe.

2.3.3.3 Flexible Pipe

The Division requires the use of Bedding Classes I, II, or III as described in ASTM D-2321 for all flexible pipe. The Division requires the proper strength pipe with the specified bedding to support the anticipated load.

The Division requires ASTM-D-2321 for bedding, haunching, initial backfill, and backfill.

The Division requires Class I bedding material for bedding, haunching, and initial backfill as described in 2.3.3.4. (polyethylene pipe).

2.3.3.4 Alternate Bedding Option

The Division will allow all sewers bedded and backfilled with a minimum of 12 inches of Class I material over the top and below the invert of the pipe--an alternative to subsections 2.3.3.1, 2.3.3.2 and 2.3.3.3.

2.3.3.5 Deflection Testing

The Division requires deflection testing of all flexible pipes. The Division requires backfill testing after it has been in place at least 24 hours.

No pipe should exceed a deflection of 5%.

The test should be run with a rigid ball or an engineer approved 9-arm mandrel having a diameter equal to 95% of the inside diameter of the pipe. The test requires manually pulling the test device through the line.

2.3.4 Joints

The Division requires the specification to include the method of making joints and the materials used. The Division requires that sewer joints eliminate infiltration and prevent the entrance of roots.

Elastomeric gaskets, other types of pre-molded (factory made) joints, and ABS solvent-cement welded joints are required. The Division requires the use of ASTM-F2620 for butt fusion joining technique with polyethylene pipe. The Division requires the removal of internal beads for butt fusion joints on pipelines with slopes less than one percent. Cement mortar joints are not acceptable. Field solvent welds for PVC and PE pipe and fittings are not acceptable.

2.3.5 Leakage Testing

The Division requires the use of ASTM-C-828 for low-pressure air testing for all pipes. The time required for the pressure to drop from the stabilized 3.5 psig to 2.5 psig should be greater than or equal to the minimum calculated test time (the Division requires that air loss rate be part of the test criteria).

The testing method should take into consideration the range in groundwater elevations projected and the situation during the test. The height of the groundwater should be measured from the top of the invert (one foot of H₂O = 0.433 psi).

Table 2-3 provides the minimum test times and allowable air loss values for various pipe size per 100 ft.

Table 2-3 Leakage Test Parameters

Pipe Size (inches)	Time, T (sec/100 ft)	Allowable Air Loss, Q (ft ³ /min)
6	42	2.0
8	72	2.0
10	90	2.5
12	108	3.0
15	126	4.0
18	144	5.0
21	180	5.5
24	216	6.0
27	252	6.5
30	288	7.0

2.3.6 Visual Inspection

The Division requires that new sewers be video inspected to confirm proper installation and to provide a visual record of the condition of the newly constructed sewer for future reference.

2.3.7 Low Pressure Systems

2.3.7.1 Application

The Division requires the consideration of low-pressure systems for situations in which gravity sewers are extremely costly or impractical, such as rock or high groundwater table.

2.3.7.2 Grinder Pumps

The Division requires all the collection and transport of raw wastewater from individual buildings/dwellings to the pressure system by appropriately sized grinder pumps.

Grinder pumps do not require a septic tank.

All pumps should have operating curves that do not allow backflow under maximum head conditions.

Pumps should be watertight and located above the seasonal groundwater table where possible.

2.3.7.3 Septic Tank Effluent Pump (STEP) system

All STEP installations require careful attention to the following design details and construction techniques:

- a. All STEPs preceded by a watertight septic tank. Retrofitting a STEP to an existing septic tank will require a visual inspection of the tank.
Replacement of all defective septic tanks.
- b. STEPs retrofitted to an existing septic tank and drain field must provide a positive means of preventing groundwater from backing up through the drain field to the STEP.
- c. The STEP should be located as close as possible to the septic tank.
- d. Electrical power supplied through the main circuit box. Electricity furnished to a separate circuit box installed on the exterior wall of the building, near the STEP.

2.3.7.4 Hydraulic

Hydraulic calculations are of extreme importance. Head losses within the low-pressure system will change with each pump activation.

2.3.7.5 Minimum Velocity

The recommended minimum operating velocity in a pressure system should be 2 feet per second (fps).

2.3.7.6 Flushing

There should be a means of cleaning the system, particularly to clear any settleable solids or grease accumulation.

2.3.7.7 Pressure Testing

There should be means for isolating and pressurizing sections of the system to detect and locate leaks.

2.3.7.8 Alarms

There should be an external visual warning system to indicate the malfunction of the pump. The high-level (in storage tank) warning system should be a dual audio / visual system.

2.3.7.9 Cleanouts

The Division requires cleanouts at a maximum of 400-foot intervals.

2.3.7.10 Ventilation

Ventilation of the pumping station should be provided via house vents where allowable or through a separate system.

2.3.8 Manholes

2.3.8.1 Location

The Division requires manholes at the end of each 8-inch diameter sewer or greater. The Division will waive this requirement if a stub-out is installed (assumes line will be extended in near future).

The Division requires manholes at all changes in grade, size, or alignment; at all intersections; and at distances not greater than 400 feet for sewers 15 inches or less. The Division requires manholes at 500 feet for sewer 18 inches to 30 inches. The Division may allow greater spacing in larger sewers and in those carrying a settled effluent.

2.3.8.2 Drop Connection

The Division requires a drop connection for a sewer entering a manhole at an elevation of 24 inches or more above the manhole invert. Where the difference in elevation between the incoming sewer and the manhole invert is less than 24 inches, a filleted invert will prevent solids deposition.

2.3.8.3 Diameter

The minimum diameter of manholes should be 48 inches; larger diameters are preferable. The minimum clear opening in the manhole frame shall meet current OSHA standards.

2.3.8.4 Flow Channels

Flow channels in manholes should be of such shape and slope to provide smooth transition between inlet and outlet sewers and to minimize turbulence. Channeling height should be to the crowns of the sewers. Benches should be sloped from the manhole wall toward the channel to prevent accumulation of solids.

2.3.8.5 Water tightness

The Division requires watertight manhole covers wherever the manhole tops may be flooded. Manholes of brick or segmented block are not appropriate materials for manhole construction where groundwater conditions are unfavorable. In pre-cast concrete manholes, the Division requires plastic gaskets, pre-molded rubber gaskets or flexible, plastic gaskets.

2.3.8.6 Connections

The Division requires special attention be paid to the connection between the manhole wall and the sewer pipe in order to minimize long-term infiltration into the system. The Division requires flexible joints for line connections directly to the manholes, or to short stubs integral with the manholes. Flexible joints are joints that permit the manholes to settle without destroying the watertight integrity of the line connections.

2.3.8.7 Ventilation

The Division requires consideration of ventilation of gravity sewer systems where continuous watertight sections are greater than 1,000 feet in length. Vent height and construction must consider flood conditions.

2.3.8.8 Frames, Covers, and Steps

Frames, covers, and steps, if utilized, should be of suitable material and designed to accommodate prevailing site conditions and to provide for a safe installation.

Materials used for manhole steps should be highly corrosion-resistant. The Division requires aluminum or plastic with reinforcing bar.

2.3.8.9 Vacuum Testing

New manholes should be vacuum tested after construction to verify they will not be new sources of infiltration or inflow. The Division requires the test to include the manhole frame. The Division considers the test acceptable if the vacuum remains at 10 inches of mercury or drops to no less than 9 inches of mercury within one minute. The Division may allow alternative testing methods--if demonstrated to be equal of better than vacuum testing.

2.4 Special Details

2.4.1 Protection of Water Supplies

2.4.1.1 Water Supply Interconnections

There shall be no physical connection between a public or private potable water supply system and a sewer or appurtenance thereto.

2.4.1.2 Relation to Water Mains

Horizontal Separation: Whenever possible, the Division requires at least 10 feet horizontal separation of the sewer from any existing or proposed water main. Should local conditions prevent a lateral separation of 10 feet, the Division may allow the sewer closer than 10 feet to a water main if in a separate trench and if the elevation of the top (crown) of the sewer is at least 18 inches below the bottom (invert) of the water main.

Vertical Separation: Whenever sewers must cross under water mains, the Division requires the sewer at such elevation that the top of the sewer is at least 18 inches below the bottom of the water main. The Division will consider other alternatives if the sewer evaluation cannot be varied.

When it is impossible to obtain proper horizontal and vertical separation as stipulated above, the sewer should be designed and constructed equal to the water main pipe and should be pressure-tested to assure water-tightness (see drinking water criteria) or the joints of the sewer pipe should be encased in concrete to inhibit infiltration/exfiltration. Details of the encasement should be clear and extend the necessary distance to achieve design goals. The designer should consider the temperature differential between the

pipe and the surrounding materials in their determination if reinforcement is necessary. Such arrangements are discouraged.

The Division requires the designer's evaluation, calculations, and conclusions in the project record and provided to all interested parties upon request.

2.4.2 Backflow Preventers

State approved reduced pressure backflow prevention devices are required on all potable water mains serving the wastewater treatment plant or pumping station. The Division can provide a list of approved backflow preventers.

2.4.3 Sewers in Relation to Streams

2.4.3.1 Site Characterizations for Sewers in Proximity to Streams

For new sewers or existing sewers replaced in the same trench that cross or have an alignment within 50 feet of the bank of a surface stream, upon notification of the potential route of the proposed sewer, the Division will perform a site characterization to determine the potential for stream capture. (See Section 1.2.4.1 of Chapter 1) If the Division determines there is potential for stream capture, a site-specific Aquatic Resource Alteration Permit (ARAP) is required, and obtaining this permit will require the design engineer to provide a plan to prevent stream capture. This may require additional study of the characteristics of the stream, including soil classification data, rock depth (if present), recommendations for controlling seepage, cut and fill recommendations, a trench dewatering plan, and other site specific data.

2.4.3.2 Location of Sewers in Streams

Open trench sewers located along streams should be located outside of the streambed and sufficiently removed there from to minimize disturbance or root damage to streamside trees and vegetation.

Sewer outfalls, headwalls, manholes, gate boxes or other structures should be located so they do not interfere with the free discharge of flood flows of the stream.

The Division requires open trench sewer crossings of streams to cross the stream as nearly perpendicular to the stream flow as possible and be free from change in grade.

2.4.3.3 Construction

Sewers entering or crossing streams should be ductile iron pipe from manhole to manhole, wrapped in plastic and encased in high strength flowable fill. (Note: This provision is subject to a case-by-case review. In this case, the Division requires an impermeable barrier that might be flowable fill, concrete, liners, casing pipe or a combination. The best practice may be different depending upon stream flow, local soils, topography and geology).

The sewer should be free of alignment or grade changes. The Division requires sewer systems designs to minimize the number of stream crossings. The Division requires the stream returned as nearly as possible to its original condition upon completion of construction. The Division requires the stream banks to be seeded or other erosion prevention methods employed to prevent erosion. Stream banks should be sodded, if necessary, to prevent erosion. The consulting engineer should specify the method or methods in the construction of the sewers in or near the stream to control siltation.

With regard to prohibitions on the contractor, the Division requires that the specifications contain the following clauses:

- unnecessarily disturbing or uprooting trees and vegetation along the stream bank and in the vicinity of the stream,
- dumping of soil and debris into streams and/or on banks of streams,
- changing course of the stream without encroachment permit,
- leaving cofferdams in streams,
- leaving temporary stream crossings for equipment,
- operating equipment in the stream, or
- pumping silt-laden water into the stream.

The Division requires provisions in the specifications to:

- retard the rate of runoff from the construction site,
- control disposal of runoff,
- liberal use of silt fencing to trap sediment resulting from construction in temporary or permanent silt-holding basins,
- pump discharges resulting from dewatering operations;
- deposit out of the flood plain area all material and debris removed from the streambed.

Specifications should require that cleanup, grading, seeding, planting or restoration of the work area should be carried out as early as practical as the construction proceeds. The Division requires the specifications mandate a trench-dewatering plan for new sewer alignments that cross a stream or are within 50 feet of the bank of the stream defined in Section 1.2.4.1.

2.4.3.4 Special Construction Requirements

The Division requires the employment of special design requirements to prevent stream drainage from sinking at the crossing and following along the sewer pipe bedding. The Division requires an in trench impounding structure of compacted clay or concrete check dams. The Division will consider other proposals.

2.4.3.5 Aerial Crossings

The Division may allow sewers that lay on piers across ravines or streams if no other practical alternative exists or, in the design engineer's judgment, other methods will not be as reliable.

The Division requires support for all joints. All supports designs must prevent frost heave, overturning or settlement. The Division requires precautions against freezing, such as insulation or increased slope and expansion joints between aboveground and belowground sewers. The Division requires designs to consider the impact of floodwaters and debris. The design should consider maintenance of an adequate waterway for the 100-year flood flows. The design engineer should analyze the impact of the proposed aerial crossing(s) on flooding, including hydraulic modeling, such as Hydrologic Engineering Center-River Analysis System (HEC-RAS) modeling, as necessary.

2.4.3.6 Permits

It is the owner's responsibility to obtain all necessary permits along streams or rivers; i.e., Corps of Engineers, TVA, or the Natural Resources Section of the Division of Water Resources.

2.4.4 Inverted Siphons

Under normal conditions, the Division will not allow inverted siphons. However, if they are, the Division requires that the following:

- Minimum of two barrels,
- Minimum pipe size of six inches--provided with necessary appurtenances for convenient flushing and maintenance,
- Manholes with adequate clearances for rodding,
- Sufficient head and pipe sizes to secure velocities of at least 3.0 feet per second for average flows,
- Inlet and outlet details arranged so that the normal flow is diverted to one barrel, and so that either barrel may be cut out of service for cleaning,
- Design engineer furnishes hydraulic calculations with the plans,
- Proper access maintained.

2.5 General Requirements for Wastewater Pumping Stations

2.5.1 Location and Flood Protection

The Division requires wastewater pumping stations located as far as practicable from present or proposed built-up residential areas, with an all-weather road and noise control, odor control, and station architectural design taken into consideration. Sites for stations should be of sufficient size for future expansion or addition, if applicable. The Division requires security for the pumping station and controls.

The Division requires protection from the 100-year flood for the station's operational components.

Where the wet well is at a depth greater than the water table elevation, special provisions should be made to ensure watertight construction of the wet well. The Division requires connections to the pumping station at an elevation higher than the maximum water table elevation, where possible.

2.5.2 Pumping Rate and Number of Units

At least two pump units should be provided, each capable of handling the expected maximum flow. The Division requires the submittal of pump head and system head curves.

For three or more units the Division requires a design to fit actual flow conditions and must be of such capacity that, with any one unit out of services, the remaining units will have capacity to handle the maximum wastewater flow.

A station expected to operate at a flow rate less than one-half the average design flow for an extended period may create septic conditions due to long holding times in the wet well. The design should consider the need for additional measures to prevent the formation of odors.

The design should the use of variable-speed or multiple staged pumps, particularly when the pumping station delivers flow directly to a treatment plant. The design allows delivery of the wastewater at approximately the same rate as received at the pumping station.

2.5.3 Grit and Clogging Protection

Where it may be necessary to pump wastewater prior to grit removal, the design of the wet well should receive special attention, and the design of the discharge piping should be to prevent grit settling in pump discharge lines of pumps not operating.

Design of the pumping station should consider the protection of the pump from damage caused by grit and debris, where warranted. To accomplish this--maintain minimum pump operational speeds, through the installation of bar screens with a grinder or comminutor, or similar devices. For the larger or deeper stations, duplicate protection units, each sized at full capacity, are preferred.

2.5.4 Pumping Units

2.5.4.1 Pump Openings

The Division requires pumps be capable of passing a 3-inch compressible solid. The Division requires pump suction and discharge openings to be at least 4 inches in diameter unless it is a pump with chopping or grinding capabilities.

2.5.4.2 Priming

The Division requires the placement of pumps so that under normal operating conditions they will operate under a positive suction head (except for suction lift pumps).

2.5.4.3 Intake

Each pump should have an individual intake. Wet well design should be such as to avoid turbulence near the intake.

2.5.4.4 Controls

The location of controls should ensure that the flows entering the wet well to not affect them, by the suction of the pumps, or by proximity to wet well walls. Controls must be able to activate additional pumps if the water in the wet well continues to rise. Controls can be float switches, air-operated pneumatic, radar, ultrasonic or capacitance probe types. Provisions should be made to automatically alternate the pumps in use. Pumping stations with motors and/or controls below grade should be equipped with a secure external disconnect switch. The Division requires consideration of an “intrinsically safe” power source if float switches are used.

The Division requires consideration of redundant controls and/or remote monitoring to assist in preventing overflows.

2.5.5 Flow Measurement

At pumping stations with flow capacity greater than 0.5 million gallons per day (mgd), the Division recommends providing suitable devices for measuring flow.

2.5.6 Alarm System

The Division recommends an alarm system for all pumping stations such as, telemetry alarm to 24-hour monitoring stations or telephone alarms to duty personnel (when reliability classification or property damage warrants it). The Division requires an audiovisual device at the station for external observation when telemetry is not used.

The Division requires alarms for high wet well and power failure, as a minimum, for all pumping stations. For larger stations, the Division requires alarms signaling pump and other component failures or malfunctions.

The Division requires a backup power supply, such as a battery pack with an automatic switchover feature, for the alarm system, such that a failure of the primary power source will not disable the alarm system. The alarm system must be tested and verified that it is in good working order.

2.5.7 Overflows and/or Bypasses

Pumping stations should be designed and built without any type of overflow or bypass structure.

2.6 Special Details

2.6.1 General

2.6.1.1 Materials

Materials must not contain hydrogen sulfide and other corrosive gases, greases, oils, and other constituents frequently present in wastewater. The Division recommends the use of concrete additives or protective coatings to prevent deterioration caused by corrosive gases.

2.6.1.2 Electrical Equipment

Electrical systems and components (e.g., motors, lights, cables, conduits, switchboxes, and control circuits) in enclosed or partially enclosed spaces where flammable mixtures occasionally may be present (including raw wastewater wet wells) should comply with the National Electrical Code requirements for Class I Division 1 locations.

2.6.1.3 Water Supply

There should be no physical connection between any potable water supply and a wastewater pumping station that under any conditions might cause contamination of the potable water supply. A potable water supply must comply with conditions stipulated in section 2.4.2.

2.6.1.4 Lighting

Adequate lighting is required for the entire pumping station.

2.6.1.5 Pump and Motor Removal

The Division requires the removal of pumps, motors, and other equipment, without interruption of system service.

2.6.1.6 Safety

The Division requires suitable and safe means of access to equipment requiring inspection or maintenance and that stairways and ladders satisfy all OSHA requirements.

2.6.1.7 Valves and Piping

The Division requires suitable shutoff valves on suction and discharge lines of each pump for normal pump isolation and a check valve on each discharge line between the shutoff valve and the pump. Pump suction and discharge piping should not be less than 4 inches in diameter except where design of special equipment allows. The velocity in the suction line should not exceed 6 feet per second and, in the discharge piping, 8 feet per second. A separate shutoff valve is desirable on the common line leaving the pumping station.

2.6.1.8 Ventilation

The Division requires ventilation for all pumping stations during all periods when the station is manned. Portable ventilation equipment is acceptable for small pumping stations. Mechanical ventilation is required if screens or mechanical equipment, which might require periodic maintenance and inspection, are located in the wet well. In pits over 15 feet deep, multiple inlets and outlets are desirable. The Division requires that dampers not be used on exhaust or fresh air ducts, and fine screens or other obstructions in air ducts should be avoided to prevent clogging.

2.6.2 Wet Well - Dry Well Stations

2.6.2.1 Separation

The Division requires complete separation of wet and dry wells, including their superstructures.

The Division recommends dividing the wet well into two sections, properly interconnected, to facilitate repairs and cleaning where continuity of pumping station operation is necessary.

2.6.2.2 Wet Well Size and Design

Provide an evaluation of the effective capacity of the wet well based on pumping requirements and reliability classifications.

Wet well design should consider approaches for minimizing solids deposition.

2.6.2.3 Dry Well Dewatering

The Division requires a separate sump pump in the dry wells to remove leakage or drainage with the discharge above the high water level of the wet well. The Division will not approve water ejectors connected to a potable water supply. All floor and walkway surfaces should have an adequate slope to a point of drainage.

2.6.3 Suction Lift Stations

2.6.3.1 Priming

Conventional suction-lift pumps should be of the self-priming type, as demonstrated by a reliable record of satisfactory operation. The maximum recommended lift for a suction lift pumping station is 15 feet, using pumps of 200 gallons per minute (gpm) capacity or less.

2.6.3.2 Capacity

The capacity of suction lift pumping stations should be limited by the net positive suction head and specific speed requirements, as stated on the manufacturer's pump curve, for the most severe operating conditions.

2.6.3.3 Air Relief

a. Air Relief Lines

An air relief line on the pump discharge piping is required for all suction lift pumps. This line should be located at the maximum elevation between the pump discharge flange and the discharge check valve to ensure the maximum bleed-off of entrapped air. The air relief line should terminate in the wet well or suitable sump and be open to the atmosphere.

b. Air Relief Valves

The Division requires air relief valves in air relief lines on pumps not discharging to gravity sewer collection systems. The air relief valve should be located as close as practical to the discharge side of the pump.

2.6.3.4 Pump Location

For standard designs, suction lift pumps are mounted on the wet well but not within the wet well.

2.6.3.5 Access to Wet Well

Access to the wet well should not be through the dry well, and the dry well should have a gastight seal when mounted directly above the wet well.

2.6.4 Submersible Pumps

2.6.4.1 Pump Removal

Submersible pumps should be readily removable and replaceable without dewatering the wet well or requiring personnel to enter the wet well.

The Division recommends a hoist or crane system for removing the pumps from the wet well either through a permanent installation at the site or a mobile system that could be utilized at multiple sites.

2.6.4.2 Controls

The control panel should be located outside the wet well and suitably protected from weather, humidity, vandalism, and gases migrating from the wet well.

2.6.4.3 Valves

The Division recommends all control valves on the discharge line for each pump in a convenient location outside the wet well in separate pits and protected from weather and vandalism.

2.6.4.4 Submergence

Positive provision, such as backup controls, is required to assure submergence of the pumping units.

2.6.5 Grinder and Effluent Pumps

The requirements for grinder pumps are included in Section 2.3.6.

2.7 Operability and Reliability

2.7.1 Objective

The objective of reliability is to prevent the discharge of raw or partially treated wastewater to any waters and to protect public health by preventing backup of wastewater and subsequent discharge to basements, streets, and other public and private property.

2.7.2 Backup Units

A minimum of two pumps or pneumatic ejectors are required in each station in accordance with section 2.5.2.

2.7.3 Power Outages

An emergency power source or auxiliary power is required for all pumping stations larger than 1 MGD to ensure continuous operability unless experience has shown the frequency and duration of outages to be low and the pumping station and/or sewers provide storage sufficient for expected interruptions in power service.

2.7.4 Emergency Power Supply (for Treatment Plants as well as Pumping stations)

2.7.4.1 General

The Division requires provision of an emergency power supply for pumping stations (and treatment plants) to at least two independent public utility sources, or by provision of portable or in-place internal combustion engine equipment that will generate electrical or mechanical energy, or by the provision of portable pumping equipment. Emergency power must be provided for all stations which are 1 MGD or larger, or as determined by the reliability classification.

Emergency power should be provided that, alone or combined with storage, will prevent overflows from occurring during any power outage that is equal to the maximum outage in the immediate area during the last 10 years. If available data were less than 10 years, an evaluation of a similar area served by the power utility for 10 years would be appropriate.

2.7.4.2 In -Place Equipment

The utilization of in-place internal combustion equipment requires the following guidelines:

- a. Placement: bolted in place. Facilities for unit removal for purposes of major repair or routine maintenance.
- b. Controls: automatic and manual startup and cut-in.
- c. Size: adequate to provide power for lighting and ventilation systems and such further systems that affect capability and safety as well as the pumps.
- d. Engine Location: located above grade, with suitable and adequate ventilation of exhaust gases.
- e. Underground Fuel Storage Tank: design and construction must conform to the applicable requirements of Federal Regulations 40 CFR 280 and 281. Contact the Tennessee Division of Superfund, Underground Storage Tank Program, for guidance.

2.7.4.3 Portable Equipment

The utilization of portable equipment requires the following guidelines:

Pumping units have connections to operate between the wet well and the discharge side of station and the station provided with permanent fixtures that will facilitate rapid and easy connection of lines.

2.7.5 Storage

The Division requires wet well and tributary main capacity above the high-level alarm sufficient to hold the peak flow expected during the maximum power outage duration during the last 10 years.

2.8 Force Mains

2.8.1 Size

Minimum size force mains required to be not less than 4 inches in diameter, except for grinder pumps or septic tank effluent applications

2.8.2 Velocity

At pumping capacity, a minimum self-scouring velocity of 3 feet per second (fps) should be maintained unless flushing facilities are provided. Velocity should not exceed 8 fps.

2.8.3 Air/Vacuum Relief Valve

An air relief valve is required at the necessary high points in the force main to relieve air locking. Vacuum relief valves may be necessary to relieve negative pressures on force mains to protect against pipe collapse.

2.8.4 Termination

The force main should enter the receiving manhole with its centerline horizontal and with an invert elevation that will ensure a smooth flow transition to the gravity flow section; but in no case should the force main enter the gravity sewer system at a point more than 1 foot above the flow line of the receiving manhole. The design should minimize turbulence at the point of discharge.

The Division requires the use of inert materials or protective coatings for the receiving manhole to prevent deterioration because of hydrogen sulfide or other chemicals where such chemicals are present or suspected to be present because of industrial discharges or long force mains.

2.8.5 Materials of Construction

The pipe material should be adapted to local conditions, such as character of industrial wastes, soil characteristics, exceptionally heavy external loadings, internal erosion, corrosion, and similar problems.

Installation specification should contain appropriate requirements based on the criteria, standards, and requirements established by the industry in its technical publications. Requirements should be set forth in the specifications for the pipe and methods of bedding and backfilling thereof so as not to damage the pipe or its joints, impede cleaning operations, not create excessive side fill pressures or ovality of the pipe, nor seriously impair flow capacity.

The Division requires that the design of all pipes prevent damage from superimposed loads. Proper design allowance for loads on the pipe because of the width and depth of trench is required.

2.8.6 Pressure Tests

The Division requires testing, before backfilling, of all force mains at a minimum pressure of at least 50 percent above the design operating pressure for at least 30 minutes. Leakage should not exceed the amount given by the following formula:

$$L = ND (P)^5 / 7,400$$

Where **L** is allowable leakage in gallons per hour

N is the number of pipe joints

D is the pipe diameter in inches

P is the test pressure in psi

2.8.7 Anchorage

The Division requires sufficient anchorage of force mains within the pumping station and throughout the line length to include, thrust blocks, restrained joints, and/or tie rods.

2.8.8 Friction Losses

The Division requires the use of a C factor that will take into consideration the conditions of the force main at its design usage. For example, a grease-coated pipe after several years will not have the same C factor as a new pipe.

2.8.9 Water Hammer

The force main design should investigate the potential for the existence of water hammer.

2.8.10 Isolation and Valving

The Division recommends the installation of isolation valves at strategic locations along the force main to facilitate maintenance of the system.

APPENDIX 2-A**Design Basis for Wastewater Flow and Loadings****Table 2-A.1. Typical Wastewater Flow Rates from Commercial Sources**
(Source: Crites and Tchobanoglous, 1998)

FACILITY	UNIT	Flow, gallons/unit/day	
		Range	Typical
Airport	Passenger	2 - 4	3
Apartment House	Person	40 - 80	50
Automobile Service Station	Vehicle served	8 - 15	12
	Employee	9 - 15	13
Bar	Customer	1 - 5	3
	Employee	10 - 16	13
Boarding House	Person	25 - 60	40
Department Store	Toilet Room	400 - 600	500
	Employee	8 - 15	10
Hotel	Guest	40 - 60	50
	Employee	8 - 13	10
Industrial Building (Sanitary waste only)	Employee	7 - 16	13
Laundry (self-service)	Machine	450 - 650	550
	Wash	45 - 55	50
Office	Employee	7 - 16	13
Public Lavatory	User	3 - 6	5
Restaurant (with toilet)	Meal	2 - 4	3
	Conventional Customer	8 - 10	9
	Short order Customer	3 - 8	6
	Bar/cocktail lounge Customer	2 - 4	3
Shopping Center	Employee	7 - 13	10
	Parking Space	1 - 3	2
Theater	Seat	2 - 4	3

Table 2-A.2. Typical Wastewater Flow Rates from Institutional Sources
(Source: Crites and Tchobanoglous, 1998)

FACILITY	UNIT	Flow, gallons/unit/day	
		Range	Typical
Assembly Hall	Seat	2 - 4	3
Hospital, Medical	Bed	125 - 240	165
	Employee	5 - 15	10
Hospital, Mental	Bed	75 - 140	100
	Employee	5 - 15	10
Prison	Inmate	80 - 150	120
	Employee	5 - 15	10
Rest Home	Resident	50 - 120	90
	Employee	5 - 15	10
School, day-only:			
With cafeteria, gym, showers	Student	15 - 30	25
With cafeteria only	Student	10 - 20	15
Without cafeteria, gym, or showers	Student	5 - 17	11
School, boarding	Student	50 - 100	75

Table 2-A.3. Typical Wastewater Flow Rates from Commercial Sources
(Source: Crites and Tchobanoglous, 1998)

FACILITY	UNIT	Flow, gallons/unit/day	
		Range	Typical
Apartment, resort	Person	50 - 70	60
Bowling Alley	Alley	150 - 250	200
Cabin, resort	Person	8 - 50	40
Cafeteria	Customer	1 - 3	2
	Employee	8 - 12	10
Camps:			
Pioneer Type	Person	15 - 30	25
Children's, with central toilet/bath	Person	35 - 50	45
Day, with meals	Person	10 - 20	15
Day, without meals	Person	10 - 15	13
Luxury, private bath	Person	75 - 100	90
Trailer Camp	Person	75 - 125	125
Campground-developed	Person	20 - 40	30
Cocktail Lounge	Seat	12 - 25	20
Coffee Shop	Customer	4 - 8	6
	Employee	8 - 12	10
Country Club	Guests on-site	60 - 130	100
	Employee	10 - 15	13
Dining Hall	Meal Served	4 - 10	7
Dormitory/bunkhouse	Person	20 - 50	40
Fairground	Visitor	1 - 2	2
Hotel, resort	Person	40 - 60	50
Picnic park, flush toilets	Visitor	5 - 10	8
Store, resort	Customer	1 - 4	3
	Employee	8 - 12	10
Swimming Pool	Customer	5 - 12	10
	Employee	8 - 12	10
Theater	Seat	2 - 4	3
Visitor Center	Visitor	4 - 8	5

4.2.5 Operability

Adjustable control valves shall be included in each diffuser air line to control mixing and particle segregation. Variable speed arrangements should be provided in cyclone or mechanical type systems. Provisions shall be made for isolation and dewatering each unit or units.

4.3 Pre-Aeration

Pre-aeration is desirable in certain instances, such as to reduce septicity. Pre-aeration may be required where pressure or small diameter collection systems are used. Long detention times in pump stations or collection lines should also be considered. Units shall be designed so that removal from service will not interfere with normal plant operations.

4.4 Flow Equalization

4.4.1 General

Equalization may be used to minimize random or cyclic peaking of organic or hydraulic loadings when the total flow is ultimately processed through the plant. Either in-line or side-line equalization is acceptable. Equalization may be required where peak flows are greater than 2 times the average design flow.

4.4.2 Location

Tanks are generally located after screening and grit removal. Care should be taken in design to minimize solids deposition if located upstream of primary clarifiers. Equalization downstream of primary clarifiers should be investigated, as primary clarifier performance is less sensitive to flow peaking when compared to other processes. Other locations will be evaluated on a case-by-case basis.

4.4.3 Design and Operability

Generally, aeration will be required. Minimum requirements are to maintain 1.0 mg/l of dissolved oxygen. Odor consideration must be addressed when a plant is located in a sensitive area or large equalization basins are used. Large tanks must be divided into compartments to allow for operational flexibility, repair and cleaning. Each compartment shall be capable of dewatering and access. In plant upgrades, existing units which are otherwise to be abandoned may be used for equalization, where possible. Sizing the tankage and compartments will depend on the intended use; i.e., when equalization is for periodic high organic loadings, peak flow events, toxics, etc. A complete analysis shall accompany all engineering report (or plan) submission.

CHAPTER 13

Plant Flow Measurement and Sampling

13.1 Purpose

13.2 Flow Measurement

13.2.1 General Considerations

13.2.2 Parshall Flumes

13.2.3 Sharp Crested Weirs

13.2.4 Venturi and Modified Flow Tube Meters

13.2.5 Other Flow Metering Devices

13.2.6 Hydrograph Controlled Release (HCR) Systems

13.3 Sampling

13.3.1 Automatic Sampling Equipment

13.3.2 Manual Sampling

13.3.3 Long Outfall Lines

13.3.4 Sampling Schedules

PLANT FLOW MEASUREMENT AND SAMPLING

13.1 Purpose

Complete and accurate flow measuring and sampling are essential in the proper treatment of wastewater. Compliance with discharge limits requires proper flow measurement and sampling. They provide the operator with the information to optimize process control and operational costs, as well as providing an accurate data base of flows and process performance which can be used to analyze changes in operational strategy or assist future plant design.

13.2 Flow Measurement

13.2.1 General Considerations

13.2.1.1 Facilities for measuring the volume of sewage flows should be provided at all treatment works.

13.2.1.2 Plants with a capacity equal to or less than 100,000 gallons per day (gpd) shall be equipped, as a minimum, with a primary metering device such as: a Parshall flume having a separate float well and staff gauge, a weir box having plate and staff gauge, or other approved devices. Continuous recording devices may be required where circumstances warrant.

13.2.1.3 Plants having a capacity of greater than 100,000 gpd shall be provided with indicating, recording, and totalizing equipment using strip or circular charts and with flow charts for periods of 1 or 7 days. The chart size shall be sufficient to accurately record and depict the flow measured.

13.2.1.4 Flows passed through the plant and flows bypassed shall be measured in a manner which will allow them to be distinguished and separately reported.

13.2.1.5 Measuring equipment shall be provided which is accurate under all expected flow conditions (minimum initial flow and maximum design peak flow). The accuracy of the total flow monitoring system (primary device, transmitter, and indicator) must be acceptable. The effect of such factors as ambient temperature, power source voltage, electronic interference, and humidity should be considered. Surges must be eliminated to provide accurate measurement.

Two primary devices and flow charts may be required in some cases.

- 13.2.1.6 Metering devices within a sewage works shall be located so that recycle flow streams do not inadvertently affect the flow measurement. In some cases, measurement of the total flow (influent plus recycle) may be desirable.
- 13.2.1.7 All clarifiers must be provided with a means for accurate flow measurement of sludge wasting and sludge return lines so that solids handling can be controlled. Sludge digesters, thickeners, and holding tanks should be provided with some way to determine the volume of sludge added or removed. This can be accomplished by a sidewall depth scale or graduation in batch operations.
- 13.2.1.8 Flow meter and indicator selection should be justified considering factors such as probable flow range, acceptable headloss, required accuracy, and fouling ability of the water to be measured. For more detailed information the consultant is encouraged to read the EPA Design Information Report "Flow Measurement Instrumentation"; Journal WPCF, Volume 58, Number 10, pp. 1005-1009. This report offers many installation details and considerations for different types of flow monitoring equipment.
- 13.2.1.9 Flow splitter boxes shall be constructed so that they are reliable, easily controllable, and accessible for maintenance purposes.
- 13.2.1.10 Where influent and effluent flow-proportional composite sampling is required, separate influent and effluent flow measuring equipment is required.
- 13.2.1.11 Consideration should be given to providing some types of flow meters with bypass piping and valving for cleaning and maintenance purposes.

13.2.2 Parshall Flumes

Parshall Flumes are ideal for measuring flows of raw sewage and primary effluents because clogging problems are usually minimal.

The properly sized flume should be selected for the flow range to be encountered. All Parshall Flumes must be designed to the specified dimensions of an acceptable reference.

The following requirements must be met when designing a Parshall Flume.

13.2.2.1 Flow should be evenly distributed across the width of the channel.

13.2.2.2 The crest must have a smooth, definite edge. If a liner is used, all screws and bolts should be countersunk.

- 13.2.2.3 Longitudinal and lateral axes of the crest floor must be level.
- 13.2.2.4 The location of the head measuring points (stilling well) must be two-thirds the length of the converging sidewall upstream from the crest. Sonar-type devices are only acceptable when foaming or turbulence is not a problem.
- 13.2.2.5 The pressure tap to the stilling well must be at right angles to the wall of the converging section.
- 13.2.2.6 The invert (i.e., inside bottom) of the pressure tap must be at the same elevation as the crest.
- 13.2.2.7 The tap should be flush with the flume side wall and have square, sharp corners free from burrs or other projections.
- 13.2.2.8 The tap pipe should be 2 inches in size and be horizontal or slope downward to the stilling well.
- 13.2.2.9 Free-flow conditions shall be maintained under all flow rates to be encountered by providing low enough elevations downstream of the flume. No constrictions (i.e., sharp bends or decrease in pipe size) should be placed after the flume as this might cause submergence under high flow conditions.
- 13.2.2.10 The volume of the stilling well should be determined by the conditions of flow. For flows that vary rapidly, the volume should be small so that the instrument float can respond quickly to the changes in rate. For relatively steady flows, a large-volume stilling well is acceptable. Consideration should be given to protecting the stilling well from freezing.
- 13.2.2.11 Drain and shut-off valves shall be provided to empty and clean the stilling well.
- 13.2.2.12 Means shall be provided for accurately maintaining a level in the stilling well at the same elevation as the crest in the flume, to permit adjusting the instrument to zero flow conditions.
- 13.2.2.13 The flume must be located where a uniform channel width is maintained ahead of the flume for a distance equal to or greater than fifteen (15) channel widths.
The approach channel must be straight and the approaching flow must not be turbulent, surging, or unbalanced. Flow lines should be essentially parallel to the centerline of the flume.

13.2.3 Sharp Crested Weirs

The following criteria are for V-notch weirs, rectangular weirs with and without end contractions, and Cipolletti weirs. The following details must be met when designing a sharp crested weir:

- 13.2.3.1 The weir must be installed so that it is perpendicular to the axis of flow. The upstream face of the bulkhead must be smooth.
- 13.2.3.2 The thickness of the weir crest should be less than 0.1 inch or the downstream edge of the crest must be relieved by chamfering at a 45° angle so that the horizontal (unchamfered) thickness of the weir is less than 0.1 inch.
- 13.2.3.3 The sides of rectangular contracted weirs must be truly vertical. Angles of V-notch weirs must be cut precisely. All corners must be machined or filed perpendicular to the upstream face so that the weir will be free of burrs or scratches.
- 13.2.3.4 The distance from the weir crest to the bottom of the approach channel must be greater than twice the maximum weir head and is never to be less than one foot.
- 13.2.3.5 The distance from the sides of the weir to the side of the approach channel must be greater than twice the maximum weir head and is never to be less than one foot (except for rectangular weirs without end contractions).
- 13.2.3.6 The nappe (overflow sheet) must touch only the upstream edges of the weir crest or notch. If properly designed, air should circulate freely under and on both sides of the nappe. For suppressed rectangular weirs (i.e., no contractions), the enclosed space under the nappe must be adequately ventilated to maintain accurate head and discharge relationships.
- 13.2.3.7 The measurement of head on the weir must be taken at a point at least four (4) times the maximum head on the crest upstream from the weir.
- 13.2.3.8 The cross - sectional area of the approach channel must be at least eight (8) times that of the nappe at the crest for a distance upstream of 15-20 times the maximum head on the crest in order to minimize the approach velocity.
The approach channel must be straight and uniform upstream of the weir for the same distance, with the exception of weirs with end contractions where a uniform cross section is not needed.

13.2.3.9 The head on the weir must have at least three (3) inches of free fall at the maximum downstream water surface to ensure free fall and aeration of the nappe.

13.2.3.10 All of the flow must pass over the weir and no leakage at the weir plate edges or bottom is permissible.

13.2.3.11 The weir plate is to be constructed of a material equal to or more resistant than 304 Stainless Steel.

13.2.4 Venturi and Modified Flow Tube Meters

The following requirements should be observed for application of venturi meters:

13.2.4.1 The range of flows, hydraulic gradient, and space available for installation must be suitable for a venturi meter and are very important in selecting the mode of transmission to the indicator, recorder, or totalizer.

13.2.4.2 Venturi meters shall not be used where the range of flows is too great or where the liquid may not be under a positive head at all times.

13.2.4.3 Cleanouts or handholes are desirable, particularly on units handling raw sewage or sludge.

13.2.4.4 Units used to measure air delivered by positive - displacement blowers should be located as far as possible from the blowers, or means should be provided to dampen blower pulsations.

13.2.4.5 The velocity and direction of the flow in the pipe ahead of the meter can have a detrimental effect on accuracy. There should be no bends or other fittings for 6 pipe diameters upstream of the venturi meter, unless treated effluent is being measured when straightening vanes are provided.

13.2.4.6 Other design guidelines as provided by manufacturers of venturi meters should also be considered.

13.2.5 Other Flow Metering Devices

Flow meters, such as propeller meters, magnetic flow meters, orifice meters, pitot tubes, and other devices, should only be used in applications in accordance with the manufacturer's recommendations and design guidelines.

13.2.6 Hydrograph Controlled Release (HCR) Systems

For plants utilizing HCR systems, accurate stream flow measurements are required. Detailed plans must be submitted outlining the construction of the primary stream flow measuring device and the associated instrumentation. The following factors should be emphasized in the design.

13.2.6.1 Accuracy over the flow range required for effluent discharge limiting purposes.

13.2.6.2 Operational factors such as cleaning and maintenance requirements.

13.2.6.3 Cost

The use of sharp crested weirs as described in Section 13.2.3 will not be allowed due to the installation requirements such as approach channel details and upstream pool depth and since entrapment and accumulation of silt and debris may cause the device to measure inaccurately. Parshall Flumes may be used due to their self-cleaning ability but field calibration will be required. Self-cleaning V-notch weirs are recommended due to their accuracy in low flow ranges. The weir can be made self-cleaning by sloping both sides of the weir away from the crest. The top portion of the crest shall be covered with angle-iron to prevent its breakdown. The angle of the V-notch should be determined by the stream characteristics; however, a smaller angle will increase accuracy in the low flow range. The primary device shall be built with sufficient depth into the stream bed to prevent undercutting and sufficient height to cover the required flow range.

It is recommended that the wastewater system director, engineer, or other city official contact the U.S. Geological Survey (USGS), Water Resources Division, in Nashville, Tennessee, for assistance with the design and installation of the flow measuring device. They offer a program which shares much of the costs for designing and maintaining the device. After visiting the site, they can assist with the design of a self-cleaning weir for the stream. They provide the consultant with a field design that shows the proper location and installation of the weir. From this field design, the consultant must provide detailed plans to the State.

The wastewater system is responsible for constructing the weir at their own cost. The flow measuring station is installed, maintained, and calibrated by USGS personnel so that accurate results are insured.

The primary device will record continuous flow of the stream and can be designed to send a feedback signal to the WWTP for other purposes such as controlling plant discharge rates.

This program benefits both the local wastewater system, the State of Tennessee, and the USGS, as it adds to stream flow data bases archived for public use. Cost sharing allows the flow measuring station to be built and operated at a lower cost for all parties concerned.

13.3 Sampling

13.3.1 Automatic Sampling Equipment

The following general guidelines should be adhered to in the use of automatic samplers:

- 13.3.1.1 Automatic samplers shall be used where composite sampling is necessary.
- 13.3.1.2 The sampling device shall be located near the source being sampled, to prevent sample degradation in the line.
- 13.3.1.3 Long sampling transmission lines should be avoided.
- 13.3.1.4 If sampling transmission lines are used, they shall be large enough to prevent plugging, yet have velocities sufficient to prevent sedimentation. Provisions shall be included to make sample lines cleanable. Minimum velocities in sample lines shall be 3 feet per second under all operating conditions.
- 13.3.1.5 Samples shall be refrigerated unless the samples will not be effected by biological degradation.
- 13.3.1.6 Sampler inlet lines shall be located where the flow stream is well mixed and representative of the total flow.
- 13.3.1.7 Influent automatic samplers should draw a sample downstream of bar screens or comminutors. They should be located before any return sludge lines or scum lines.
- 13.3.1.8 Effluent sampling should draw a sample immediately upstream of the chlorination point. This will eliminate the need to dechlorinate and then re-seed the sample.

13.3.2 Manual Sampling

Because grab samples are manually obtained, safe access to sampling sites should be considered in the design of treatment facilities.

13.3.3 Long Outfall Lines

Many wastewater systems are constructing long outfall lines to take advantage of secondary or equivalent permit limits.

Due to possible changes in effluent quality between the treatment facility and the outfall, a remote sampling station will be required at or near the confluence of the outfall line and the receiving stream on all outfall lines greater than one mile in length.

Dissolved oxygen, fecal coliform, and chlorine residual may have to be measured at the remote sampling station for permit compliance purposes.

13.3.4 Sampling Schedules

Samples must be taken and analyzed for two purposes: permit compliance and process control. Any time a new permit is issued, a sampling schedule for permit compliance will be determined by the Division of Water Pollution Control. An additional sampling program needs to be set up for process control purposes. This would include all testing required for completing the monthly operational report, as well as any other tests that might aid the operation of the plant. This schedule can be determined by the Division of Water Pollution Control, Wastewater Treatment Section or the appropriate field office once final plans are approved. The designer shall provide safe access points to collect representative influent and effluent samples of all treatment units and to collect samples of all sludge transmission lines. This makes it possible to determine the efficiency of each treatment process. Additional information about methods of analyses can be obtained from the Federal Register 40 CFR Part 136. Information about sampling locations and techniques can be obtained from the EPA Aerobic Biological Wastewater Treatment Facilities Process Control Manual and EPA's NPDES Compliance Inspection Manual.

Continuing Education Requirements

The following hours of Continuing Education are required to maintain certification.

Certification Title	Number of Continuing Education Hours Needed
Biological/Natural Systems	6 hours every 3 years
Collection 1	6 hours every 3 years
Collection 2	6 hours every 3 years
Distribution 1	6 hours every 3 years
Distribution 2	6 hours every 3 years
Small Water System	6 hours every 3 years
Water Treatment 1	6 hours every 3 years
Water Treatment 2	6 hours every 3 years
Water Treatment 3	12 hours every 3 years
Water Treatment 4	12 hours every 3 years
Wastewater Treatment 1	6 hours every 3 years
Wastewater Treatment 2	6 hours every 3 years
Wastewater Treatment 3	12 hours every 3 years
Wastewater Treatment 4	12 hours every 3 years

Fleming Training Center
 2022 Blanton Drive
 Murfreesboro, TN 37129
 Phone: 615-898-8090
 Fax: 615- 898-8064

Section 16

Sacramento Review Questions




Sacramento Review Questions

References




What is another name for a wastewater collection system?

- A. Septage system
- B. Septic system
- C. Sewerage system
- D. Storm sewer

*Volume 1, Chapter 1 – Introduction to Wastewater Collection

Because other underground utilities are normally installed near the wastewater collection, what is one other service that could also be disrupted if a collection system fails due to leaking sewer mains?

- A. Cell phone service
- B. Emergency service
- C. Solid waste service
- D. Water service

*Volume 1, Chapter 1

What utilities must be shut off immediately when basements flood?

- A. Cable and internet
- B. Electricity and gas
- C. Municipal separate stormwater collection system
- D. Solid waste and backup generators

*Volume 1, Chapter 1

Once wastewater is collected from residences and businesses, where does it go?

- A. Holding tanks in the collection system
- B. Local bodies of water
- C. Municipal separate stormwater collection systems
- D. Wastewater treatment plants

*Volume 1, Chapter 1

By using the latest technology and techniques, where can most collection systems operations be performed?

- A. Aboveground
- B. Confined spaces
- C. Control rooms
- D. Vehicles

*Volume 1, Chapter 1

If operators must work underground, how should the work be done?

- A. Quickly
- B. Safely
- C. Using ditching equipment
- D. With shoring

*Volume 1, Chapter 1

Why must the operator of a small collection system be a jack-of-all-trades?

- A. Because of the diversity of tasks
- B. Because of the lack of work for a full-time operator
- C. Because of the need to find other work to provide additional income
- D. Because of the requirement to continually train part-time operators

*Volume 1, Chapter 1

What is one aspect of incorrect installation of collection systems that causes problems?

- A. Faulty construction
- B. Flexible pipe joints
- C. Preventive maintenance programs
- D. Sufficient flow

*Volume 1, Chapter 1

What will prevent root intrusion into collection systems?

- A. Rigid joints
- B. Scouring action
- C. Sufficient flow
- D. Vapor-tight joints

*Volume 1, Chapter 1

Why are people not very concerned about collection systems?

- A. Collection systems are not as important as other community assets such as roadways and traffic signals
- B. Collection systems are out of sight, and thus out of mind
- C. Collections systems are too expensive to maintain
- D. Collection systems rarely have problems that cause concern

*Volume 1, Chapter 1

Which infrastructure project has incurred the largest investment in most communities?

- A. Electrical power grid
- B. Government buildings
- C. Streets and sidewalks
- D. Wastewater collection systems

*Volume 1, Chapter 1

What does the term inflow refer to in a wastewater collection system?

- A. Liquid wastes and liquid-carried wastes that unintentionally leak out of a sewer pipe system and into the environment
- B. The seepage of groundwater into a collection system, including service connections
- C. Water discharged into a collection system and service connections from sources other than regular connections
- D. Water or wastewater flowing from a higher elevation due to the force of gravity

*Volume 1, Chapter 1

What is one cause of an ineffective maintenance program?

- A. Airtight joints
- B. Poor records
- C. Regular analysis of records
- D. Sufficient flows

*Volume 1, Chapter 1

Which components are part of a wastewater collection system?

- A. Clarifiers and disinfection basins
- B. Force mains and manholes
- C. Intake facilities and digesters
- D. Sedimentation and flotation basins

*Volume 1, Chapter 1

What is asset management?

- A. A system whereby managers prioritize the collection system agency's assets
- B. A system whereby the collection system agency's assets are managed on a priority basis
- C. A system whereby things that are monitored and maintained are of value to the collection system agency
- D. A system whereby things that are of value to the collection system agency are monitored and maintained

*Volume 1, Chapter 1

What are important elements in the of an effective maintenance program?

- A. Emergency repairs
- B. Frequency and schedule of maintenance activities
- C. Poor recordkeeping
- D. Sanitary sewer overflows

*Volume 1, Chapter 1

What is one of the standard permit conditions for owners of sanitary sewer collection systems in the proposed sanitary sewer overflow (SSO) rule?

- A. Expand collection systems
- B. Increase the impact of SSOs
- C. Prohibition on SSOs
- D. Reduce capacity

*Volume 1, Chapter 1

In some locations, the replacement of sewer pipes is extremely expensive and practically impossible because of which factor?

- A. Because of the close proximity of other utilities
- B. Because of the rising costs of shoring materials
- C. Because operators must be trained and certified to replace sewer pipes
- D. Because the pipes must be excavated in city streets, which would impede traffic

*Volume 1, Chapter 1

What is monitored as part of the O&M program in well-managed wastewater collection system agencies?

- A. Chain of custody records
- B. Human and material resources
- C. Locations of sidewalk upheavals
- D. pH and dissolved oxygen levels

*Volume 1, Chapter 1

Which items are sources of pressure on the financial resources of a wastewater collection system agency?

- A. Fewer federal, state, and local environmental regulations
- B. Fewer safety regulations and less enforcement
- C. Increase in the skilled labor pool
- D. Reduction of federal, state, and local funds

*Volume 1, Chapter 1

Why should design engineers consult collection system operators who know how and why wastewater collection systems work?

- A. To allow design engineers to evaluate the competency of collection system operators
- B. To improve the design and construction of future systems
- C. To provide operators with the opportunity to educate design engineers
- D. To reduce the time design engineers have to spend on design and construction of projects

*Volume 1, Chapter 2 – Wastewater Collection Systems

What problems can occur when velocities in a collection system are too high or too low?

- A. The velocities can be difficult to measure and record
- B. The velocities can collect and release hydrogen sulfide gas
- C. The velocities can enhance the inhibition of corrosion
- D. The velocities can interfere with the operation and maintenance of the system

*Volume 1, Chapter 2

How is wastewater in collection systems usually conveyed?

- A. Evaporation
- B. Gravity
- C. Precipitation
- D. Suction

*Volume 1, Chapter 2

Which sources are included in determining the amount of wastewater that a collection system will convey?

- A. Commercial and domestic wastewater
- B. Hazardous discharges and pollution mitigation flows
- C. Irrigation runoff and canal overflow
- D. Precipitation and stormwater

*Volume 1, Chapter 2

What is infiltration?

- A. The direct discharge of water into a collection system
- B. The percolation of septic tank effluent into a collection system
- C. The release of boiler feed water directly into a collection system
- D. The seepage of groundwater into a collection system

*Volume 1, Chapter 2

What might cause design velocities in sewers to be reduced?

- A. Changes in pipe material
- B. Increase in sewer line maintenance activities
- C. Reduction in design flows
- D. Roots or other obstructions

*Volume 1, Chapter 2

What are used to estimate velocities in existing sewers flowing partially full?

- A. Floats
- B. Markers
- C. Pumps
- D. Vacuum systems

*Volume 1, Chapter 2

What will vary proportionally to the seasonal variation in groundwater levels and rainfall intensity in a collection system?

- A. Exfiltration and evaporation
- B. Incursion and cross-connections
- C. Infiltration and inflow
- D. Pressure and dissolved oxygen

*Volume 1, Chapter 2

What are lateral branch sewers?

- A. Sewers that connect a building's internal wastewater drainage system (plumbing) to the larger street sewer
- B. Sewers that receive the wastewater from trunk sewers and convey it to the treatment plant
- C. Sewers that serve as the main arteries of a wastewater collection system
- D. Sewers that serve the upper ends of the street sewer components of a collection system

*Volume 1, Chapter 2

Why are lift stations used in gravity collection systems?

- A. To lift wastewater when the force of gravity becomes weak
- B. To provide station locations at intervals in the collection system that are most convenient for operation and maintenance tasks
- C. To pump wastewater to a higher elevation when the slope of the route followed by a gravity sewer would cause the sewer to be laid at an insufficient slope or at an impractical depth
- D. To route wastewater under or around utilities that prevent or interfere with gravity flow

*Volume 1, Chapter 2

Which type of collection system's principal components are force mains, grinder pumps, and holding tanks?

- A. Combination
- B. Gravity
- C. Low-pressure
- D. Vacuum

*Volume 1, Chapter 2

Why must building sewer connections be constructed with care?

- A. To avoid damage to piping and tapping materials
- B. To avoid damage to the landscaping
- C. To avoid potential injuries and accidents
- D. To avoid sources of groundwater infiltration and sewer stoppages

*Volume 1, Chapter 2

When operators review collection system designs, which factors should be considered?

- A. As-built or record drawings are accurate
- B. Construction subcontractor agreements
- C. Manhole locations
- D. Professional certifications of designers

*Volume 1, Chapter 2

Which factor is not important in determining the slope of a sewer line?

- A. Available pipe bedding material
- B. Should be adequate to produce gravity flow
- C. Should be adequate to produce the minimum scouring velocity
- D. The slope of the land along the route of the sewer

*Volume 1, Chapter 2

What conditions may not produce a scouring or self-cleaning velocity in a sewer?

- A. Maximum daily flow
- B. Minimum daily flow
- C. Sanitary sewer overflow
- D. Turbulent flow

*Volume 1, Chapter 2

What information is needed to calculate the flow rate in a sewer?

- A. Elevation of the upstream manhole
- B. Pipe cross-sectional flow area
- C. Population contributing to the flow
- D. Results of a flowmeter calibration

*Volume 1, Chapter 2

Which item is a limitation of cast-iron pipe (grey iron)?

- A. Low cost
- B. Significant weight
- C. Resistant to chemical attack in corrosive soils
- D. Resistant to shear and beam breakage when improperly bedded

*Volume 1, Chapter 2

What kind of pipe is commonly used for force mains, but rarely used for gravity sewers?

- A. Acrylonitrile butadiene styrene
- B. Ductile iron
- C. Steel
- D. Vitrified clay

*Volume 1, Chapter 2

What is one advantage of polyvinyl chloride (PVC) pipe?

- A. Difficulty in field cutting and tapping
- B. Heavy weight
- C. Long laying lengths
- D. Subject to excessive deflection when improperly bedded

*Volume 1, Chapter 2

Which type of pipe joint is available for nearly all types of pipe used in collection systems?

- A. Flanged pipe joint
- B. Heat fusion pipe joint
- C. Push-on pipe joint
- D. Welded pipe joint

*Volume 1, Chapter 2

What can reduce the risk of injury or fatality to operators and coworkers before a task is begun?

- A. Carelessness
- B. Hurry
- C. Planning
- D. Shortcuts

*Volume 1, Chapter 3 – Safe Procedures

When are governing road authorities most likely to restrict construction work in streets?

- A. Low traffic periods
- B. Nighttime hours
- C. Peak traffic periods
- D. Weekend days

*Volume 1, Chapter 3

In what area should work activity and storage of equipment, vehicles, and material not occur?

- A. Buffer space
- B. Stationary work space
- C. Signage space
- D. Channelized space

*Volume 1, Chapter 3

Which item is not a major category of hazards an operator may encounter upon entering a manhole?

- A. Atmospheric hazards
- B. Insect, bug, rodent, and snake bites
- C. Physical injuries
- D. Traffic hazards

*Volume 1, Chapter 3

When must atmospheric testing be conducted?

- A. After the confined space has been vacated
- B. During warning alarm activation
- C. Only before an operator enters a confined space
- D. While the confined space is occupied

*Volume 1, Chapter 3

What does engulfment mean?

- A. Being caught up by mechanical equipment
- B. Being overcome by liquid or gas
- C. Being surrounded and captured by a liquid or finely divided (flowable) solid substance
- D. Being surrounded by high-voltage electricity

*Volume 1, Chapter 3

Which items are toxicants that may enter the wastewater collection system?

- A. Acids and bases
- B. Filtered and distilled water
- C. Residential and retail wastewater
- D. Stormwater and drinking water

*Volume 1, Chapter 3

What type of respirator provides the highest level of protection?

- A. Air-purifying respirator
- B. Air-supplying respirator
- C. Emergency escape breathing apparatus
- D. Powered-air purifying respirator

*Volume 1, Chapter 3

What should you do if you are working in a confined space and there is an atmospheric alarm condition?

- A. Conduct atmospheric testing in the confined space to determine the cause of the alarm condition
- B. Get out and stay out until the condition is cleared
- C. Ignore alarms and continue working
- D. Stay in the confined space until rescuers arrive

*Volume 1, Chapter 3

When using atmospheric analyzers to test air in confined spaces, in what order should the tests be performed?

- A. Combustible gases, toxic gases, and oxygen content
- B. Oxygen content, combustible gases, and toxic gases
- C. Oxygen content, toxic gases, and combustible gases
- D. Toxic gases, combustible gases, and oxygen content

*Volume 1, Chapter 3

Why must the electrochemical sensor in an atmospheric test instrument be replaced periodically?

- A. It becomes corroded
- B. It burns out
- C. It gets plugged
- D. It loses its sensitivity to hydrogen sulfide

*Volume 1, Chapter 3

What skin conditions provide entryway for disease-causing organisms that may be carried by water or air?

- A. Cuts, bruises, and blisters
- B. Moles, corns, and calluses
- C. Rosacea, rashes, and acne
- D. Vitiligo, hives, and warts

*Volume 1, Chapter 3

What must occur if an alarm condition develops in a confined space?

- A. Area should be evacuated, ventilated, and retested
- B. Atmospheric testing equipment should be recalibrated
- C. Confined space entry permit should be reviewed
- D. Operators should receive additional training

*Volume 1, Chapter 3

What is shoring?

- A. A complete framework of wood or metal that is designed to support the walls of a trench
- B. A wooden or metal wall placed on a trench
- C. An area near a body of water with a high groundwater table
- D. An area where surface water is readily visible and scenic

*Volume 1, Chapter 3

When installing braces or screw jacks, which one should be installed first?

- A. Bottom brace or jack
- B. Left brace or jack
- C. Right brace or jack
- D. Top brace or jack

*Volume 1, Chapter 3

Which diseases can be caused by bacteria that may be present in untreated domestic wastewater?

- A. Ascariasis and trichuriasis
- B. Cholera and typhoid fever
- C. Giardiasis and amebiasis
- D. Taeniasis and hepatitis

*Volume 1, Chapter 3

What should be done before working on any equipment that could unexpectedly start up or release stored energy?

- A. Check that all energy sources are connected
- B. Ensure that remote operation systems will function during repairs
- C. Lock out and tag out the equipment with assigned devices
- D. Remove all lockout and tagout devices on the equipment

*Volume 1, Chapter 3

What is the most effective means of controlling noise?

- A. Operator protection
- B. Path control
- C. Receiver control
- D. Source control

*Volume 1, Chapter 3

What type of material is consumed by a class B fire?

- A. Combustible materials
- B. Energized electrical equipment
- C. Flammable liquids and vapors
- D. Ordinary combustibles

*Volume 1, Chapter 3

What information is on safety data sheets?

- A. Industry-specific information
- B. Pricing information
- C. Product related information
- D. Trade and tariff information

*Volume 1, Chapter 3

What techniques are used to gather information to develop wastewater collection system operation and maintenance programs to ensure that new and existing systems serve their intended purposes?

- A. Compliance and enforcement
- B. Inspection and testing
- C. Recordkeeping and records management
- D. Sampling and data analyses

*Volume 1, Chapter 4 – Inspecting and Testing Collection Systems

Which types of problems may be caused by the existence of leaks in a wastewater collection system?

- A. Improved flow rates to wastewater treatment plants
- B. More pipe blockages
- C. Reduced flows in receiving waters stress aquatic life
- D. Public health hazards in nearby wells or open ditches

*Volume 1, Chapter 4

What is one major source of collection system problems?

- A. Coordination and communication among local agencies
- B. Good design and proper installation
- C. Improper inspection and enforcement of tap-ins and service connections
- D. Strict enforcement of sewer-use ordinances

*Volume 1, Chapter 4

Which item is not a possible source of inflow?

- A. Basement sump pumps
- B. Heating and cooling tower water
- C. High levels of groundwater
- D. Roof drains

*Volume 1, Chapter 4

How are sources of surface drainage best located?

- A. Air testing
- B. CCTV
- C. Dye testing
- D. Smoke testing

*Volume 1, Chapter 4

How does infiltration enter the wastewater collection system?

- A. Cross-connections from the drinking water supply system
- B. Deteriorated or broken pipes and joints
- C. Illegal or improper connections
- D. Surface, roof, yard, and parking lot drainage

*Volume 1, Chapter 4

What is exfiltration?

- A. Wastewater leaking out of the collection system through broken or damaged pipes and manholes
- B. Wastewater moving through the collection system as designed
- C. Water entering the wastewater collection system through deteriorated or broken pipes and joints
- D. Water entering a sewer as a result of a deliberate illegal connection

*Volume 1, Chapter 4

Why is a rocking or improperly seated manhole lid in a traffic lane a hazard?

- A. A vehicle driving over the cover can flip the lid completely out of the ring
- B. The lid can spin the ring, changing the inflow pattern
- C. The movement will cause an increase in the manhole ring elevation
- D. The rocking can eventually weaken the ring

*Volume 1, Chapter 4

What type of illegal taps might be revealed during a television inspection of a collection system conducted to search for unrecorded connections?

- A. Buried or lost
- B. Excavation and construction
- C. Industrial, stormwater, or surface drainage
- D. Misaligned or corroded

*Volume 1, Chapter 4

Which method can be used to evaluate the effectiveness of solutions and equipment in maintaining or correcting problem areas in sewers?

- A. CCTV inspection
- B. Dye testing
- C. Smoke testing
- D. Wastewater treatment plant flow rate evaluation

*Volume 1, Chapter 4

Which items may adversely affect the capacity of the sewers as a result of the construction of house service connections to the lateral and branch sewers?

- A. Collection system staff assignments
- B. Debris accumulations
- C. The contributing population
- D. Water conservation practices

*Volume 1, Chapter 4

Why is sewer cleaning generally necessary before CCTV inspections?

- A. To ensure a full day's work for all the collection system operators on staff
- B. To make a good impression on CCTV contractors
- C. To remove debris that could interfere with the operation of the TV camera
- D. To scare away any animals that may be in the pipes

*Volume 1, Chapter 4

At what set point do CCTV camera footage readings usually start?

- A. At the same set point, the center of the manhole
- B. At the same set point, the crown of the sewer leaving the upstream manhole
- C. At the same set point, the focal point of the camera
- D. At the same set point, the invert of the sewer leaving the upstream manhole

*Volume 1, Chapter 4

If a grade defect is observed during a CCTV inspection, what information should be logged?

- A. Estimation of gallons per minute
- B. Indication of how far out of line the pipe is
- C. Root intrusion scale rating
- D. Start and end point of defect

*Volume 1, Chapter 4

During CCTV inspections of active sewer lines, what must be recorded?

- A. Building connections
- B. Defects
- C. Entire pipe run
- D. Laterals

*Volume 1, Chapter 4

What can be located using smoke testing?

- A. Broken sewers due to settling of foundations, manholes, and other structures
- B. Minimal root intrusion
- C. Protruding service taps
- D. Unused septic tanks

*Volume 1, Chapter 4

When is smoke testing best done?

- A. After manholes have been inspected
- B. After the sewer has been cleaned
- C. When the groundwater is low so any cracks will leak smoke
- D. When the sewer is being inspected by CCTV

*Volume 1, Chapter 4

Which factor can prevent smoke from entering an occupied building?

- A. A defective wax ring under commodes
- B. Cleanout plugs missing from sewers
- C. Defects in the wastewater collection system of the building
- D. Wetted traps

*Volume 1, Chapter 4

What can be identified using dye tests?

- A. Illegal connections
- B. Partial root blockages
- C. Pipe defects
- D. Staffing problems

*Volume 1, Chapter 4

Which examples are typical situations where dye tests would be appropriate?

- A. After smoke testing has given conclusive results
- B. For acceptance of newly installed sewer pipes
- C. For buildings that show smoke at vents during smoke tests
- D. For estimating the velocity of flow in a sewer

*Volume 1, Chapter 4

What can produce harmful and obnoxious gases in collection systems?

- A. Air curtains
- B. Scouring velocity
- C. Solids buildup
- D. Turbulent flows

*Volume 1, Chapter 5 – Pipeline Cleaning and Maintenance Methods

Which item is a hydraulic sewer cleaning method?

- A. Bucket machines
- B. High-velocity cleaners
- C. Hand rodders
- D. Power rodders

*Volume 1, Chapter 5

Which HVC nozzles are engineered to provide a more powerful stream of water using less power with less maintenance?

- A. Bottom or floor cleaners
- B. High performance
- C. Rotational or spinning
- D. Specialty

*Volume 1, Chapter 5

Why should a high-velocity cleaner sewer hose not be empty when wound back onto the reel?

- A. Because if the hose flattens out as it is wrapped, then the next time the cleaner is used, the hose will expand and possibly damage the hose reel
- B. Because the hose may collapse and be unable to expand the next time the cleaner is used
- C. Because the weight of the empty hose may be too great for the hose reel to support
- D. Because there may not be enough space on the hose reel to contain the empty hose

*Volume 1, Chapter 5

Which devices are commonly used to clean large diameter sewers such as force mains?

- A. Bucket machines
- B. High-velocity cleaners
- C. Kites, bags, and poly pigs
- D. Power rodders

*Volume 1, Chapter 5

How does a power rodding machine clean the pipes?

- A. By pushing or pulling various cleaning tools through pipes
- B. By scooping debris out of pipes using buckets
- C. By scouring the inside of the pipe using physical scraping and high-velocity water
- D. By spraying high-pressure streams of water into the pipe to push debris down pipes

*Volume 1, Chapter 5

Why must a continuous rod be clean as it passes through the drive rollers?

- A. To avoid debris splashing on the operators
- B. To avoid the need to uncouple the rod
- C. To prevent damage and wear
- D. To prevent development of unsanitary working conditions

*Volume 1, Chapter 5

Why is a broken continuous rod in a sewer more difficult to retrieve than a broken sectional rod?

- A. Can cover greater distances
- B. Has no couplings for the pick-up tool to grab
- C. Must be cleaned as it passes through the drive rollers
- D. Reduced in operating length to the length remaining in the reel

*Volume 1, Chapter 5

Under which condition is a third operator recommended for a power rodder crew?

- A. Every time a power rodder is used
- B. If equipment must be moved frequently from site to site
- C. If there are children or pets running loose near the work site
- D. If traffic control is required

*Volume 1, Chapter 5

When changing tools on a power rodder, what should not be handled until the rodding machine has been shut down?

- A. The assembly wrench
- B. The power switch
- C. The rod guide hose
- D. The tool on the end of the rod

*Volume 1, Chapter 5

How can a broken sectional rod be recovered from a sewer?

- A. By carrying extra couplings and repair tools to the job site
- B. By digging it up
- C. By trying to reconnect the broken parts
- D. By using a pick-up tool

*Volume 1, Chapter 5

What can prevent losing considerable time attempting to recover a broken cleaning rod?

- A. Adequate maintenance of the rodding machine
- B. Inadequate maintenance before rodding
- C. Loose couplings on sectional rods
- D. Leaky hose and fittings on hydraulic units

*Volume 1, Chapter 5

Which of the following are necessary maintenance items for continuous rodders?

- A. Inspect for loose rod couplings
- B. Inspect for worn "drive dogs"
- C. Look for stacking of the rod on the reel
- D. Maintaining proper torque on the driver rollers

*Volume 1, Chapter 5

When are hand rods used extensively?

- A. For emergencies at night or during weekends
- B. For grease stoppages from restaurants
- C. For root intrusion in small-diameter sewers
- D. When only one operator is available to thoroughly clean a sewer

*Volume 1, Chapter 5

What determines whether the working bucket machine is set up at the upstream or down-stream manhole?

- A. Communication methods
- B. Field conditions
- C. Time of day
- D. Weather conditions

*Volume 1, Chapter 5

Which maintenance task on a hydraulic unit on a rodding machine is particularly important in hot weather?

- A. Drain pump daily
- B. Keep oil filter clean
- C. Maintain proper hydraulic oil level
- D. Repair leaky fittings and hoses

*Volume 1, Chapter 5

If sewer cleaning equipment is not used regularly, what maintenance task will help ensure that the engine will operate properly when needed?

- A. Check finned nozzle extension
- B. Exercise (operate) equipment weekly
- C. Inspect belt tension and packing gland
- D. Lube drive chains and high-pressure swivels

*Volume 1, Chapter 5

Which technique is not appropriate to immediately clear stoppages and blockages?

- A. Chemicals
- B. Hand rodders
- C. HVCs
- D. Power rodders

*Volume 1, Chapter 5

What is one factor that affects the rate of buildup of the grease deposit on the walls of the sewer?

- A. Depth pipe is buried
- B. Flow and velocity of wastewater
- C. Recordkeeping system
- D. Spacing of manholes

*Volume 1, Chapter 5

What factors will prevent odors in collection systems?

- A. Low-velocity flows, warmer wastewater temperatures, and long transmission lines
- B. Hotter weather, flatter sewers, and longer flow times
- C. Operator overtime, frequent breaks, and robust retirement benefits
- D. Proper design, cleaning, and maintenance

*Volume 1, Chapter 5

What may cause damage to or deterioration of underground sewer pipes?

- A. Age and natural forces
- B. Poor attitudes of management
- C. Proper construction material specifications
- D. Use of flexible joints

*Volume 1, Chapter 6 – Underground Repair and Construction

Why might bypass pumping be required during sewer repair?

- A. High flows could interfere with the repair process
- B. Low flows could interfere with the repair process
- C. Stormwater inflow could cause backups into buildings
- D. Temporary pumping could cause backups into buildings

*Volume 1, Chapter 6

What two perspectives are shown on sewer construction plans?

- A. AutoCAD and hand drawn
- B. Easements and property lines
- C. Horizontal and vertical
- D. Plan and profile

*Volume 1, Chapter 6

Why is compaction of trench backfill important?

- A. To avoid later settling
- B. To improve shoring operations
- C. To avoid using excess soil and rocks
- D. To improve the performance of the sewer

*Volume 1, Chapter 6

What are the main disadvantages of mechanical compaction of trench backfill?

- A. Availability of mechanical compaction equipment
- B. Length of time required
- C. Minimal impact reduces damage to pipe
- D. Reduces need for surface restoration

*Volume 1, Chapter 6

When are sewer main line repairs required?

- A. When a contractor is available and repair costs are reasonable
- B. When a sewer line repeatedly shows partial or complete stoppage of flow
- C. When engineering has prepared the necessary plans and specifications
- D. When underground repair crews are available

*Volume 1, Chapter 6

Before starting repair of a main line, the supervisor must perform which tasks?

- A. Barricade and mark work sites to prevent vehicle parking
- B. Contact the local traffic control agency if permits are needed to handle traffic
- C. Drive all equipment to the work site
- D. Notify local media outlets of work to be performed

*Volume 1, Chapter 6

What are sump pumps and hoses used for during sewer repairs?

- A. To cut plastic pipe
- B. To inspect the pipe
- C. To pump water out of excavations
- D. To remove loose dirt from under pipes

*Volume 1, Chapter 6

When inspecting a manhole before scheduling repair work, what is one problem that may be discovered in the manhole?

- A. Broken or collapsed pipe
- B. Improper or illegal taps
- C. Pipe with deep sags
- D. Structural failure

*Volume 1, Chapter 6

What problems can be encountered at the bottom of a manhole?

- A. A low inflow invert elevation to a high outflow invert elevation
- B. Cracked cone or barrel
- C. Frame and cover below grade
- D. Lack of flow turbulence

*Volume 1, Chapter 6

What is the most common type of pipe used for inside drop lines up to 12-inches in diameter?

- A. Galvanized steel
- B. PVC SDR 36
- C. Stainless steel
- D. Transite pipe

*Volume 1, Chapter 6

What is one way to prevent inflow through manhole covers?

- A. Drain surface waters toward the cover
- B. Install barricades above the manhole cover
- C. Install inflow dishes
- D. Install waterproof covers

*Volume 1, Chapter 6

What are inflow dishes made of?

- A. Concrete, epoxy, or mortar
- B. Stainless steel, galvanized steel, or plastic
- C. Teflon, aluminum, or copper
- D. Tin screen, nylon webbing, or polypropylene cloth

*Volume 1, Chapter 6

Which materials are suitable bedding for a wye connection?

- A. Crushed rock, gravel, and sand
- B. Lime, wood, and construction debris
- C. Large stones or rocks
- D. Recycled concrete and blacktop

*Volume 1, Chapter 6

Why must the pipe bedding in a trench be properly tamped?

- A. So the bedding can prevent infiltration
- B. So the bedding will be comfortable
- C. So the bedding will not settle after the job is completed
- D. So the use of tamping equipment can be justified

*Volume 1, Chapter 6

Who prepares a list of final items of work to be completed before acceptance of the project by public agency-owner?

- A. General manager
- B. Inspector
- C. Operator
- D. Supervisor

*Volume 1, Chapter 6

Portland cement concrete used for constructing load-bearing structures should be tested with respect to which items?

- A. Color and stain resistance
- B. Composition and density
- C. Overburden and impact loadings
- D. Availability and displacement ratio

*Volume 1, Chapter 6

Which aspects of the compaction of sewer trench backfilling be checked by an inspector?

- A. Completed in the manner and amount specified
- B. Joints made in accordance with manufacturer's instructions
- C. Laid on correct line and grade
- D. Traffic safety regulations implemented

*Volume 1, Chapter 6

Where conditions are appropriate, which test will provide an accurate test of a new sewer line's ability to convey wastewater without excessive leakage and to resist groundwater infiltration?

- A. Water dispersion test
- B. Water exfiltration test
- C. Water inflow test
- D. Water pressure test

*Volume 1, Chapter 6

What type of sewer line problems can be located by using the mandrel test?

- A. Building sewer connections that protrude into main lines
- B. Illegal taps
- C. Improper grade and line
- D. Small cracks and leaks

*Volume 1, Chapter 6

What is wastewater that flows out of a sanitary sewer (or lift station) because of flows exceeding the hydraulic capacity of the sewer or stoppages in the sewer, or a discharge of wastewater from a location that is not authorized by an NPDES permit?

- A. SSES
- B. CSO
- C. I/I
- D. SSO

*Volume 2, Chapter 1 – Introduction to CMOM

What is made up of the accepted industry practices for properly managing, operating, and maintaining sanitary wastewater collection, transmission, and treatment systems?

- A. Capacity, management, operation, and maintenance program
- B. Preventative maintenance program
- C. Asset management program
- D. National pollutant discharge elimination system

*Volume 2, Chapter 1

What is infiltration?

- A. Bottoms of trenches in which gravity pipes are installed that allow water to move down the trench
- B. Seepage of groundwater into a wastewater collection system
- C. Gradual decomposition or destruction of material by chemical action
- D. Water and water-carried wastes that unintentionally leak out of defects in a collection system pipe

*Volume 2, Chapter 1

What can be caused by increased flow in the system (Inflow/Infiltration problems), pipe failures (tree root intrusions; blocked, broken, or cracked pipes; and pipe settlement at the joints), and manhole deterioration?

- A. I/I
- B. NPDES
- C. SSES
- D. SSO

*Volume 2, Chapter 1

What hazard category includes injury or illness caused by the surroundings or situation where work takes place?

- A. Acute
- B. Exposures
- C. Chronic
- D. Work environment or condition

*Volume 2, Chapter 1

What infection route involves breathing spray or mist containing pathogens?

- A. Direct contact
- B. Person-to-person
- C. Ingestion
- D. Inhalation

*Volume 2, Chapter 1

What can prevent a mix of combustible gas and oxygen from exploding when it contacts a spark or flame?

- A. Gas company experts
- B. Too rich or too lean
- C. Addition of water
- D. Containment

*Volume 2, Chapter 1

When should the public, health agencies, drinking water suppliers, and other affected entities be notified of an SSO that has the immediate potential to substantially endanger public health?

- A. As soon as response crew has been sent out
- B. Immediately
- C. Depends on NPDES permit specifications
- D. Within 72 hours

*Volume 2, Chapter 1

What is often the first indication that something is wrong in the collection system?

- A. Performance indicators
- B. Work orders
- C. Sewer system evaluations
- D. Customer complaints

*Volume 2, Chapter 1

How are collection system utilities able to ensure that new and rehabilitated collection pipes and connections have been properly designed, constructed, and tested before put into service?

- A. Required by preventative maintenance programs
- B. Implicit in CMOM program implementation
- C. Capital improvement program budgets allow for these activities
- D. Legal authority given by legally binding documents

*Volume 2, Chapter 1

Where can operators look up what has been constructed, where, what size, the materials used, and the conditions encountered?

- A. Standard operating procedures
- B. Computerized maintenance management systems
- C. As-built drawings
- D. System maps

*Volume 2, Chapter 1

Who is responsible for providing timely, relevant information about the collection system for planning, implementing, reviewing, and evaluating CMOM programs?

- A. Support staff
- B. Computer mapping technicians
- C. Operators
- D. Stakeholders

*Volume 2, Chapter 1

What decreases the capacity of a collection system?

- A. Increases in the roughness of pipes
- B. Constant hydraulic loads
- C. Scouring velocities
- D. Decreases in pipe bedding

*Volume 2, Chapter 1

What can significantly reduce repair and rehabilitation costs by providing accurate information on the causes of an SSO problem?

- A. Parts and supplies inventory
- B. Emergency repair work orders
- C. Detailed evaluation of the collection system
- D. Construction warranties

*Volume 2, Chapter 1

What should receive the highest priority for corrective actions in a capacity assurance plan?

- A. SSOs resulting from rainfall-induced infiltration
- B. SSOs that can be corrected easily and inexpensively
- C. SSOs that substantially endanger human health now or near the future
- D. Anticipated flow increases from planned new connections

*Volume 2, Chapter 1

What can make needed parts and supplies available quickly, thereby reducing equipment downtime and work delays?

- A. Implementing a procurement process
- B. Maintaining an equipment and replacement parts inventory
- C. Keeping a stock of supplies and parts with little organization
- D. Ordering parts and supplies when equipment fails

*Volume 2, Chapter 1

How can operators ensure that new components are installed and repaired according to accepted standards and requirements to minimize future problems with those components?

- A. Inspection and testing
- B. Proactive and preventative maintenance
- C. Prioritization and risk assessment
- D. Legal authority and compliance

*Volume 2, Chapter 1

What can be used to measure and report progress toward achieving goals and objectives?

- A. Plans and specifications
- B. Performance indicators
- C. Work orders
- D. Capital improvement plans

*Volume 2, Chapter 1

Which piece of equipment carries wastewater under pressure from the discharge side of a pump to a point of gravity flow downstream?

- A. Trunk sewer
- B. Centrifugal pump
- C. Force main
- D. Pumping station

*Volume 2, Chapter 2 – Lift Stations

Where in the collection system are lift stations installed?

- A. Less populated section of the service area
- B. Where pumping stations are too expensive
- C. Low points at the end of gravity systems
- D. Points of convergence for wastewater tributaries

*Volume 2, Chapter 2

Which stations are generally used to lift small to medium wastewater flows?

- A. Pumping stations
- B. Suction lift stations
- C. Submersible lift stations
- D. Dry pit stations

*Volume 2, Chapter 2

What is a solution to water hammer and negative pressures strong enough to collapse a pipe?

- A. Readjust pump to run at rated head
- B. Reduce wastewater flow in a pipe
- C. Install lift station higher up the collection system
- D. Install air release valves

*Volume 2, Chapter 2

How are most pump capacities rated?

- A. In gallons per minute
- B. In horsepower
- C. By flow rate
- D. By size

*Volume 2, Chapter 2

What describes the vertical distance from a reference point to the water surface when the water is not moving?

- A. Submergence
- B. Elevation head
- C. Depth
- D. Static head

*Volume 2, Chapter 2

How does vortexing happen within a pump?

- A. Mechanical seal failure
- B. Flooding of the pump casing
- C. Water drawn too rapidly into the pump
- D. Backsiphonage due to clogging

*Volume 2, Chapter 2

Where does an operator interact with the control system?

- A. Motor control center
- B. Remote terminal unit
- C. Circuit breaker
- D. Human machine interface

*Volume 2, Chapter 2

What nameplate data indicates how long a motor can be run continuously at or above its rated horsepower without causing damage to the insulation?

- A. Ambient temperature
- B. Service factor
- C. RPM
- D. Class of insulation

*Volume 2, Chapter 2

Which type of motor is most commonly used to drive raw wastewater pumps?

- A. Phase wound induction
- B. Alternating current synchronous
- C. Direct current
- D. Squirrel cage induction

*Volume 2, Chapter 2

When is it recommended to include additional insulation treatment to improve the moisture resistance of motor insulation?

- A. For NEMA design C motors
- B. In submersible lift station motors
- C. In damp or warm weather climates
- D. Annually as part of a preventative maintenance program

*Volume 2, Chapter 2

What is the kilovolt-ampere per horsepower requirement for a NEMA Code G motor?

- A. 4.50-5.00 kVA/hp
- B. 5.00-5.60 kVA/hp
- C. 5.60-6.30 kVA/hp
- D. 6.30-7.10 kVA/hp

*Volume 2, Chapter 2

Which type of starter uses microprocessor-controlled SCRs to regulate motor starting and is frequently furnished with a wide variety of functions to boost performance?

- A. Auto-transformer starter
- B. Level transducer
- C. Primary resistor starter
- D. Solid-state controls

*Volume 2, Chapter 2

Which type of level-sensing device may become entangled with other floats and cables in the wet well?

- A. Air bubbler system
- B. Float switches
- C. Electrode sensors
- D. Ultrasonic transducers

*Volume 2, Chapter 2

What describes a reverse flow condition, created by a difference in water pressures, that causes water to flow back into the distribution pipes of a potable water supply?

- A. Backsiphonage
- B. Backflow
- C. Positive displacement
- D. Negative pressure

*Volume 2, Chapter 2

Which pump component provides separation between the liquid end of the pump and the atmosphere?

- A. Gate valve
- B. Keyway
- C. Packing box
- D. Wear rings

*Volume 2, Chapter 2

What is a measurement of the amount of energy that a pump must develop to move a liquid?

- A. Suction lift
- B. Gravity flow
- C. Total dynamic head
- D. Brake horsepower

*Volume 2, Chapter 2

What type of valve is an example of a discharge check valve?

- A. Swing
- B. Gate
- C. Plug
- D. Needle

*Volume 2, Chapter 2

Why should operators be given the chance to participate in the planning and design of new and rehabilitated lift stations?

- A. Ensure resources for proper O&M
- B. Operators will have final say in station design
- C. Oversee design engineer
- D. Will accept new station after preliminary walk-through

*Volume 2, Chapter 2

What is a likely cause of overflows and backups when the pumps do not start and/or damage occurs to the pump from short cycling?

- A. Cavitation
- B. Incorrectly configured wet well level controls
- C. Improperly packed stuffing boxes
- D. Leaking shaft sleeve or cracked mechanical seal

*Volume 2, Chapter 2

How can an operating agency best ensure continuous, efficient, and reliable lift station operation?

- A. Checking lift stations and treatment facilities daily
- B. Following manufacturer-recommended O&M
- C. Responding to emergency situations and customer complaints quickly
- D. Updating all station equipment to a CMMS-based system

*Volume 2, Chapter 2

What practice effectively tracks process control changes and serves as a historical reference for future decisions?

- A. SCADA system
- B. Proactive maintenance
- C. HMI setup
- D. Sign-in log

*Volume 2, Chapter 2

What is the most common reason for a malfunctioning instrument to trigger an alarm?

- A. Backsiphonage
- B. Blown fuses
- C. Erratic measurements
- D. Operator error

*Volume 2, Chapter 2

Which odor control method inhibits the activity of the sulfate-reducing bacteria that release hydrogen sulfide?

- A. Adding iron salts
- B. Nitrate addition
- C. Oxygen injection
- D. pH adjustment

*Volume 2, Chapter 2

When does the CMMS automatically update the maintenance schedule and all other related database information?

- A. During manual and hard resets
- B. At a prescribed time, such as midnight
- C. After completed work orders are submitted
- D. Once the sign-in log has been submitted

*Volume 2, Chapter 2

Where should active lift station records be kept?

- A. Locked in the supervisor's office
- B. In the office copy of the station book
- C. Stored in a cabinet in the lift station dry pit
- D. On service or utility vehicles going out to assignments

*Volume 2, Chapter 2

What type of report is most useful in preparing next year's annual budget for the utility?

- A. Work orders
- B. Operational data
- C. Written reports
- D. Cost records

*Volume 2, Chapter 2

Replacing a pump when its performance deteriorates but before it stops working is an example of which type of maintenance?

- A. Reactive
- B. Preventative
- C. Predictive
- D. Emergency

*Volume 2, Chapter 3 – Equipment Maintenance

Which term best describes the gradual decomposition of a material by chemical action, often due to an electrochemical reaction?

- A. Deterioration
- B. Anaerobic digestion
- C. Electrowinning
- D. Corrosion

*Volume 2, Chapter 3

Who installs the lock on the energy-isolating device when maintenance work is being done on equipment?

- A. Supervisor
- B. Competent person
- C. Operator doing the work
- D. Anyone authorized by management

*Volume 2, Chapter 3

What describes an electrical connection to earth or a large conductor at the earth's potential or neutral voltage?

- A. Circuit
- B. Ground
- C. Fuse
- D. Ohm

*Volume 2, Chapter 3

Where can you find information like the proper voltage and allowable current on a piece of electrical equipment?

- A. Nameplate
- B. Safety data sheet
- C. Hazard communication
- D. Circuit breaker

*Volume 2, Chapter 3

What describes the strength of an electric current in amperes?

- A. Electromotive force
- B. Voltage
- C. Resistance
- D. Amperage

*Volume 2, Chapter 3

Which term describes the frequency of cycles completed per second?

- A. Hertz
- B. Amplitude
- C. Direct current
- D. Ohm

*Volume 2, Chapter 3

How is energy requirement expressed?

- A. Amps
- B. Kilowatts
- C. Horsepower
- D. Kilowatt-hours

*Volume 2, Chapter 3

What device is used to measure voltage?

- A. Ammeter
- B. Multimeter
- C. Megger
- D. Ohmmeter

*Volume 2, Chapter 3

If you are testing for unbalance and find that the readings on lines L1, L2, and L3 are all about the same before and after changing the wiring, what can you assume about the problem?

- A. It is in the motor
- B. It is caused by the pump
- C. The test equipment is faulty
- D. It is caused by the power company

*Volume 2, Chapter 3

What is a major advantage of using aluminum over copper as a conductor?

- A. Slower oxidation
- B. More economical
- C. Much softer
- D. Requires less maintenance

*Volume 2, Chapter 3

What machines are most commonly used to convert electrical energy to mechanical energy in a lift station?

- A. Electric motor
- B. Centrifugal pump
- C. Single-phase circuit
- D. Motor control center

*Volume 2, Chapter 3

What is one of the most common causes of motor failure?

- A. Unbalance
- B. Old age
- C. Overheating
- D. Bearing failure

*Volume 2, Chapter 3

What is the more common name for overload protection devices?

- A. Fuses
- B. Lockout devices
- C. Circuit breakers
- D. Heater elements

*Volume 2, Chapter 3

What is a coupling designed to do?

- A. Meter power outputs
- B. Transmit torque from the motor to the pump
- C. Lockout motors that are not currently needed
- D. Connect all motors and pumps within the station

*Volume 2, Chapter 3

What is the first step of troubleshooting an electric motor?

- A. Make a visual inspection
- B. Examine all factors
- C. Consider what should happen
- D. Analyze what you know

*Volume 2, Chapter 3

Why are pumps used in collection systems?

- A. To separate wastewater from stormwater
- B. To generate energy for the motors
- C. To move wastewater when there is no gravity flow
- D. To lower wastewater in elevation

*Volume 2, Chapter 3

Which type of pump consists of an impeller fixed on a rotating shaft that is enclosed in a casing and has an inlet and discharge connection?

- A. Screw pump
- B. Diaphragm pump
- C. Turbine pump
- D. Centrifugal pump

*Volume 2, Chapter 3

Which pump part is a spiral-shaped casing that surrounds the pump's rotating vanes and collects the discharged liquid or gas?

- A. Volute
- B. Impeller
- C. Sleeve
- D. Shaft

*Volume 2, Chapter 3

What is one of the limitations of submersible pumps?

- A. Much more expensive than other types
- B. Burnout of the motor from water leakage
- C. Require a large amount of daily maintenance
- D. Packing must be used and wears out quickly

*Volume 2, Chapter 3

If a diaphragm pump will not cycle, what should you check for?

- A. Whether the suction line is plugged
- B. If check valves are not seating
- C. If the inlet valve is open
- D. Whether the suction lift is too high

*Volume 2, Chapter 3

Why do wastewater pumps commonly have larger clearances?

- A. Reduce erosion by solid particles
- B. Create higher suction
- C. Allow for greater flow rate
- D. Reduce turbidity and aeration

*Volume 2, Chapter 3

What is the name for thin metal sheets inserted between 2 surfaces to align or space the surfaces correctly?

- A. Shear pins
- B. Shims
- C. Sumps
- D. Slugs

*Volume 2, Chapter 3

How is a worn ring removed from a pump impeller or volute?

- A. Through heat erosion
- B. Worn rings should slip off easily
- C. Cutting or grinding them off
- D. Replacing the impeller or volute

*Volume 2, Chapter 3

Type of pump, material being pumped, temperature of liquid being pumped, grease or water flushing, and peripheral speed of shaft are all considerations when choosing which pump component?

- A. Valve
- B. Shaft sleeves
- C. Couplings
- D. Packing

*Volume 2, Chapter 3

Which preventative maintenance task for pumps should be performed daily?

- A. Check stator winding assembly
- B. Inspect pumps controls for correct response to variable control
- C. Inspect and lubricate bearings
- D. Check piping connections for leaks or corrosion

*Volume 2, Chapter 3

Why do compressors get extremely hot when working?

- A. It is easy for them to malfunction
- B. Hot water is needed in the process
- C. Gases give off heat when compressed
- D. Friction buildup on the compressor side

*Volume 2, Chapter 3

Which factor contributes significantly to the deterioration of a collection system?

- A. Short-term system repairs
- B. Rapid system expansion
- C. Sewer surcharge
- D. I/I

*Volume 2, Chapter 4 - Rehabilitation

Where do most utilities store their collection system records?

- A. A data card system
- B. In individual operator files for quick reference
- C. Utility logbooks
- D. GIS and CAD systems

*Volume 2, Chapter 4

What is a major problem to a collection system from a public relations viewpoint?

- A. Low I/I levels
- B. Traffic and street closures
- C. Surcharge backflooding into private property
- D. Underloading the collection system mains

*Volume 2, Chapter 4

What is the cause of backflow?

- A. Gravity
- B. Equal water pressures
- C. A difference in pipe sizes
- D. A difference in water pressures

*Volume 2, Chapter 4

What is an important component in the hydraulic analysis phase?

- A. Night flow isolation
- B. Groundwater measurement
- C. The production of flow guidelines and hydrographs
- D. Precipitation runoff

*Volume 2, Chapter 4

What is a cause of leakage at a manhole?

- A. Worn cover ring
- B. Storm drain cross connection
- C. Point source leak
- D. Defective cleanout leak

*Volume 2, Chapter 4

Which is the preferred method for locating rainfall-induced leaks?

- A. Smoke testing
- B. Chemical markers in the collection system
- C. Dyed water flooding
- D. Through point source leaks

*Volume 2, Chapter 4

What does a positive reading of a smoke test indicate?

- A. I/I sources
- B. Where pipes are leaking
- C. Cross bores
- D. Prime locations for dye testing

*Volume 2, Chapter 4

When examining for sewer pipe structural defects, what information should you record?

- A. Precast joint condition
- B. Circumferential and longitudinal cracks
- C. Step condition
- D. Collection systems surcharging

*Volume 2, Chapter 4

What is the most effective method of identifying and quantifying defects in collection system pipes?

- A. Flow monitoring
- B. Smoke testing
- C. Dyed water testing
- D. CCTV

*Volume 2, Chapter 4

Which term describes a fair rating in NASSCO's PACP pipeline rating system for utilities and municipalities?

- A. Needs attention immediately
- B. Defects will continue to worsen
- C. Severe defects are seen
- D. Defects are not deteriorating

*Volume 2, Chapter 4

What should a rehabilitation program problem history include?

- A. Design specifications of flow capacities
- B. Up-to-date system maps
- C. Historical data concerning problem areas such as maintenance limitations
- D. An itemized list of all system components

*Volume 2, Chapter 4

What should a preliminary statement of needs list include?

- A. Needed tasks in order of urgency
- B. Tasks recently finished and their outcomes
- C. Costs involved in the rehab process
- D. A utility's wish list

*Volume 2, Chapter 4

Which costs should be considered when evaluating the cost effectiveness of an I/I rehabilitation program?

- A. Public relations costs
- B. Return-to-utility costs
- C. Operation and maintenance costs
- D. Personal costs

*Volume 2, Chapter 4

Which problem is unique to the excavation and replacement method?

- A. Noise
- B. Traffic disruption and control
- C. Shoring requirements
- D. Effects on other utilities

*Volume 2, Chapter 4

What do you use for pressure grouting large-diameter collection pipes?

- A. Pipe grouting pumps
- B. Pipe grouting rings or predrilled injection holes
- C. Sealant pumps
- D. In-pipe robots

*Volume 2, Chapter 4

What does the pipe bursting method involve?

- A. A tool to break up the pipe while it is still in the ground
- B. A cured-in-place pipe liner
- C. Injecting a chemical around the outside of the pipe to fill voids
- D. Cementitious liners

*Volume 2, Chapter 4

Which is a disadvantage to using the CIPP rehabilitation method?

- A. No grouting is required
- B. Essentially no annular space is left between the old and new pipe
- C. Excavation typically is required for either the installation process or reestablishment of house connections
- D. Setup costs are high on small projects

*Volume 2, Chapter 4

What is shotcrete?

- A. A slurry of cement and water
- B. A mixture of sand, cement, and water
- C. A mixture of resin, cement, and heat
- D. A slurry of resin, cement, and water

*Volume 2, Chapter 4

How is shotcrete applied?

- A. Air pressure
- B. Trowel
- C. Inversion tube
- D. Gravity flow

*Volume 2, Chapter 4

When should sliplining be used?

- A. When there are obstructions inside the old pipe
- B. When the old pipe is excessively deteriorated
- C. When no obstruction exists inside the old pipe
- D. When the old pipe's dimensions are in poor shape

*Volume 2, Chapter 4

Which is an advantage of the pipe displacement rehabilitation method?

- A. Trained operators are needed
- B. The existing pipe must be friable, not reinforced concrete
- C. The liner can be installed with an insertion pit or a manhole
- D. Excavation is required to disconnect and reconnect the laterals

*Volume 2, Chapter 4

What is a limitation of the drawdown pipe rehabilitation method?

- A. High overall costs
- B. House connections need a remote-control cutter to reconnect
- C. High mobilization costs
- D. The liner forms tightly against the wall of the original pipe and leaves no annular space

*Volume 2, Chapter 4

What is the purpose of the frame backstop in the manhole for the inversion tube rehabilitation method?

- A. To ensure the stopping position of the liner bag
- B. To hold the liner bag
- C. To determine the required liner bag length
- D. To hold the liner bag on the inversion tube platform

*Volume 2, Chapter 4

What is the purpose of a christy box?

- A. Assist in installing a saddle on the main line
- B. Keep the push hole from collapsing
- C. Replace the plastic cap on the riser
- D. Serve as the cleanout point

*Volume 2, Chapter 4

Which is a potential I/I entry point in a collection system?

- A. Only at cross bores
- B. At each joint in the service
- C. Only at the tap
- D. Only at the property line

*Volume 2, Chapter 4

What is a sewer sausage?

- A. A sewer service sealing unit that requires a special packer with an inflatable tube
- B. A way to make sure the pipe is full of grout
- C. A camera/packer combination to seal the pipe
- D. A pipe-cleaning tool also known as a poly pig

*Volume 2, Chapter 4

What can make manhole joints potentially susceptible to infiltration?

- A. Stormwater runoff
- B. Inflow
- C. Surcharge of collection system
- D. Groundwater

*Volume 2, Chapter 4

Which is a disadvantage to the manhole rehabilitation method of structural relining?

- A. Raises manhole cover slightly
- B. Excavation required
- C. Loss of steps
- D. Loss of venting

*Volume 2, Chapter 4

What is the managerial function controlling?

- A. Recruiting new operators and staff and determining if there are enough qualified operators and staff to fill available positions
- B. Taking the steps necessary to ensure that essential activities are performed so that objectives will be achieved as planned
- C. Determining the goals, policies, procedures, and other elements to achieve the goals and objectives of the agency
- D. Guiding, teaching, motivating, and supervising operators and utility staff members

*Volume 2, Chapter 5 - Management

What may be the most difficult planning problem for utilities in small communities?

- A. Recognizing and planning for a decline in population
- B. Controlling the treatment process to ensure that water is being properly treated
- C. Selecting and training employees and evaluating their performance
- D. Keeping up with technological changes and new procedures

*Volume 2, Chapter 5

What is responsibility?

- A. Answering to those above you in the chain of command to explain how and why you have used your authority
- B. Power is given to another person in the organization to accomplish a specific job
- C. When a manager gives power or responsibility to an employee, the employee ensures that the manager is informed of results or events
- D. The power and resources to do a specific job or to get that job done

*Volume 2, Chapter 5

What components make up a successful delegation by a supervisor?

- A. Proper job assignments, authority, and responsibility
- B. Power and resources to do a specific job
- C. Short- and long-term goals and plans
- D. Organizational plan and written policies

*Volume 2, Chapter 5

Why should a manager examine the work requirements and staffing of the utility on a periodic basis?

- A. To ensure that the utility is operating as efficiently as possible
- B. To develop qualification profiles
- C. To eliminate unqualified applicants from the interview pool
- D. To answer questions from new employees during employee orientation

*Volume 2, Chapter 5

What is the best way for a manager to prevent harassment in the workplace?

- A. Set an example by behavior and keep communication open between employees
- B. Distribute copies of the utility's harassment policy
- C. Ignore occasional flirting, innuendo, or jokes that do not meet the legal definition of harassment
- D. Insist that the employee with a complaint meet with the employee the complaint is against

*Volume 2, Chapter 5

What should a utility's annual report summarize?

- A. Daily flow rates, new connections installed, and repairs completed for the last year
- B. Spare parts inventory, preventative maintenance task lists, and purchase orders for the last year
- C. Expenses, treatment services provided, and revenues generated over the last year
- D. Employee records including pay rates, disciplinary actions, and sick leave taken over the last year

*Volume 2, Chapter 5

Why should employees be trained to deal positively with the public?

- A. To contribute to favorable first impressions of the organization
- B. To get press coverage for events and press conferences
- C. To evaluate employees' ability to make prepared speeches
- D. To prepare operators for arguments with consumers

*Volume 2, Chapter 5

What is the purpose of a repair/replacement fund?

- A. To generate additional revenue to pay for the repair or replacement of capital equipment as the equipment wears out
- B. To generate additional revenue to pay for system expansion
- C. To generate additional revenue to reduce water rates for economically disadvantaged consumers
- D. To generate additional revenue to improve the coverage and operating ratios

*Volume 2, Chapter 5

What do you need to calculate to decide among several options to meet a capital improvement need?

- A. Payback time
- B. Water rates
- C. Operating ratio
- D. Present worth

*Volume 2, Chapter 5

Who defines the safety program responsibilities of manager, supervisors, and employees for safety and health in the workplace?

- A. Safety committee
- B. Program administrator
- C. Superintendent
- D. Operators

*Volume 2, Chapter 5

What level of the safety program is responsible for coordinating and distributing safety requirements and regulations?

- A. Safety department
- B. Supervisors
- C. Operators
- D. Safety committee

*Volume 2, Chapter 5

Which kind of safety meetings are short discussions that help put the focus on safety as part of everyday routine collection system operator tasks?

- A. Monthly safety meetings
- B. Supplier presentations on equipment
- C. Presentations from other municipal departments
- D. Tailgate safety meetings

*Volume 2, Chapter 5

What is a way for employers to inform exposed employees of the existence, location, and danger posed by specific confined spaces?

- A. Distribute confined space policy
- B. Provide employees with safety data sheets
- C. Post danger signs
- D. Implement atmospheric testing

*Volume 2, Chapter 5

What kind of employee should be trained to recognize when a lockout/tagout procedure is being implemented, to understand the purpose of the procedure, and to avoid attempting to start up or use the equipment that has been locked or tagged out?

- A. Attendant
- B. Affected
- C. Other
- D. Authorized

*Volume 2, Chapter 5

What can cause reduced vision when wearing eye protection?

- A. Loose nosepieces
- B. Lack of disinfection between uses by multiple employees
- C. Worn-out headband
- D. Pitted or dirty lenses

*Volume 2, Chapter 5

What are the most common causes of on-the-job head injuries?

- A. Flames and hair entanglement
- B. Engulfment and asphyxiation
- C. Falling or flying objects and head bumps against fixed objects
- D. Chemical or toxic splashes, spills, and drips

*Volume 2, Chapter 5

Who is responsible for ensuring that no information about an incident is overlooked that may be helpful in preventing recurrences?

- A. Safety officer
- B. Operator
- C. Supervisor
- D. Manager

*Volume 2, Chapter 5

What can help identify wastewater facilities or operations that may be at risk during human-caused and natural disasters?

- A. Emergency communication plan
- B. Vulnerability assessment
- C. National Terrorism Advisory System
- D. Mutual aid agreement

*Volume 2, Chapter 5

What should be reported to county or state health officials?

- A. Attacks on wastewater facilities
- B. Suspicious behavior
- C. Criminal threats
- D. Employee illness associated with wastewater contamination

*Volume 2, Chapter 5

What can help utilities respond quicker to emergencies and avoid some altogether?

- A. Personal protective equipment
- B. Preventative maintenance program
- C. National Terrorism Advisory system
- D. Sewer system evaluation survey

*Volume 2, Chapter 5

What kind of monitoring is used to isolate line segments with excessive infiltration?

- A. Instantaneous flow monitoring
- B. Discharge compliance monitoring
- C. Temporary flow monitoring
- D. Long-term flow monitoring

*Volume 2, Chapter 5

Which economic approach to level of service measures the costs associated with the O&M program and accurate measurement of the program benefits?

- A. Minimizing costs
- B. Community determined benefits
- C. Maximizing net benefits
- D. Cost effectiveness

*Volume 2, Chapter 5

As part of CMOM best practices, what should managers use to determine whether to repair, replace, or rehabilitate system components?

- A. Expected life cycles
- B. Performance indicators
- C. Conditions and performance
- D. Construction warranties

*Volume 2, Chapter 5

Who evaluates the problems, assigns priorities, redirects service crews, and requests assistance from preventative maintenance crews when multiple emergency calls are received?

- A. Assistant superintendent
- B. Section supervisor
- C. Most experienced crew
- D. Dispatcher

*Volume 2, Chapter 5

What is the best way to prevent flooding caused by a service line connection that is low in relation to the collection system and is an overflow point?

- A. Install a backflow preventer and an overflow valve
- B. Record all relevant information manually or electronically in a permanent log
- C. Alert an agency crew to the property to assist in cleaning and removing damaged articles
- D. Give instructions to the homeowner that will avoid damage from impending wastewater flows

*Volume 2, Chapter 5

Who performs level 1 maintenance at a lift station?

- A. Journey-level tradespeople, lead person/line supervisor, and manager
- B. Any available crew of operators from any section in the organization
- C. Skilled tradespeople such as electricians, pipefitters, machinists, and mechanics
- D. Operators with a broad background and understanding of the various types of equipment and systems installed in lift stations

*Volume 2, Chapter 5

Which section of the wastewater collection agency determines the need for preventative maintenance, repairs, and replacements in all areas of the system except lift stations?

- A. Repair and replacement section
- B. Preventative maintenance section
- C. Service request response section
- D. Inspection and investigation section

*Volume 2, Chapter 5

Why is it important for collection utilities to communicate with the wastewater treatment plant?

- A. To coordinate operations and solve problems that affect wastewater systems
- B. To ensure that the collection system is being operated and maintained according to established plans and norms
- C. To ensure that people in the organization have the information they need to do their jobs well and safely
- D. To encourage operators to suggest ways to improve wastewater systems performance

*Volume 2, Chapter 5

What allows managers to rapidly manipulate large amounts of information so that it is quickly accessible and usable when performing collection system O&M?

- A. CMMS
- B. CCTV
- C. CMOM
- D. SSES

*Volume 2, Chapter 5

What gives collection system agencies the ability to develop and enforce regulations regarding the inspection, operation, and maintenance of grease traps and grease interceptors?

- A. Legal authority
- B. CMOM program
- C. Capacity assurance plan
- D. O&M plan to prevent grease buildup in pipes

*Volume 2, Chapter 5

After an SSO event, how long should the water quality in nearby waters be monitored?

- A. A minimum of 6 months
- B. Until adverse impacts are determined
- C. Depends on the type of nearby waters
- D. Until no adverse impacts are detected

*Volume 2, Chapter 5

What kind of program may be needed to address frequent odor complaints?

- A. Water quality monitoring
- B. Grease control
- C. Hydrogen sulfide control
- D. Capital improvement

*Volume 2, Chapter 5

What documentation shows who at the collection system agency does what and when under disaster conditions?

- A. Reports on previous emergencies
- B. Mutual aid agreements
- C. Emergency operations plan
- D. Vulnerability assessment

*Volume 2, Chapter 5

What should be shown by footage from connecting manholes, by scale in relation to property lines and property corners, and by coordinates on collection system maps?

- A. Pipes in easements
- B. Main pipelines
- C. Building connections
- D. Manholes

*Volume 2, Chapter 5

What are shape files?

- A. Maps at a scale that clearly shows identification numbers, footage, and pipe sizes
- B. Information delivered to skilled drafting or computer personnel to update maps
- C. Layers that display different types of information about the physical structures or components in a geographic area
- D. Accurate, legal records showing property identifications and sizes, rights of way, and street names and widths

*Volume 2, Chapter 5

What is the ideal maintenance schedule?

- A. Maintenance is performed when operators are not busy with other tasks
- B. Maintenance takes place only at prescribed intervals based on equipment run time
- C. Maintenance is performed when equipment or systems fail
- D. Maintenance is scheduled only when needed to avoid problems or emergencies

*Volume 2, Chapter 5

When should how critical the part is, the lead time from manufacturer, and the frequency of usage of a particular part be considered?

- A. When deciding whether to reject defective or damaged shipments
- B. When conducting an inventory of tools
- C. When stocking parts or materials at a warehouse
- D. When repairing equipment in the field

*Volume 2, Chapter 5